

COOLPIX A100



Reference Manual

Introduction	→ i
Table of Contents	→ xi
Parts of the Camera	→ 1
Preparing for Shooting	→ 6
Basic Shooting and Playback Operations	→ 11
Shooting Features	→ 19
Playback Features	→ 46
Recording and Playing Back Movies	⇒ 55
Using Menus	⇒ 59
Connecting the Camera to a TV, Printer, or Computer	→ 90
Technical Notes	→ 100

Introduction

Read This First

To get the most from this Nikon product, be sure to read "For Your Safety" (\(\Divi-\tilde{\text{viii}}\)), and all other instructions thoroughly and keep them where they will be read by all who use the camera.

 If you want to start using the camera right away, see "Preparing for Shooting" (□6) and "Basic Shooting and Playback Operations" (□11).


Other Information

Symbols and Conventions

Symbol	Description
V	This icon marks cautions and information that should be read before using the camera.
Ø	This icon marks notes and information that should be read before using the camera.
\Box	This icon marks other pages containing relevant information.

- SD, SDHC, and SDXC memory cards are referred to as "memory cards" in this
 manual.
- The setting at the time of purchase is referred to as the "default setting."
- The names of menu items displayed in the camera monitor, and the names of buttons or messages displayed on a computer monitor appear in bold.
- In this manual, images are sometimes omitted from monitor display samples so that monitor indicators can be more clearly shown.

How to Attach the Camera Strap



Information and Precautions

Life-Long Learning

As part of Nikon's "Life-Long Learning" commitment to ongoing product support and education, continually updated information is available online at the following websites:

- For users in the U.S.A.: http://www.nikonusa.com/
- For users in Europe: http://www.europe-nikon.com/support/
- For users in Asia, Oceania, the Middle East, and Africa: http://www.nikon-asia.com/
 Visit these websites to keep up-to-date with the latest product information, tips, answers to frequently asked questions (FAQs), and general advice on digital imaging and photography. Additional information may be available from the Nikon representative in your area. Visit the website below for contact information. http://imaging.nikon.com/

Use Only Nikon Brand Electronic Accessories

Nikon COOLPIX cameras are designed to the highest standards and include complex electronic circuitry. Only Nikon brand electronic accessories (including battery chargers, batteries, Charging AC Adapter, and AC adapters) certified by Nikon specifically for use with this Nikon digital camera are engineered and proven to operate within the operational and safety requirements of this electronic circuitry. The USE OF NON-NIKON ELECTRONIC ACCESSORIES COULD DAMAGE THE CAMERA AND MAY VOID YOUR NIKON WARRANTY.

The use of third-party rechargeable Li-ion batteries not bearing the Nikon holographic seal could interfere with normal operation of the camera or result in the batteries overheating, igniting, rupturing, or leaking.

Holographic seal: Identifies this device as an authentic Nikon product.



For more information about Nikon brand accessories, contact a local authorized Nikon dealer.

Before Taking Important Pictures

Before taking pictures on important occasions (such as at weddings or before taking the camera on a trip), take a test shot to ensure that the camera is functioning normally. Nikon will not be held liable for damages or lost profits that may result from product malfunction.

About the Manuals

- No part of the manuals included with this product may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form, by any means, without Nikon's prior written permission.
- Illustrations and monitor content shown in this manual may differ from the actual product.
- Nikon reserves the right to change the specifications of the hardware and software described in these manuals at any time and without prior notice.
- Nikon will not be held liable for any damages resulting from the use of this
 product.
- While every effort was made to ensure that the information in these manuals is
 accurate and complete, we would appreciate it were you to bring any errors or
 omissions to the attention of the Nikon representative in your area (address
 provided separately).

Notice Concerning Prohibition of Copying or Reproduction

Note that simply being in possession of material that was digitally copied or reproduced by means of a scanner, digital camera or other device may be punishable by law.

· Items prohibited by law from being copied or reproduced

Do not copy or reproduce paper money, coins, securities, government bonds or local government bonds, even if such copies or reproductions are stamped "Sample." The copying or reproduction of paper money, coins, or securities which are circulated in a foreign country is prohibited. Unless the prior permission of the government was obtained, the copying or reproduction of unused postage stamps or post cards issued by the government is prohibited.

The copying or reproduction of stamps issued by the government and of certified documents stipulated by law is prohibited.

Cautions on certain copies and reproductions

The government has issued cautions on copies or reproductions of securities issued by private companies (shares, bills, checks, gift certificates, etc.), commuter passes, or coupon tickets, except when a minimum of necessary copies are to be provided for business use by a company. Also, do not copy or reproduce passports issued by the government, licenses issued by public agencies and private groups, ID cards and tickets, such as passes and meal coupons.

Comply with copyright notices

The copying or reproduction of copyrighted creative works such as books, music, paintings, woodcut prints, maps, drawings, movies, and photographs is governed by national and international copyright laws. Do not use this product for the purpose of making illegal copies or to infringe copyright laws.

Disposing of Data Storage Devices

Please note that deleting images or formatting data storage devices such as memory cards or built-in camera memory does not completely erase the original image data. Deleted files can sometimes be recovered from discarded storage devices using commercially available software, potentially resulting in the malicious use of personal image data. Ensuring the privacy of such data is the user's responsibility.

Before discarding a data storage device or transferring ownership to another person, erase all data using commercial deletion software, or format the device and then completely refill it with images containing no private information (for example, images of empty sky). Care should be taken to avoid injury or damage to property when physically destroying data storage devices.

For Your Safety

To prevent damage to your Nikon product or injury to yourself or to others, read the following safety precautions in their entirety before using this equipment. Keep these safety instructions where all those who use the product will read them.

The consequences that could result from failure to observe the precautions listed in this section are indicated by the following symbol:



This icon marks warnings, information that should be read before using this Nikon product, to prevent possible injury.

WARNINGS



Turn off in the event of malfunction

Should you notice smoke or an unusual smell coming from the camera or Charging AC Adapter, unplug the Charging AC Adapter and remove the battery immediately, taking care to avoid burns. Continued operation could result in injury. After removing or disconnecting the power source, take the equipment to a Nikon-authorized service representative for inspection.



Do not disassemble

Touching the internal parts of the camera or Charging AC Adapter could result in injury. Repairs should be performed only by qualified technicians. Should the camera or Charging AC Adapter break open as the result of a fall or other accident, take the product to a Nikon-authorized service representative for inspection, after unplugging the product and/or removing the battery.



Do not use the camera or Charging AC Adapter in the presence of flammable gas

Do not use electronic equipment in the presence of flammable gas, as this could result in explosion or fire.



A Handle the camera strap with care

Never place the strap around the neck of an infant or child.



Keep out of reach of children

Particular care should be taken to prevent infants from putting the battery or other small parts into their mouths.



Do not remain in contact with the camera, Charging AC Adapter, or AC adapter for extended periods while the devices are on or in use

Parts of the devices become hot. Leaving the devices in direct contact with the skin for extended periods may result in low-temperature burns.



♠ Do not leave the product where it will be exposed to extremely high temperatures, such as in an enclosed automobile or in direct sunliaht

Failure to observe this precaution could cause damage or fire.



Observe caution when handling the battery

The battery may leak, overheat, or explode if improperly handled. Observe the following precautions when handling the battery for use in this product:

- Before replacing the battery, turn the product off. If you are using the Charging AC Adapter/AC adapter, be sure it is unplugged.
- Use only a Rechargeable Li-ion Battery EN-EL19 (included). Charge the battery by using a camera that supports battery charging. To perform this operation, use either Charging AC Adapter EH-72P/EH-72PCH (included) or the **Charge by computer** function. The Battery Charger MH-66 (available separately) is also available to charge the battery without using a camera.
- When inserting the battery, do not attempt to insert it upside down or backwards.
- Do not short or disassemble the battery or attempt to remove or break the battery insulation or casing.
- Do not expose the battery to flame or to excessive heat.
- Do not immerse in or expose to water.
- Put the battery in a plastic bag, etc. in order to insulate it before transporting. Do not transport or store with metal objects such as necklaces or hairpins.
- The battery is prone to leakage when fully discharged. To avoid damage to the product, be sure to remove the battery when no charge remains.
- Discontinue use immediately should you notice any change in the battery, such as discoloration or deformation.
- If liquid from the damaged battery comes in contact with clothing or skin, rinse immediately with plenty of water.

Observe the following precautions when handling the Charging **AC Adapter**

- Keep dry. Failure to observe this precaution could result in fire or electric shock
- Dust on or near the metal parts of the plug should be removed with a dry cloth. Continued use could result in fire.
- Do not handle the plug or go near the Charging AC Adapter during lightning storms. Failure to observe this precaution could result in electric shock.

- Do not damage, modify, forcibly tug or bend the USB cable, place it under heavy objects, or expose it to heat or flames. Should the insulation be damaged and the wires become exposed, take it to a Nikon-authorized service representative for inspection. Failure to observe these precautions could result in fire or electric shock.
- Do not handle the plug or Charging AC Adapter with wet hands. Failure to observe this precaution could result in electric shock.
- Do not use with travel converters or adapters designed to convert from one voltage to another or with DC-to-AC inverters. Failure to observe this precaution could damage the product or cause overheating or fire.

Use appropriate cables

When connecting cables to the input and output jacks, use only the cables provided or sold by Nikon for the purpose, to maintain compliance with product regulations.

Do not touch the moving parts of the lens

Failure to observe this precaution could result in injury.

Handle moving parts with care

Be careful that your fingers or other objects are not pinched by the lens cover or other moving parts.

Using the flash close to your subject's eyes could cause temporary visual impairment

The flash should be no less than 1 meter (3 ft 4 in.) from the subject. Particular care should be observed when photographing infants.

⚠ Do not operate the flash with the flash window touching a person or object

Failure to observe this precaution could result in burns or fire.

Avoid contact with liquid crystal

Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent liquid crystal from the monitor touching the skin or entering the eyes or mouth.

Note: Follow the instructions of airline and hospital personnel

Notices

Notices for Customers in the U.S.A.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS

For connection to a supply not in the U.S.A., use an attachment plug adapter of the proper configuration for the power outlet if needed.

The power supply unit is intended to be correctly orientated in a vertical or floor mount position.

Federal Communications Commission (FCC) Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful



interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

CAUTIONS

Modifications

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by Nikon Corporation may void the user's authority to operate the equipment.

Interface Cables

Use the interface cables sold or provided by Nikon for your equipment. Using other interface cables may exceed the limits of Class B Part 15 of the FCC rules.

Notice for Customers in the State of California

WARNING

Handling the cord on this product will expose you to lead, a chemical known to the State of California to cause birth defects or other reproductive harm.

Wash hands after handling.

Nikon Inc.,

1300 Walt Whitman Road, Melville, New York 11747-3064, U.S.A. Tel: 631-547-4200

Notice for Customers in Canada

CAN ICES-3(B) / NMB-3(B)

Notices for Customers in Europe

CAUTIONS

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

This symbol indicates that electrical and electronic equipment is to be collected separately.

The following apply only to users in European countries:

- This product is designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- Separate collection and recycling helps conserve natural resources and prevent negative consequences for human health and the environment that might result from incorrect disposal.
- For more information, contact the retailer or the local authorities in charge of waste management.

This symbol on the battery indicates that the battery is to be collected separately.

The following apply only to users in European countries:

- All batteries, whether marked with this symbol or not, are designated for separate collection at an appropriate collection point. Do not dispose of as household waste.
- For more information, contact the retailer or the local authorities in charge of waste management.



Table of Contents

Introduction	
Read This First	
Other Information	
How to Attach the Camera Strap	
Information and Precautions	ii
For Your Safety	
WARNINGS	V
Notices	
Parts of the Camera	
The Camera Body	1
The Monitor	3
Shooting Mode	3
Playback Mode	5
Preparing for Shooting	6
Insert the Battery and Memory Card	6
Removing the Battery or Memory Card	
Memory Cards and Internal Memory	6
Charge the Battery	7
Turn the Camera On and Set the Display Language, Date, and Time	9
Basic Shooting and Playback Operations	11
Shooting with Scene Auto Selector Mode	
Using the Zoom	13
The Shutter-release Button	13
Play Back Images	14
Delete Images	15
Changing the Shooting Mode	17
Using the Flash, Self-timer, Etc	18
Recording Movies	18
Shooting Features	19
(Scene Auto Selector) Mode	19
Scene Mode (Shooting Suited to Scenes)	
Tips and Notes	21
Shooting with Panorama Assist	24
Playback with Panorama Assist	26


special Effects Mode (Applying Effects When shooting)	
Smart Portrait Mode (Enhancing Human Faces When Shooting)	
Using Smile Timer	
(Auto) Mode	
Using the Creative Slider	
Flash Mode	
Self-timer	
Macro Mode (Taking Close-up Pictures)	
Exposure Compensation (Adjusting Brightness)	
Default Settings (Flash, Self-timer, Etc.)	
Focusing	
Using Face Detection	
Using Skin Softening	
Using Target Finding AF	
Subjects Not Suitable for Autofocus	
Focus Lock	
Functions That Cannot Be Used Simultaneously When Shooting	44
Playback Features	46
Playback Zoom	
Thumbnail Playback/Calendar Display	
List by Date Mode	
Editing Images (Still Images)	
Before Editing Images	
Quick Effects: Changing Hue or Mood	
Quick Retouch: Enhancing Contrast and Saturation	
D-Lighting: Enhancing Brightness and Contrast	
Red-eye Correction: Correcting Red-eye When Shooting with the Flash	
Glamour Retouch: Enhancing Human Faces	
Small Picture: Reducing the Size of an Image	
Crop: Creating a Cropped Copy	
Recording and Playing Back Movies	
5 , 5	
Operations During Movie Playback	58
Jsing Menus	
The Shooting Menu (for 🗖 (Auto) Mode)	61
Image Mode (Image Size and Quality)	
White Balance (Adjusting Hue)	63
Continuous Shooting	65
ISO Sensitivity	66

Caring for the Product	101
Technical Notes	
Transferring Images to a Computer	97
Installing ViewNX-i	
Using ViewNX-i (Transferring Images to a Computer)	
Printing Multiple Images	
Printing Images One at a Time	
Connecting the Camera to a Printer	
Connecting the Camera to a Printer (Direct Print)	
Connecting the Camera to a TV (Playback on a TV)	
Connecting the Camera to a TV, Printer, or Computer	90
Firmware Version	89
Reset All	
Charge by Computer	
Video Mode	
Language	87
Format Card/Format Memory	
Auto Off	85
Sound Settings	85
Digital Zoom	84
AF Assist	84
Electronic VR	83
Date Stamp	82
Monitor Settings	80
Time Zone and Date	78
The Setup Menu	78
Wind Noise Reduction	77
Autofocus Mode	77
Movie Options	76
The Movie Menu	
The Image Selection Screen	
Copy (Copy Between the Memory Card and Internal Memory)	
Rotate Image	
Protect	
Slide Show	
The Playback Menu	
Blink Proof	
The Smart Portrait Menu	
Autofocus Mode	
AF Area Mode	6

The Camera	101
The Battery	102
The Charging AC Adapter	103
Memory Cards	104
Cleaning and Storage	105
Cleaning	
Storage	105
Error Messages	106
Troubleshooting	109
File Names	
Optional Accessories	
Specifications	118
Memory Cards That Can Be Used	
Index	


Parts of the Camera

The Camera Body



1	Shutter-release button12
2	Zoom control 13 W: Wide-angle 13 T: Telephoto 13 S: Thumbnail playback 47 Q: Playback zoom 46 Ø: Help 20
3	Power switch/power-on lamp9

4	Flash32
5	Self-timer lamp34 AF-assist illuminator
6	Lens
7	Built-in microphone
8	Lens cover
9	Eyelet for camera strapii



1	Flash lamp32
2	● (*▼ movie-record) button18
3	(shooting mode) button 17, 20, 27, 28, 30
4	▶ (playback) button14
5	Multi selector59
6	(apply selection) button59
7	(delete) button15

8	MENU (menu) button	59
9	Monitor	3
10	USB/audio/video output connector	90
11	Tripod socket	120
12	Speaker	
13	Connector cover	90
14	Battery-chamber/	6


The Monitor

The information that is displayed in the monitor during shooting and playback changes depending on the camera's settings and state of use.

By default, information is displayed when the camera is turned on and when


By default, information is displayed when the camera is turned on and when you operate the camera, and turns off after a few seconds (when **Photo info** is set to **Auto info** in **Monitor settings** (280)).

Shooting Mode




1	Shooting mode17, 20, 27, 28, 30
2	Flash mode32
3	Macro mode35
4	Zoom indicator13, 35
5	Focus indicator12
6	AE/AF-L indicator25
7	Movie options76
8	Image mode61

9	Panorama assist24
10	Electronic VR icon83
11	Wind noise reduction77
12	Exposure compensation value36
13	Remaining movie recording time18
14	Number of exposures remaining (still images)10
15	Internal memory indicator



16	Aperture value13	26	Travel destination icon78
17	Focus area (target finding AF)41, 68	27	Soft
.,		28	White balance 63
18	Focus area (manual or center)43, 67	29	Foundation makeup28
	·	30	Hue31
19	Focus area (face detection, pet detection)23, 28, 39, 67	31	Skin softening28
20	Focus area (subject tracking)	32	Vividness 28, 31
20	68, 69	33	Continuous shooting mode65
21	Shutter speed13	34	Blink proof icon71
22	ISO sensitivity66	35	Hand-held/tripod21
23	Battery level indicator10	36	Self-timer indicator34
24	Date stamp82	37	Smile timer29
25	"Date not set" indicator110	38	Pet portrait auto release23

Playback Mode



	,	
2	Protect icon73	
3	Glamour retouch icon52	
4	Quick effects icon49	
5	D-Lighting icon50	
6	Quick retouch icon50	
7	Red-eye correction icon51	
8	Internal memory indicator	
9	Current image number/ total number of images	
10	Movie length or elapsed playback time	
11	Image mode61	
12	Panorama assist24	

1 List by date icon.....48

16		
13	Movie options76	
14	Small picture icon53	
15	Crop icon46, 54	
16	Volume indicator58	
17	Quick effects guide	
18	Panorama assist playback guide Movie playback guide	
19	Time of recording	
20	Date of recording	
21	Battery level indicator10	
22	Charging AC Adapter connection indicator	
23	File number and type116	

Preparing for Shooting

Insert the Battery and Memory Card

Battery latch

Memory card slot









- With the battery's positive and negative terminals oriented correctly, move the orange battery latch (3), and fully insert the battery (4).
- Slide the memory card in until it clicks into place (5).
- Be careful not to insert the battery or memory card upside-down or backward, as this could cause a malfunction.

Formatting a Memory Card

The first time you insert a memory card that has been used in another device into this camera, make sure to format it with this camera. Insert the memory card into the camera, press the MENU button, and select Format card in the setup menu (\subseteq 59).

Removing the Battery or Memory Card

Turn the camera off and make sure that the power-on lamp and monitor have turned off, and then open the battery-chamber/memory card slot cover.


- Move the battery latch to eject the battery.
- Gently push the memory card into the camera to partially eject the memory card.
- Be careful when handling the camera, battery, and memory card immediately after using the camera, as they may become hot.

Memory Cards and Internal Memory

Camera data, including images and movies, can be saved either on a memory card or in the camera's internal memory. To use the camera's internal memory, remove the memory card.

Charge the Battery

With the battery installed, connect the camera to an electrical outlet.



If a plug adapter* is included with your camera, securely connect it to the Charging AC Adapter. Once the two are connected, attempting to forcibly remove the plug adapter could damage the product.

- * The shape of the plug adapter varies according to the country or region in which the camera was purchased. This step can be omitted if the plug adapter comes permanently bonded to the Charging AC Adapter.
- The charge lamp slowly flashes green to indicate that the battery is charging.
- When charging is complete, the charge lamp turns off. It takes about 3 hours to charge a fully exhausted battery.
- The battery cannot be charged when the charge lamp quickly flashes green, possibly due to one of the reasons described below.
 - The ambient temperature is not suited to charging.
 - The USB cable or Charging AC Adapter is not properly connected.
 - The battery is damaged.
- **2** Disconnect the Charging AC Adapter from the electrical outlet and then disconnect the USB cable.

Notes About the USB Cable

Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an angle when connecting or disconnecting them.

Turning the Camera On While Charging

The camera does not turn on if you press the power switch while charging with the Charging AC Adapter. If you press and hold the (playback) button, the camera turns on in playback mode, and captured images can be played back. Shooting is not possible.


Charging Using a Computer or Battery Charger

- You can also charge the battery by connecting the camera to a computer.
- You can use the Battery Charger MH-66 (available separately) to charge the battery without using the camera.

Turn the Camera On and Set the Display Language, Date, and Time

When the camera is turned on for the first time, the language-selection screen and the date and time setting screen for the camera clock are displayed.

- 1 Press the power switch to turn on the camera.
 - · The monitor turns on.
 - To turn the camera off, press the power switch again.



2 Use the multi selector ▲▼ to select the desired language and press the ® button.





- **3** Select **Yes** and press the **®** button.
- 4 Select your home time zone and press the ® button.
 - Press ▲ to display %
 above the map and enable
 daylight saving time. Press
 ▼ to disable it.





5 Use ▲▼ to select the date format and press the [®] button.

6 Set the date and time, and press the 60 button.

- Use ◀▶ to select a field and then use ▲▼ to set the date and time.
- Select the minute field and press the ® button to confirm the setting.



When the confirmation dialog is displayed, use $\blacktriangle \blacktriangledown$ to select **Yes** and press the ® button.

- · When settings are finished, the lens extends.
- The shooting screen is displayed, and you can take pictures in scene auto selector mode.
- · Battery level indicator
 - : The battery level is high.
 - : The battery level is low.
- · Number of exposures remaining is displayed when no memory card is inserted in the camera, and images

are saved in the internal memory.

remaining

Number of exposures



Battery level indicator

Changing the Language or the Date and Time Setting

- You can change these settings using the Language and Time zone and date settings in the Υ setup menu (\square 59).
- You can enable or disable daylight saving time in the Y setup menu by selecting Time zone and date followed by Time zone. Press the multi selector ▶ and then \triangle to enable daylight saving time and move the clock forward one hour, or ∇ to disable daylight saving time and move the clock back one hour.

The Clock Battery


- The camera's clock is powered by a built-in backup battery. The backup battery charges when the main battery is inserted into the camera or when the camera is connected to an optional AC adapter, and it can run the clock for several days after about 10 hours of charging.
- If the camera's backup battery becomes exhausted, the date and time setting screen is displayed when the camera is turned on. Set the date and time again $(\square 9).$


Basic Shooting and Playback Operations

Shooting with Scene Auto Selector Mode

1 Hold the camera steady.


- Keep fingers and other objects away from the lens, flash, AF assist-illuminator, microphone, and speaker.
- When taking pictures in portrait ("tall") orientation, turn the camera so that the flash is above the lens.





2 Frame the picture.

- Move the zoom control to change the zoom lens position.
- When the camera recognizes the shooting scene, the shooting mode icon changes accordingly.




Shooting mode icon



3 Press the shutter-release button halfway.

- When the subject is in focus, the focus area or focus indicator is displayed in green.
- When you are using digital zoom, the camera focuses in the center of the frame and the focus area is not displayed.
- If the focus area or focus indicator flashes, the camera is unable to focus. Modify the composition and try pressing the shutter-release button halfway again.





Without lifting your finger, press the shutter-release button the rest of the way down.



Notes About Saving Images or Movies

The indicator showing the number of exposures remaining or the indicator showing the remaining recording time flashes while images or movies are being saved. **Do not open the battery-chamber/memory card slot cover or remove the battery or memory card** while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

The Auto Off Function

- When no operations are performed for about one minute, the monitor turns off, the camera enters standby mode, and then the power-on lamp flashes. The camera turns off after remaining in standby mode for about three minutes.
- To turn the monitor back on while the camera is in standby mode, perform an
 operation such as pressing the power switch or shutter-release button.

When Using a Tripod

We recommend using a tripod to stabilize the camera in the following situations:


- When shooting in dim lighting with the flash mode (QQ 18) set to (3) (off)
- When the zoom is at a telephoto position

Using the Zoom

When you move the zoom control, the zoom lens position changes.

- To zoom in: Move toward **T**
- To zoom out: Move toward W
 When you turn the camera on, the zoom
 moves to the maximum wide-angle
 position.
- A zoom indicator is displayed on the shooting screen when the zoom control is moved.
- Digital zoom, which allows you to further magnify the subject up to approximately 4x the maximum optical zoom ratio, can be activated by moving and bodding the zoom

activated by moving and holding the zoom control toward ${f T}$ when the camera is zoomed in to the maximum optical zoom position.



Digital Zoom

The zoom indicator changes to blue when the digital zoom is activated, and it changes to yellow when the zoom magnification is increased further.

- Zoom indicator is blue: Image quality is not noticeably reduced by using the Dynamic Fine Zoom.
- Zoom indicator is yellow: There may be cases in which image quality is noticeably reduced.
- The indicator remains blue across a wider area when the image size is smaller.
- The zoom indicator may not change to blue when using certain continuous shooting settings or other settings.

The Shutter-release Button

Press halfway



To set focus and exposure (shutter speed and aperture value), press the shutter-release button lightly until you feel a slight resistance. Focus and exposure remain locked while the shutter-release button is pressed halfway.

Press all the way



Press the shutter-release button all the way to release the shutter and take a picture.
Do not use force when pressing the shutter-release button, as this may result in camera shake and blurred images. Press the button gently.

Play Back Images

- - If you press and hold down the button while the camera is turned off, the camera turns on in playback mode.



Use the multi selector to select an image to display.

- Press and hold down ▲▼◀▶ to scroll through the images quickly.
- To return to shooting mode, press the button or shutter-release button.

Display the previous image



Display the next image



 Move the zoom control toward T (Q) in full-frame playback mode to zoom in on an image.





 In full-frame playback mode, move the zoom control toward W () switch to thumbnail playback mode and display multiple images on the screen.





Delete Images

1 Press the (delete) button to delete the image currently displayed in the monitor.



- 2 Use the multi selector ▲▼ to select the desired deletion method and press the ® button.
 - To exit without deleting, press the MENU button.



- 3 Select **Yes** and press the **®** button.
 - Deleted images cannot be recovered.



Ø Deleting the Image Captured While in Shooting Mode

When using shooting mode, press the $\widehat{\textbf{m}}$ button to delete the last image that was saved.

Operating the Erase Selected Images Screen

- 1 Use the multi selector ◀▶ to select an image to be deleted, and then use ▲ to display ∰.
 - To undo the selection, press ▼ to remove ₩
 - Move the zoom control (□1) toward T (Q) to switch to full-frame playback or W (□1) to switch to thumbnail playback.



- 2 Add file to all images that you want to delete and then press the 60 button to confirm the selection.
 - A confirmation dialog is displayed. Follow the on-screen instructions to complete operations.

Changing the Shooting Mode

The shooting modes described below are available.

• Scene auto selector

The camera automatically recognizes the shooting scene when you frame a picture, making it easier to take pictures using settings that suit the scene.

• 🙎 Scene mode

Camera settings are optimized according to the scene that you select.

SO Special effects

Effects can be applied to images during shooting.

☑ Smart portrait

Use glamour retouch to enhance human faces during shooting, and use the smile timer function to take pictures.

Auto mode

Used for general shooting. Settings can be changed to suit the shooting conditions and the type of shot that you want to capture.

When the shooting screen is displayed, press the (shooting mode) button.



- 2 Use the multi selector ▲▼ to select a shooting mode and press the ® button.
 - When scene mode or special effects mode is selected, press ▶ to select a scene mode or effect before pressing the ⋈ button.





Using the Flash, Self-timer, Etc.

When the shooting screen is displayed, you can press the multi selector \blacktriangle (\$) \blacktriangleleft (\$) \lor (\$) \lor (\$) to set the functions described below.



\$ Flash mode

You can select a flash mode to match the shooting conditions.

• (S) Self-timer

The camera releases the shutter 10 seconds or 2 seconds after you press the shutter-release button.

Macro mode

Use macro mode when you take close-up pictures.

• **Exposure compensation**


You can adjust overall image brightness.

The functions that can be set vary depending on the shooting mode.

Recording Movies

Display the shooting screen and press the (*\overline{Tmovie}\), movie-record) button to start recording a movie. Press the (*\overline{Tmovie}\), button again to end recording.

• To play back a movie, select a movie in fullframe playback mode and press the **®** button.



Shooting Features

(Scene Auto Selector) Mode

The camera automatically recognizes the shooting scene when you frame a picture, making it easier to take pictures using settings that suit the scene.

Enter shooting mode $\rightarrow \square$ (shooting mode) button $\rightarrow \square$ (scene auto selector) mode $\rightarrow \square$ button

When the camera automatically recognizes the shooting scene, the shooting mode icon displayed on the shooting screen changes accordingly.

Ž *	Portrait (for taking close-up portraits of one or two people)	
ŹĬ	Portrait (for taking portraits of large numbers of people, or images in which the background takes up a large portion of the frame)	
	Landscape	
2"	Night portrait (for taking close-up portraits of one or two people)	
<u>s</u>	Night portrait (for taking portraits of large numbers of people, or images in which the background takes up a large portion of the frame)	
E"	Night landscape	
W.	Close-up	
79 °	Backlighting (for taking pictures of subjects other than people)	
79 H	Backlighting (for taking portrait pictures)	
SCENE *	Other scenes	

Notes About 🍱 (Scene Auto Selector) Mode

- Depending on shooting conditions, the camera may not select the desired scene mode. In this case, select another shooting mode (\$\sum_{17}\$).
- When the digital zoom is in effect, the shooting mode icon changes to **3**.

Functions Available in III (Scene Auto Selector) Mode

- Flash mode (QQ 32)
- Self-timer (□□34)
- Exposure compensation (QQ36)
- Image mode (□ 61)

Scene Mode (Shooting Suited to Scenes)

When a scene is selected, camera settings are automatically optimized for the selected scene.

Enter shooting mode $\Rightarrow \square$ (shooting mode) button $\Rightarrow \cancel{2}$ (second icon from the top*) $\Rightarrow \triangleright \Rightarrow \triangle \nabla \Rightarrow$ select a scene $\Rightarrow \bigcirc$ 8 button

* The icon of the last scene selected is displayed.

₹ Portrait (default setting)	à Dusk/dawn ^{1, 2, 3}
■ Landscape ^{1, 2}	■ Night landscape ^{1, 2, 3} (□21)
₹ Sports ² (◯◯21)	ℬ Close-up (◯◯ 21)
☑ Night portrait ³	₹¶ Food (2 22)
※ Party/indoor ² (◯◯21)	Fireworks show ^{1, 3} (QQ22)
₽ Beach ²	Backlighting ² (□□22)
₿ Snow ²	Panorama assist (QQ24)
Sunset ^{2, 3}	₩ Pet portrait (📖 23)

The camera focuses at infinity.

Displaying a Description of Each Scene Mode (Help Display)

Select a scene and move the zoom control $(\square 1)$ toward T(?) to view a description of that scene. To return to the previous screen, move the zoom control toward T(?) again.



² The camera focuses on the area in the center of the frame.

³ Use of a tripod is recommended, because the shutter speed is slow.

Tips and Notes

Sports

- While the shutter-release button is held all the way down, the camera shoots up to about 6 images continuously at a rate of about 1.1 fps (when image mode is set to 2021).
- The frame rate for continuous shooting may vary depending on the current image mode setting, the memory card used, or shooting conditions.
- Focus, exposure, and hue are fixed at the values determined with the first image in each series.

XX Party/indoor

 To avoid the effects of camera shake, hold the camera steady. In dark surroundings, the use of a tripod is recommended.

■ Night landscape

- On the screen displayed when **Night landscape** is selected, select **¬ Handheld** or **¬ Tripod**.
 - the Hand-held (default setting): Select this option to produce shots with reduced blurring and noise even when the camera is hand-held.
 - Tripod: Select this option when using a tripod or other means to stabilize the camera when shooting.

Close-up

- Macro mode (\$\sum35\$) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can move the focus area. Press the ௵ button, use the multi selector ▲▼◀► to move the focus area, and press the ௵ button to apply the setting.

¶¶ Food

- Macro mode (\$\sum35\$) is enabled and the camera automatically zooms to the closest position at which it can focus.
- You can adjust hue by using the multi selector
 ▼. The hue setting is saved in the camera's memory even after the camera is turned off.



Fireworks show

• The shutter speed is fixed at four seconds.

Backlighting

• The flash always fires.

🎀 Pet portrait


- When you point the camera at a dog or cat, the camera detects the pet's face and focuses on it. By default, the camera detects a dog or cat face and automatically releases the shutter (pet portrait auto release).
- - S Single: The camera captures one image when a dog or cat face is detected.
 - Continuous: The camera captures three images continuously when a dog or cat face is detected.

Pet Portrait Auto Release

- Press the multi selector \blacktriangleleft (\circlearrowleft) to change the **Pet portrait auto release** setting.
 - 🖼: The camera detects a dog or cat face and automatically releases the shutter.
 - OFF: The camera does not release the shutter automatically, even if a dog or cat face is detected. Press the shutter-release button. The camera also detects human faces when OFF is selected.
- Pet portrait auto release is set to OFF after five bursts have been taken.
- Shooting is also possible by pressing the shutter-release button, regardless of the
 Pet portrait auto release setting. When Continuous is selected, you can
 take pictures continuously while holding down the shutter-release button all the
 way.

Focus Area

 When the camera detects a face, the face is displayed inside a yellow border. When the camera acquires focus on a face displayed inside a double border (focus area), the double border changes to green. If no faces are detected, the camera focuses on the subject in the center of the frame.



 Under some shooting conditions, the pet face may not be detected and other subjects may be displayed inside a border.

Shooting with Panorama Assist

Enter shooting mode $\rightarrow \square$ (shooting mode) button $\rightarrow \mathcal{Z}$ (second icon from the top*) $\rightarrow \square \rightarrow \square$ (Panorama assist) $\rightarrow \square$ button

- * The icon of the last scene selected is displayed.
- 1 Use the multi selector ▼▶ to select the direction in which images are joined, and press the ® button.
 - If necessary, apply flash mode (□32), selftimer (□34), macro mode (□35) and exposure compensation (□36) settings in this step.
 - Press the **(R)** button to reselect the direction.



2 Frame the first portion of the panorama scene and take the first picture.

- The camera focuses on the subject in the center of the frame.
- About one third of the image is displayed as translucent.





3 Take the next picture.

 Match the outline of the next image so that one third of the frame overlaps the previous image, and press the shutterrelease button.





- 4 Press the ® button when shooting is complete.
 - The camera returns to step 1.



Notes About Panorama Assist

- Up to three images can be taken and combined in a panorama series. Shooting automatically ends after the third image is taken.
- A panorama image may not be saved if the translucent portion of an image is not properly aligned with the subject when taking the next image.
- The range of the image seen in the saved image is narrower than that seen in the monitor at the time of shooting.
- If shooting ends after only the first image is taken, the camera cannot scroll the playback of the image (\$\sum26\$).
- Shooting for the panorama series is terminated if the auto off function (\$\subset\$85) initiates standby mode during shooting. Setting the time allowed to elapse before the auto off function is enabled to a longer setting is recommended.
- Images cannot be deleted while shooting in panorama assist mode. When shooting a new image, return to step 1 and start over again.

In panorama assist scene mode, exposure, white balance, and focus for all images in a panorama are fixed at the values for the first image in each series. When the first image is taken, AE/AF-L is displayed to indicate that exposure, white balance, and focus are locked.



Playback with Panorama Assist

Switch to playback mode (\(\infty\)14), display an image captured using panorama assist in full-frame playback mode, and then press the button to scroll the image in the direction that was used when shooting.

Playback controls are displayed in the monitor during playback.

Use the multi selector ◀► to select a control, and then press the ❸ button to perform the operations described below.





Function	lcon	Description	
Rewind	*	Hold down the 🕦 button to scroll backward quickly.	
Advance	*	Hold down the 🚯 button to scroll forward quickly.	
		Pause playback. The operations listed below can be performed while paused.	
Pause		√ III	Hold down the 🕦 button to rewind.
			Hold down the 🕦 button to scroll.
			Resume automatic scrolling.
End		Switch to full-frame playback mode.	

Notes About Panorama Assist Images

- The images cannot be edited on this camera.
- This camera may not be able to scroll the playback of, or zoom in on, panorama assist images captured with another make or model of digital camera.

Notes About Printing Panorama Images

The entire image may not be able to be printed depending on the printer's settings. Additionally, printing may not be possible depending on the printer.

Special Effects Mode (Applying Effects When Shooting)

Effects can be applied to images during shooting.

Enter shooting mode $\Rightarrow \square$ (shooting mode) button \Rightarrow \$0 (third icon from the top*) $\Rightarrow \triangleright \Rightarrow \triangle \nabla \Rightarrow$ select an effect $\Rightarrow \bigcirc$ button

* The icon of the last effect selected is displayed.

Type	Description	
\$0 Soft (default setting)	Softens the image by adding a slight blur to the entire image.	
SE Nostalgic sepia	Adds a sepia tone and reduces the contrast to simulate the qualities of an old photograph.	
High-contrast monochrome	Changes the image to black and white and gives it sharp contrast.	
Selective color Creates a black and white image in which only the specified color remains.		
POP Pop	Increases the color saturation of the entire image to create a bright look.	
श्ली Toy camera effect 1	Gives the entire image a yellowish hue and darkens the image periphery.	
₹2 Toy camera effect 2	Decreases the color saturation of the entire image and darkens the image periphery.	
ॐ Cross process	Gives the image a mysterious appearance based on a specific color.	

- The camera focuses on the area in the center of the frame.
- When Selective color or Cross process is selected, use the multi selector ▲▼ to select the desired color, and press the ❸ button to apply the color. To change the color selection, press the ❸ button again.



Smart Portrait Mode (Enhancing Human Faces When Shooting)

You can take a picture with the glamour retouch function to enhance human faces.

Enter shooting mode $\Rightarrow \Box$ (shooting mode) button $\Rightarrow \boxdot$ Smart portrait mode $\Rightarrow \otimes$ button

1 Press the multi selector ▶.



- **2** Apply an effect.
 - Use ◀▶ to select the desired effect.
 - Use ▲▼ to select the amount of effect.
 - You can simultaneously apply multiple effects.
 - Skin softening, Foundation makeup, Soft, ⊗ Vividness, ⊠ Brightness (Exp. +/-)
 - Select X Exit to hide the slider.
 - After configuring the desired effects, press the button to apply them.



3 Frame the picture and press the shutter-release button.

Notes About Smart Portrait Mode

The amount of effect may differ between the image on the shooting screen and the saved image.

Functions Available in Smart Portrait Mode

- Glamour retouch (QQ28)
- Smile timer (QQ29)
- Flash mode (◯◯32)
- Self-timer (□□34)
- Smart portrait menu (QQ71)

Using Smile Timer

Enter shooting mode \Rightarrow \square (shooting mode) button \Rightarrow \boxdot Smart portrait mode \Rightarrow \bowtie button

When you press the multi selector ◀ to select ☑ Smile timer and press the ⑧ button, the camera automatically releases the shutter whenever a smiling face is detected.

- Set the glamour retouch function before selecting smile timer (□28).
- When you press the shutter-release button to take a picture, smile timer is terminated.





Notes About Smile Timer

Under some shooting conditions, the camera may be unable to detect faces or smiles ($\square 39$). The shutter-release button can also be used for shooting.

When the Self-timer Lamp Flashes

When using smile timer, the self-timer lamp flashes when the camera detects a face and flashes quickly immediately after the shutter is released.

(Auto) Mode

Used for general shooting. Settings can be adjusted to suit the shooting conditions and the type of shot you want to capture.

Enter shooting mode \Rightarrow \square (shooting mode) button \Rightarrow \square (auto) mode \Rightarrow \bowtie button

 You can change how the camera selects the area of the frame to focus on by changing the **AF area mode** setting (\sum_67).
 The default setting is **Target finding AF** (\sum_41).

Functions Available in (Auto) Mode

- Creative slider (□□31)
- Flash mode (□□32)
- Self-timer (QQ34)
- Macro mode (QQ35)
- Shooting menu (QQ61)

Using the Creative Slider

You can adjust the brightness (exposure compensation), vividness, and hue when shooting.

Enter shooting mode \Rightarrow \square (shooting mode) button \Rightarrow \square (auto) mode \Rightarrow \square button

1 Press the multi selector **▶**.



- **2** Use **♦** to select an item.
 - B Hue: Adjust the hue (reddish/bluish) of the entire image.
 - **& Vividness**: Adjust the vividness of the entire image.
 - Brightness (Exp. +/-): Adjust the brightness of the entire image.



- **3** Use $\blacktriangle \blacktriangledown$ to adjust the level.
 - You can preview the results on the monitor.
 - To set another item, return to step 2.
 - Select X Exit to hide the slider.
 - To cancel all settings, select Reset and press the button. Return to step 2 and adjust the settings again.



- 4 Press the ® button when setting is complete.
 - The settings are applied and the camera returns to the shooting screen.
- Creative Slider Settings
- The settings for brightness (exposure compensation), vividness and hue are saved in the camera's memory even after the camera is turned off.

Flash Mode

You can select a flash mode to match the shooting conditions.

1 Press the multi selector \triangle (\$).



- 2 Select the desired flash mode (33) and press the button.



The Flash Lamp

- The status of the flash can be confirmed by pressing the shutter-release button halfway.
 - On: The flash fires when you press the shutter-release button all the way down.
 - Flashing: The flash is charging. The camera cannot shoot images.
 - Off: The flash does not fire when a picture is taken.
- If the battery level is low, the monitor turns off while the flash is charging.



Available Flash Modes

₺∭∏ Auto

The flash fires when necessary, such as in dim lighting.

 The flash mode icon on the shooting screen is displayed only immediately after the setting is made.

4 Auto with red-eye reduction

Reduce "red-eye" in portraits caused by the flash.

Off

The flash does not fire.

 We recommend using a tripod to stabilize the camera when shooting in dark surroundings.

Fill flash

The flash fires whenever a picture is taken. Use to "fill-in" (illuminate) shadows and backlit subjects.

\$Slow sync

Suited to evening and night portraits that include background scenery. The flash fires when necessary to illuminate the main subject; slow shutter speeds are used to capture background at night or under dim lighting.

The Flash Mode Setting

- The setting may not be available with some shooting modes (\square 37).
- The setting applied in (auto) mode is saved in the camera's memory even after the camera is turned off

Red-eye Reduction

If the camera detects red eye while saving an image, the affected area is processed to reduce red-eye before the image is saved.

Note the following when shooting:

- More time than usual is required to save images.
- Red-eye reduction may not produce the desired results in some situations.
- In rare cases, red-eye reduction may be applied unnecessarily to other areas of the image. In these cases, select another flash mode and take the picture again.

Self-timer

The camera is equipped with a self-timer that releases the shutter 10 seconds or 2 seconds after you press the shutter-release button.

1 Press the multi selector **◄** (**७**).



⊗10s

<>> 25

- 2 Select **310s** or **2s**, and press the **b** button.
 - **🖒 10s** (10 seconds): Use on important occasions, such as weddings.
 - O2s (2 seconds): Use to prevent camera shake.
 - If the setting is not applied by pressing the w button within a few seconds, the selection will be canceled.

 - When the shooting mode is smart portrait mode, you can also use **Smile timer** (\(\subseteq 29\)) in addition to the self-timer.
- Frame the picture and press the shutter-release button halfway.
 - · Focus and exposure are set.
- Press the shutter-release button the rest of the way down.
 - Countdown starts. The self-timer lamp flashes and then glows steadily about one second before the shutter is released.
 - When the shutter is released, the self-timer is set to OFF.
 - To stop the countdown, press the shutter-release button again.







Macro Mode (Taking Close-up Pictures)

Use macro mode when taking close-up pictures.

1 Press the multi selector **▼** (**♣**).



- 2 Select **ON** and press the **®** button.
 - If the setting is not applied by pressing the button within a few seconds, the selection will be canceled.



3 Move the zoom control to set the zoom ratio to a position where 3 and the zoom indicator are displayed in green.



When the zoom ratio is set to a position where the zoom indicator is
displayed in green, the camera can focus on subjects as close as
approximately 30 cm (1 ft) from the lens.
 When the zoom is at the position where △ is displayed, the camera can
focus on subjects as close as approximately 10 cm (4 in.) from the lens.

Notes About Using the Flash

The flash may be unable to light the entire subject at distances of less than 50 cm (1 ft 8 in.).

The Macro Mode Setting

- The setting may not be available with some shooting modes (2237).
- If the setting is applied in (auto) mode, it will remain saved in the camera's memory even after the camera is turned off.

Exposure Compensation (Adjusting Brightness)

You can adjust overall image brightness.

1 Press the multi selector ▶ (☑).



- 2 Select a compensation value and press the (R) button.
 - To brighten the image, set a positive (+) value.
 - To darken the image, set a negative (–) value.
 - The compensation value is applied, even without pressing the **®** button.
 - When the shooting mode is smart portrait mode, the glamour retouch screen is displayed instead of the exposure compensation screen (□28).

Exposure Compensation Value

- The setting may not be available with some shooting modes (QQ37).
- If the setting is applied in (auto) mode, it will remain saved in the camera's memory even after the camera is turned off.



Default Settings (Flash, Self-timer, Etc.)

Default settings for each shooting mode are listed below.

	Flash (CC) 32)	Self-timer (QQ34)	Macro (QQ35)	Exposure compensation (36)
(scene auto selector)	\$ AUTO¹	Off	Off ²	0.0
SCENE (scene)				
🙎 (portrait)	\$⊚	Off	Off ³	0.0
(landscape)	③ ³	Off	Off ³	0.0
❖ (sports)	③ ³	Off ³	Off ³	0.0
(night portrait)	\$⊚ ⁴	Off	Off ³	0.0
💥 (party/indoor)	\$⊚ ⁵	Off	Off ³	0.0
(beach)	\$ AUTO	Off	Off ³	0.0
🗿 (snow)	\$ AUTO	Off	Off ³	0.0
👛 (sunset)	③ ³	Off	Off ³	0.0
當 (dusk/dawn)	③ ³	Off	Off ³	0.0
d (night landscape)	3 3	Off	Off ³	0.0
🗱 (close-up)	3	Off	On ³	0.0
¶¶ (food)	③ ³	Off	On ³	0.0
(fireworks show)	③ ³	Off ³	Off ³	0.03
(backlighting)	\$ 3	Off	Off ³	0.0
(panorama assist)	3	Off	Off	0.0
😽 (pet portrait)	③ ³	ਛ ੱ ⁶	Off	0.0

	Flash (CC)32)	Self-timer (CC)34)	Macro (◯◯35)	Exposure compensation (36)
🕻 (special effects)	3	Off	Off	0.0
(smart portrait)	\$ AUTO	Off ⁷	Off ³	0.08
(auto)	\$ AUTO	Off	Off	0.09

¹ The camera automatically selects the flash mode appropriate for the scene it has selected. **(3)** (off) can be selected manually.

- ² Cannot be changed. The camera enters macro mode when ***** is selected.
- ³ Cannot be changed.
- ⁴ Cannot be changed. The flash mode setting is fixed at fill flash with red-eye reduction
- Slow sync with red-eye reduction flash mode may be used.
- 6 Self-timer cannot be used. Pet portrait auto release can be turned on or off (□23).
 7 ➡ Smile timer (□29) can be used in addition to self-timer.
- ⁸ The glamour retouch screen is displayed (Q28).
- ⁹ Creative slider is displayed (\square 31).

720 to 20

Focusing

The focus area varies depending on the shooting mode.

Using Face Detection

In the following shooting modes, the camera uses face detection to automatically focus on human faces.

- **23**/**23 Portrait**, **23**/**33 Night portrait**, or **23 Backlighting** in **33** (scene auto selector) mode (◯19)
- Portrait or Night portrait scene mode (□20)
- Smart portrait mode (□28)
- When AF area mode (□67) in (auto) mode (□30) is set to Face priority.

If the camera detects more than one face, a double border is displayed around the face that the camera focuses on, and single borders are displayed around the other faces.

2"

If the shutter button is pressed halfway when no faces are detected:

- In see (scene auto selector) mode, the focus area changes depending on the scene.
- In Portrait and Night portrait scene modes or in smart portrait mode, the camera focuses in the center of the frame.
- In (auto) mode, the camera selects the focus area containing the subject closest to the camera.

Notes About Face Detection

- The camera's ability to detect faces depends on a variety of factors, including the direction in which the faces are looking.
- The camera cannot detect faces in the following situations:
 - When faces are partially hidden by sunglasses or otherwise obstructed
 - When faces take up too much or too little of the frame

Using Skin Softening

When the shutter is released while using one of the shooting modes listed below, the camera detects human faces and processes the image to soften facial skin tones (up to three faces).

- Smart portrait mode (□ 28)
 - The amount of the **Skin softening** effect can be adjusted.
- Portrait, Night portrait, or Backlighting in (scene auto selector) mode (□ 19)
- Portrait or Night portrait scene mode (QQ20)

Editing functions such as **Skin softening** can be applied to saved images by using **Glamour retouch** (\square 52) even after shooting.


Notes About Skin Softening

- It may take more time than usual to save images after shooting.
- Under some shooting conditions, the desired skin softening results may not be achieved, and skin softening may be applied to areas of the image where there are no faces.

Using Target Finding AF


When **AF area mode** (\square 67) in \square (auto) mode is set to **Target finding AF**, the camera focuses in the manner described below when you press the shutter-release button halfway.

 The camera detects the main subject and focuses on it. When the subject is in focus, the focus area is displayed in green. If a human face is detected, the camera automatically sets focus priority on it.



Focus areas

 If no main subject is detected, the camera automatically selects one or more of the nine focus areas containing the subject closest to the camera. When the subject is in focus, the focus areas that are in focus are displayed in green.



Focus areas

Notes About Target Finding AF

- Depending on shooting conditions, the subject that the camera determines to be the main subject may vary.
- The main subject may not be detected when using certain White balance settings.
- The camera may not detect the main subject appropriately in the following situations:
 - When the subject is very dark or bright
 - When the main subject lacks clearly defined colors
 - When the shot is framed so that the main subject is at the edge of the monitor
 - When the main subject is composed of a repeating pattern

Subjects Not Suitable for Autofocus

The camera may not focus as expected in the following situations. In rare cases, the subject may not be in focus despite the fact that the focus area or the focus indicator is displayed in green:

- · Subject is very dark
- Objects of sharply differing brightness are included in the scene (e.g. the sun behind the subject makes that subject appear very dark)
- No contrast between the subject and surroundings (e.g. a portrait subject wearing a white shirt is standing in front of a white wall)
- Several objects are at different distances from the camera (e.g. the subject is inside a cage)
- Subjects with repeating patterns (window blinds, buildings with multiple rows of similarly shaped windows, etc.)
- · Subject is moving rapidly

In the situations noted above, try pressing the shutter-release button halfway to refocus several times, or focus on another subject positioned at the same distance from the camera as the actual desired subject, and use focus lock $(\Box \Box 43).$

Focus Lock

Focus lock shooting is recommended when the camera does not activate the focus area that contains the desired subject.

- 1 Set **AF area mode** to **Center** in \Box (auto) mode (\Box 67).
- **2** Position the subject in the center of the frame and press the shutter-release button halfway.





- . The camera focuses on the subject and the focus area is displayed in green.
- · Exposure is also locked.
- **3** Without lifting your finger, recompose the picture.
 - Make sure to maintain the same distance between the camera and the subject.



4 Press the shutter-release button the rest of the way down to take the picture.



Functions That Cannot Be Used Simultaneously When Shooting

Some functions cannot be used with other menu options.

Restricted function	Option	Description	
Flash mode	Continuous (CC)	When Continuous is selected, the flash cannot be used.	
riasii iiiode	Blink proof (QQ71)	When Blink proof is set to On , the flash cannot be used.	
Self-timer	AF area mode (҈☐67)	When Subject tracking is selected, the self-timer cannot be used.	
Macro mode	AF area mode (҈☐67)	When Subject tracking is selected, macro mode cannot be used.	
lmage mode	ISO sensitivity (🎞 66)	When 3200 is selected, the image mode setting of only 4. 2272×1704, 2. 1600×1200, or 6. 400×480 can be selected. If any image mode setting other than above is selected, the image mode setting is automatically changed to 6. 2272×1704 when ISO sensitivity is set to 3200.	
White balance	Hue (Using the creative slider) (ДД31)	When Hue is adjusted using the creative slider, White balance setting is not available in the shooting menu.	
AF area mode Digital zoom (\$\sumsymbol{\pi}\$84)		When digital zoom is in effect, the camera focuses in the center of the frame regardless of the AF area mode setting.	
	ISO sensitivity (∭66)	When a setting other than Auto is selected, electronic vibration reduction is disabled.	
Electronic VR	Continuous (🎞 65)	When Continuous is selected, electronic vibration reduction is disabled.	
	Blink proof (QQ71)	When On is selected, electronic vibration reduction is disabled.	

Restricted function	Option	Description	
Digital zoom	AF area mode (□167)	When Subject tracking is selected, digital zoom cannot be used.	
Shutter sound	Continuous (CC)	When Continuous is selected, the shutter sound is disabled.	


Notes About Digital Zoom

- Depending on the shooting mode or the current settings, digital zoom may not be available (\$\sum 84\$).
- When digital zoom is in effect, the camera focuses in the center of the frame.

Playback Features

Playback Zoom

Moving the zoom control toward T (Q playback zoom) in full-frame playback mode $(\square 14)$ zooms in on the image.



- You can change the magnification rate by moving the zoom control toward \mathbf{W} ($\mathbf{\Xi}$) or \mathbf{T} (\mathbf{Q}).
- To view a different area of the image, press the multi selector ▲▼◀▶.
- When a zoomed image is displayed, press the button to return to fullframe playback mode.

Cropping Images

When a zoomed image is displayed, you can press the **MENU** button to crop the image to include only the visible portion and save it as a separate file $(\square 54)$.

Thumbnail Playback/Calendar Display

Moving the zoom control toward \mathbf{W} (\blacksquare thumbnail playback) in full-frame playback mode (\square 14) displays images as thumbnails.



- You can change the number of thumbnails displayed by moving the zoom control toward W (➡) or T (Q).
- While using thumbnail playback mode, press the multi selector ▲▼◀▶ to select an image and then press the → button to display that image in fullframe playback mode.
- While using calendar display mode, press ▲▼◀▶ to select a date and then press the
 ⊕ button to display the images captured on that day.

Notes About Calendar Display

Images captured when the camera's date is not set are treated as images captured on January 1, 2016.

List by Date Mode

Press the ightharpoonup button (playback mode) ightharpoonup button ightharpoonup ightharpoonup button

List by date

31

18/11/2016

Use the multi selector $\blacktriangle \nabla$ to select a date and then press the 8 button to play back the images captured on the selected date.

- Functions in the playback menu (\$\sum 72\$) can be used for the images in the selected shooting date (except **Copy**).
- The following operations are available while the shooting date selection screen is displayed.
 - MENU button: The functions listed below are available.
 - Slide show
 - Protect*
 - * The same settings can be applied to all images captured on the selected date.
 - 🗑 button: Deletes all images captured on the selected date.

Notes About List by Date Mode

- Up to the most recent 29 dates can be selected. If images exist for more than 29 dates, all images saved earlier than the most recent 29 dates will be combined under Others.
- The 9,000 most recent images can be displayed.
- Images captured when the camera's date is not set are treated as images captured on January 1, 2016.

Editing Images (Still Images)

Before Editing Images

You can easily edit images on this camera. Edited copies are saved as separate files.

Edited copies are saved with the same shooting date and time as the original.

Restrictions on Image Editing

- An image can be edited up to 10 times.
- You may not be able to edit images of a certain size or with certain editing functions.

Quick Effects: Changing Hue or Mood

Quick effects type	Description	
Painting	Mainly adjusts hue and creates a different look for the image.	
Photo illustration/Soft portrait/Fisheye/Cross screen/Miniature effect	Processes images with a variety of effects.	

Display the image to which you want to apply an effect in full-frame playback mode and press the button.



- 2 Use the multi selector ▲▼◀▶ to select the desired effect and press the ® button.
 - Move the zoom control (□1) toward T (Q) to switch to full-frame playback or W (□1) to switch to thumbnail playback.
 - To exit without saving the edited image, press the MENU button.



- **3** Select **Yes** and press the **®** button.
 - · An edited copy is created.

Quick Retouch: Enhancing Contrast and Saturation

Press the ▶ button (playback mode) → select an image → MENU button → Quick retouch → ® button

Use the multi selector $\blacktriangle \nabla$ to select the amount of effect applied and press the $\textcircled{\textbf{M}}$ button.

- The edited version is displayed on the right.
- To exit without saving the copy, press \blacktriangleleft .



D-Lighting: Enhancing Brightness and Contrast

Press the ▶ button (playback mode) → select an image → MENU button → D-Lighting →

® button

Use the multi selector $\blacktriangle \nabla$ to select **OK** and press the \circledR button.

- The edited version is displayed on the right.
- To exit without saving the copy, select **Cancel** and press the **®** button.



Red-eye Correction: Correcting Red-eye When Shooting with the Flash

Press the ▶ button (playback mode) → select an image → MENU button → Red-eye correction → ® button

Preview the result and press the ® button.

 To exit without saving the copy, press the multi selector ◀.




Notes About Red-eye Correction

- Red-eye correction can only be applied to images when red-eye is detected.
- Red-eye correction can be applied to pets (dogs or cats) even if their eyes are not red.
- Red-eye correction may not produce the desired results in some images.
- In rare cases, red-eye correction may be applied unnecessarily to other areas of the image.

Glamour Retouch: Enhancing Human Faces

Press the ▶ button (playback mode) → select an image → MENU button → Glamour retouch → 🔞 button

- 1 Use the multi selector ▲▼◀► to select the face that you want to retouch and press the ® button.
 - When only one face is detected, proceed to step 2.



0FF

Small face

- 2 Use ◀▶ to select the effect, use ▲▼ to select the effect level, and press the ๋ button.
 - You can simultaneously apply multiple effects.

Adjust or check the settings for all effects before pressing the ❸ button. U (Small face), ☑ (Skin softening), ☑

(Foundation makeup), ☐ (Glare reduction), ⓒ (Hide eye bags), ⓒ (Big eyes), ⓒ (Whiten eyes), ⓒ (Eye shadow), ⓒ (Mascara), ♣ (Whiten teeth), ⓒ (Lipstick), ⓒ (Redden cheeks)

- Press the **MENU** button to return to the screen for selecting a person.
- Preview the result and press the button.
 - To change the settings, press

 to return to step 2.
 - To exit without saving the edited image, press the **MENU** button.



4 Select **Yes** and press the **(N)** button.

• An edited copy is created.



Notes About Glamour Retouch

- Only one face at a time can be edited. To retouch another face in the same image, select the edited copy of the image and make additional changes.
- Depending on the direction in which faces are looking, or the brightness of faces, the camera may be unable to accurately detect faces, or the glamour retouch function may not perform as expected.
- If no faces are detected, a warning is displayed and the screen returns to the playback menu.
- The glamour retouch function is available only for images captured at an ISO sensitivity of 1600 or lower, and the image size of 640 x 480 or larger.

Small Picture: Reducing the Size of an Image

Press the ▶ button (playback mode) → select an image → MENU button → Small picture →

® button

- - Images captured at an image mode setting of 5120x2880 are saved at a size of 640 x 360, and images captured at an image mode setting of 13864x3864 are saved at 480 x 480. Press the button to proceed to step 2.



2 Select **Yes** and press the ® button.

 An edited copy is created (compression ratio of approximately 1:16).



Crop: Creating a Cropped Copy

- **1** Move the zoom control to enlarge the image (\square 46).
- Adjust the image so that only the portion that you want to keep is displayed, and then press the MENU (menu) button.



- Move the zoom control toward T (Q) or W (➡) to adjust the magnification rate. Set a magnification rate at which ➡: ★ is displayed.
- Use the multi selector ▲▼◀▶ to scroll to the portion of the image that you want to display.
- 3 Select **Yes** and press the **®** button.
 - An edited copy is created.



Image Size

Copies created with the small picture function or cropped to a size of 320×240 or smaller are displayed at a small size on the playback screen and cannot be cropped.

Cropping the Image in Its Current "Tall" Orientation

Use the **Rotate image** option (\square 73) to rotate the image so that it is displayed in landscape orientation. After cropping the image, rotate the cropped image back to "tall" orientation.

Recording and Playing Back Movies

- 1 Display the shooting screen.
 - Check the remaining amount of movie recording time.
 - When Electronic VR (\$\sum_8\$) in the setup menu is set to On, electronic vibration reduction is enabled and camera shake is reduced.



Remaining movie recording time

- 2 Press the (*▼ movie-record) button to start movie recording.
 - The camera focuses in the center of the frame





- **3** Press the (*★ movie-record) button again to end recording.
- 4 Select a movie in full-frame playback mode and press the ® button to play it back.
 - An image with a movie options icon is a movie.



Movie options

Area Captured in Movies

- The area that is captured in a movie varies depending on the Movie options settings in the movie menu.
- If Photo info in Monitor settings (\$\sum 80\$) in the setup menu is set to
 Movie frame+auto info, you can confirm the area that will be captured in
 a movie before you start recording.

Maximum Movie Recording Time

Individual movie files cannot exceed 2 GB in size or 29 minutes in length, even when there is sufficient free space on the memory card for longer recording.

- The remaining recording time for a single movie is displayed on the shooting screen.
- The actual remaining recording time may vary depending on the movie content, subject movement, or type of memory card.
- Memory cards with an SD Speed Class rating of 6 or faster are recommended when recording movies (2122). Movie recording may stop unexpectedly when memory cards with a lower Speed Class rating are used.

Notes About Camera Temperature

- The camera may become hot when shooting movies for an extended period of time or when the camera is used in a hot area.
- If the inside of the camera becomes extremely hot when recording movies, the camera will automatically stop recording.

The amount of time remaining until the camera stops recording ($\triangle 10s$) is displayed.

After the camera stops recording, it turns itself off. Leave the camera off until the inside of the camera has cooled.

Notes About Movie Recording

Notes About Saving Images or Movies

The indicator showing the number of exposures remaining or the indicator showing the remaining recording time flashes while images or movies are being saved. **Do** not open the battery-chamber/memory card slot cover or remove the battery or memory card while an indicator is flashing. Doing this could result in loss of data, or in damage to the camera or the memory card.

Notes About Recorded Movies

- When recording movies with 220 m 720/30p or 220 m 720/25p selected for Movie options, the angle of view (the area captured in the recorded movie) is smaller than when taking still images.
- Optical zoom cannot be adjusted once movie recording begins.
- There may be some degradation in image quality when digital zoom is used.
 Subjects can be magnified up to 4x the digital zoom ratio that was applied before movie recording began.
- The sounds of zoom control operation, autofocus lens drive movement, and aperture operation when brightness changes may be recorded.
- Smear (\(\suma102\)) visible in the monitor with movie recording will be recorded with movies. Avoiding bright objects such as the sun, reflections of the sun, and electric lights when recording movies is recommended.
- Depending on the distance to the subject or the amount of zoom applied, colored stripes may appear on subjects with repeating patterns (fabrics, lattice windows, etc.) during movie recording and playback. This occurs when the pattern in the subject and the layout of the image sensor interfere with each other; it is not a malfunction.

Notes About Electronic VR During Movie Recording

When **Electronic VR** (\square 83) is set to **On** in the setup menu, the angle of view (the area captured in the recorded movie) is smaller than when taking still images.

Notes About Autofocus for Movie Recording

Autofocus may not perform as expected (QQ42). Should this occur, try the following:

- Set Autofocus mode in the movie menu to Single AF (default setting) before starting movie recording.
- Frame another subject (positioned at the same distance from the camera as the intended subject) in the center of the frame, press the ● (*★ movie-record) button to start recording, and modify the composition.

Operations During Movie Playback

To adjust the volume, move the zoom control while a movie is playing $(\square 1)$.



Volume indicator

Playback controls are displayed in the monitor. The operations described below can be performed by using the multi selector ◀▶ to select a control and then pressing the ❸ button.



Function	lcon	Description		
Rewind	*	Hold d	Hold down the 🔞 button to rewind the movie.	
Advance	>>	Hold d	Hold down the 🕦 button to advance the movie.	
			olayback. The operations listed below can be ned while paused.	
Pause	4 II	Rewind the movie one frame. Hold down the ® button for continuous rewinding.		
		II>	Advance the movie one frame. Hold down the ® button for continuous advancing.	
		Resume playback.		
End		Return to full-frame playback mode.		

Using Menus

You can set the menus listed below by pressing the MENU (menu) button.

• 🗖 Shooting menu

Available by pressing the **MENU** button when the shooting screen is displayed.

Allows you to change image size and quality, continuous shooting settings, etc.

• Playback menu

Available by pressing the **MENU** button when viewing images in full-frame playback mode or thumbnail playback mode. Allows you to edit images, play slide shows, etc.

• **塚** Movie menu

Available by pressing the $\mbox{\it MENU}$ button when the shooting screen is displayed.

Allows you to change movie recording settings.

Y Setup menu

Allows you to adjust basic camera functions such as date and time, display language, etc.

1 Press the MENU (menu) button.

• The menu is displayed.



2 Press the multi selector **◄**.

 The current menu icon is displayed in yellow.





Menu icons

3 Select a menu icon and press the ® button.

 The menu options become selectable.





4 Select a menu option and press the ® button.

 Certain menu options cannot be set depending on the current shooting mode or the state of the camera.





5 Select a setting and press the **(B)** button.

- The setting you selected is applied.
- When you are finished using the menu, press the
- MENU button.

 When a menu is displayed,





When a menu is displayed, you can switch to shooting mode by pressing the shutter-release button,
button, or
(≀ →) button.

The Shooting Menu (for (Auto) Mode)

Image Mode (Image Size and Quality)

Enter shooting mode* → MENU button → Image mode → ® button

Select the combination of image size and compression ratio to be used when saving images.

The higher the image mode setting, the larger the size at which it can be printed, and the lower the compression ratio, the higher the quality of the images, but the number of images that can be saved is reduced.

Option*	Compression ratio	Aspect ratio (horizontal to vertical)
20 <u>м</u> * 5152×3864 ★	Approx. 1:4	4:3
20 _M 5152×3864 (default setting)	Approx. 1:8	4:3
10 _M 3648×2736	Approx. 1:8	4:3
4 _м 2272×1704	Approx. 1:8	4:3
2 _M 1600×1200	Approx. 1:8	4:3
VGA 640×480	Approx. 1:8	4:3
5120×2880	Approx. 1:8	16:9
1:1 3864×3864	Approx. 1:8	1:1

^{*} The numerical values indicate the number of pixels that are captured. Example: 201 5152x3864 = approx. 20 megapixels, 5152 x 3864 pixels

^{*} This setting can also be changed in shooting modes other than auto. The changed setting is also applied to other shooting modes.

Notes About Printing Images at 1:1 Aspect Ratio

Change the printer setting to "Border" when printing images at a 1:1 aspect ratio. Some printers may not be able to print images at a 1:1 aspect ratio.

Notes About Image Mode

This function may not be available to use in combination with other functions $(\Box \Box 44).$

Number of Images That Can Be Saved

- The approximate number of images that can be saved can be checked in the monitor when shooting (\square 10).
- Note that due to JPEG compression, the number of images that can be saved may vary greatly depending on the image content, even when using memory cards with the same capacity and the same image mode setting. In addition, the number of images that can be saved may vary depending on the make of the memory card.
- If the number of exposures remaining is 10,000 or more, the number of exposures remaining display shows "9999".

White Balance (Adjusting Hue)

Enter shooting mode $\rightarrow \square$ (shooting mode) button $\rightarrow \square$ (auto) mode $\rightarrow \square$ button \rightarrow MENU button \rightarrow White balance $\rightarrow \square$ button

Adjust white balance to suit the light source or weather conditions in order to make the colors in images match what you see with your eyes.

Option	Description
AUTO Auto (default setting)	White balance is automatically adjusted.
PRE Preset manual	Use when the desired result is not achieved with Auto , Incandescent , etc. (\(\sum_64\)).
※ Daylight	Use under direct sunlight.
* Incandescent	Use under incandescent lighting.
₩ Fluorescent	Use under fluorescent lighting.
Cloudy	Use under overcast skies.
≯ Flash	Use with the flash.

Notes About White Balance

- This function may not be available to use in combination with other functions (

 44).

Using Preset Manual

Use the procedure below to measure the white balance value under the lighting used during shooting.


- 1 Place a white or gray reference object under the lighting that will be used during shooting.
- 2 Use the multi selector ▲▼ to select Preset manual in the White balance menu, and press the 函 button.
 - The camera zooms in to the position for measuring white balance.



- 3 Select Measure.
 - To apply the last measured value, select Cancel and press the button.



- Frame the white or gray reference object in the measuring window, and press the ® button to measure the value.
 - The shutter is released and measurement is complete (no image is saved).



Measuring window

Notes About Preset Manual

A value for flash lighting cannot be measured with **Preset manual**. When shooting using the flash, set **White balance** to **Auto** or **Flash**.

Continuous Shooting

Enter shooting mode $\Rightarrow \square$ (shooting mode) button $\Rightarrow \square$ (auto) mode $\Rightarrow \bigcirc$ button \Rightarrow MENU button \Rightarrow Continuous $\Rightarrow \bigcirc$ button

Option	Description
S Single (default setting)	One image is captured each time the shutter-release button is pressed.
☐ Continuous	While the shutter-release button is held all the way down, images are captured continuously. • The frame rate for continuous shooting is about 1.1 fps and the maximum number of continuous shots is about 6 (when image mode is set to 100 5152×3864).

Notes About Continuous Shooting

- Focus, exposure, and white balance are fixed at the values determined with the first image in each series.
- It may take some time to save the images after shooting.
- This function may not be available to use in combination with other functions (□44).

ISO Sensitivity

Enter shooting mode $\Rightarrow \square$ (shooting mode) button $\Rightarrow \square$ (auto) mode $\Rightarrow \square$ button \Rightarrow MENU button \Rightarrow ISO sensitivity $\Rightarrow \square$ button

A higher ISO sensitivity allows darker subjects to be captured. Additionally, even with subjects of similar brightness, pictures can be taken at faster shutter speeds, and blurring caused by camera shake and subject movement can be reduced.

• When a higher ISO sensitivity is set, images may contain noise.

Option	Description
AUTO Auto (default setting)	Sensitivity is automatically selected from the range of ISO 80 to 1600.
ISO Fixed range auto	Select the range in which the camera automatically adjusts ISO sensitivity, from ISO 80-400 or ISO 80-800 .
80, 100, 200, 400, 800, 1600, 3200	Sensitivity is locked at the specified value.

Notes About ISO Sensitivity

This function may not be available to use in combination with other functions (\square 44).

Notes About ISO 3200

When ISO sensitivity is set to 3200, the available Image mode settings are limited to 4 2272×1704, 2 1600×1200, and 4 40×480. ■ is displayed next to the ISO sensitivity indicator in the monitor.



ISO Sensitivity Display on the Shooting Screen

- When **Auto** is selected, **ISO** is displayed when the ISO sensitivity increases.
- When Fixed range auto is selected, the maximum value for ISO sensitivity is displayed.

AF Area Mode

Enter shooting mode $\rightarrow \square$ (shooting mode) button $\rightarrow \square$ (auto) mode $\rightarrow \square$ button $\rightarrow \square$ MENU button $\rightarrow \square$ AF area mode $\rightarrow \square$ button

Set how the camera selects the focus area for autofocus.

Option	Des	cription
	When the camera detects a human face, it focuses on that face. See "Using Face Detection" (□39) for more information.	Cas 03 115000
일 Face priority	When framing a composition with no human subjects or detected faces, the camera automatically selects one or more of the nine focus areas containing the subject closest to the camera when the shutter-release button is pressed halfway.	1/250 F3.2 Focus areas
[13] Manual	Use the multi selector ▼ ▼ to move the focus area to where you want to focus. • To use the multi selector to configure the flash mode or other settings, press the button. To return to moving the focus area, press the button again.	Scope of movable focus area

Option	Desc	cription
[•] Center	The camera focuses on the subject in the center of the frame.	\$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$ \$
⊕ Subject tracking	Use this function to take pictures of moving subjects. Register the subject on which the camera focuses. The focus area automatically moves to track the subject. See "Using Subject Tracking" ((16)) for more information.	C
[•] Target finding AF (default setting)	When the camera detects the main subject, it focuses on that subject. See "Using Target Finding AF" (□41) for more information.	1/28 F3.2 Focus areas

Notes About AF Area Mode

- When digital zoom is in effect, the camera focuses in the center of the frame regardless of the AF area mode setting.

3m 0s

Using Subject Tracking

Enter shooting mode → ♠ (shooting mode) button → ♠ (auto) mode
→ ♠ button → MENU button → AF area mode → ♠ button →
♣ Subject tracking → ♠ button → MENU button

a

1 Register a subject.

- Align the subject that you want to track with the border in the center of the monitor and press the button.
- When the subject is registered, a yellow border (focus area) is displayed around it and the camera begins tracking the subject.
- If the subject cannot be registered, the border is displayed in red. Change the composition and try registering the subject again.
- To cancel subject registration, press the ® button.
- If the camera can no longer track the registered subject, the focus area disappears. Register the subject again.

2 Press the shutter-release button fully to take the picture.

 If the shutter-release button is pressed while the focus area is not displayed, the camera focuses on the subject in the center of the frame.



Notes About Subject Tracking

- If you perform operations such as zooming while the camera is tracking the subject, the registration is canceled.
- Subject tracking may not be possible in certain shooting conditions.



Autofocus Mode

Enter shooting mode $\Rightarrow \square$ (shooting mode) button $\Rightarrow \square$ (auto) mode $\Rightarrow \square$ button \Rightarrow MENU button \Rightarrow Autofocus mode $\Rightarrow \square$ button

Set how the camera focuses when shooting still images.

Option	Description
AF-S Single AF (default setting)	The camera focuses only when the shutter-release button is pressed halfway.
AF-F Full-time AF	The camera continues focusing even when the shutter-release button is not pressed halfway. The sound of lens drive movement is heard while the camera focuses.

Autofocus Mode for Movie Recording

Autofocus mode for movie recording can be set with **Autofocus mode** $(\Box$ 77) in the movie menu.

The Smart Portrait Menu

 See "Image Mode (Image Size and Quality)" (□61) for information about Image mode.

Blink Proof

Enter shooting mode $\Rightarrow \square$ (shooting mode) button $\Rightarrow \square$ Smart portrait mode $\Rightarrow \square$ button \Rightarrow MENU button \Rightarrow Blink proof $\Rightarrow \square$ button

Option	Description
® On	The camera automatically releases the shutter twice with every shot and saves one image in which the subject's eyes are open. If the camera saved an image in which the subject's eyes may have been closed, the dialog shown on the right is displayed for a few seconds. The flash cannot be used.
Off (default setting)	Turns the blink proof off.

Notes About Blink Proof

This function may not be available to use in combination with other functions $(\Box 44)$.

The Playback Menu

Slide Show

Press the $lackbox{ }$ button (playback mode) ightharpoonup button ightharpoonup Slide show ightharpoonup button

Play back images one by one in an automated "slide show." When movie files are played back in the slide show, only the first frame of each movie is displayed.

1 Use the multi selector ▲▼ to select Start and press the ® button.

- · The slide show begins.
- To change the interval between images, select Frame intvl, press the button, and specify the desired interval time before selecting Start.



- To repeat the slide show automatically, select **Loop** and press the button before selecting **Start**.
- The maximum playback time is up to about 30 minutes even if Loop is enabled.

2 End or restart the slide show.

The screen shown on the right is displayed after the slide show ends or is paused. To exit the show, select ■ and then press the ❸ button. To resume the slide show, select ■ and then press the ❸ button.



Operations During Playback

- Press the 🕅 button to pause or end the slide show.

Protect

Press the ▶ button (playback mode) → MENU button → Protect → ® button

The camera protects selected images from accidental deletion. Select images to protect or cancel protection from the image selection screen (\square 75).

Note that formatting the memory card or the camera's internal memory permanently deletes all data including protected files (\square 86).

Rotate Image

Press the $lackbox{P}$ button (playback mode) \Rightarrow MENU button \Rightarrow Rotate image \Rightarrow 8 button

Specify the orientation in which saved images are displayed during playback. Still images can be rotated 90 degrees clockwise or 90 degrees counterclockwise

Select an image from the image selection screen (\square 75). When the Rotate image screen is displayed, press the multi selector \blacktriangleleft to rotate the image 90 degrees.



Rotate 90 degrees







Rotate 90 degrees clockwise

Press the **®** button to finalize display orientation, and save orientation information with the image.

Copy (Copy Between the Memory Card and Internal Memory)

Press the ightharpoonup button (playback mode) ightharpoonup MENU button ightharpoonup Copy ightharpoonup 68 button

Images can be copied between a memory card and the internal memory.

- When a memory card that contains no images is inserted and the camera is switched to playback mode, Memory contains no images. is displayed. In that case, press the MENU button to select Copy.
- 1 Use the multi selector ▲▼ to select a destination option to which images are copied and press the ® button.





Notes About Copying Images

- Only files in formats that this camera can record can be copied.
- Operation is not guaranteed with images captured with another make of camera or that have been modified on a computer.

The Image Selection Screen

When an image selection screen such as the one shown on the right is displayed while operating the camera, follow the procedures described below to select the images.



- 1 Use the multi selector ◀▶ to select an image.
 - Move the zoom control (□1) toward T (९) to switch to full-frame playback or W (□1) to switch to thumbnail playback.
 - Only one image can be selected for Rotate image. Proceed to step 3.



- 2 Use ▲▼ to select or deselect (or to specify the number of copies).
 - When an image is selected, an icon is displayed below the image. Repeat steps 1 and 2 to select additional images.



- **3** Press the **6** button to apply image selection.
 - When a confirmation dialog is displayed, follow the on-screen instructions to operate.

The Movie Menu

Movie Options

Enter shooting mode \Rightarrow MENU button \Rightarrow $\frac{1}{12}$ menu icon \Rightarrow Movie options \Rightarrow $\frac{1}{12}$ button

Select the desired movie option to record. The movie options that can be selected vary depending on the **Video mode** setting (\square 87).

 Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies (
122).

Option (Image size/Frame rate)	Image size	Aspect ratio (horizontal to vertical)
720 g 720/30p 720 g 720/25p (default setting*)	1280 × 720	16:9
480 gm 480/30p 480 am 480/25p	640 × 480	4:3
240 gg 240/30p 240 gg 240/25p	320 × 240	4:3

^{*} When recording in the internal memory, the default setting is 480/30p or 480/8 480/25p, and 220 720/30p or 220 720/25p cannot be selected.

Autofocus Mode

Enter shooting mode \Rightarrow MENU button \Rightarrow * menu icon \Rightarrow Autofocus mode \Rightarrow * button

Set how the camera focuses in movie mode.

Option	Description
AF-S Single AF (default setting)	Focus is locked when movie recording starts. Select this option when the distance between the camera and subject will remain fairly consistent during movie recording.
AF-F Full-time AF	The camera focuses continuously during movie recording. Select this option when the distance between the camera and subject will change significantly during recording. The sound of the camera focusing may be heard in the recorded movie. Use of Single AF is recommended to prevent the sound of the camera focusing from interfering with recording.

Wind Noise Reduction

Enter shooting mode \rightarrow MENU button \rightarrow ' $\overline{}$ menu icon \rightarrow Wind noise reduction \rightarrow ® button

Option	Description
₽∮ On	Reduces the sound that is produced when wind passes over the microphone during movie recording. Other sounds may become difficult to hear during playback.
Off (default setting)	Wind noise reduction is disabled.

The Setup Menu

Time Zone and Date

Press the MENU button \Rightarrow Υ menu icon \Rightarrow Time zone and date \Rightarrow 8 button

Set the camera clock.

Option	Description
Date and time	Select a field: Press the multi selector Edit the date and time: Press Apply the setting: Select the minute setting and press the button. D M Y h m 101.01.2016 00:00 W GEdit
Date format	Select Year/Month/Day, Month/Day/Year, or Day/Month/Year.
Time zone	Set time zone and daylight saving time. • When Travel destination (♠) is set after having set the home time zone (♠), the time difference between the travel destination and the home time zone is automatically calculated, and the date and time are saved for the selected region.

Setting the Time Zone

1 Use the multi selector ▲▼ to select Time zone and press the ® button.



2 Select ★ Home time zone or ﴿ Travel destination and press the button.

 The date and time displayed in the monitor changes depending on whether the home time zone or travel destination is selected.



3 Press ▶.



4 Use **♦** to select the time zone.

- Press ▲ to enable daylight saving time function, and 🏶 is displayed. Press ▼ to disable the daylight saving time function.
- Press the **®** button to apply the time zone.
- If the correct time is not displayed for the home or travel destination time zone setting, set the appropriate time in **Date** and time.



Monitor Settings

Press the MENU button \Rightarrow Υ menu icon \Rightarrow Monitor settings \Rightarrow M button

Option	Description
Photo info	Set whether or not to display information in the monitor.
Image review	Set whether or not to display the captured image immediately after shooting. • Default setting: On
Brightness	Adjust the brightness. • Default setting: 3

Photo Info

	Shooting mode	Playback mode
Showinfo	22350 (A)	4/9
Auto info (default setting)	The same information as shown in Show info is displayed, and it is hidden as shown in Hide info if no operations are performed for a few seconds. The information is displayed again when an operation is performed.	
Hide info		

Shooting mode Playback mode 4/4 ź* 720 H 20. Framing grid+auto info In addition to the information Same as Auto info. shown in Auto info, a framing grid is displayed to help frame pictures. The framing grid is not displayed while recording movies. 720 to 20. 2"

Movie frame+auto info

In addition to the information shown in **Auto info**, a frame is displayed before movie recording begins that represents the area that will be captured when recording movies.

The movie frame is not displayed while recording movies.

Same as Auto info.

Date Stamp

Press the MENU button → 🕆 menu icon → Date stamp → 🚳 button

The shooting date and time can be stamped on images when shooting. The information can be printed even when using a printer that does not support the date imprinting function.



Option	Description
DATE Date	Date is stamped on images.
DATEC Date and time	Date and time are stamped on images.
Off (default setting)	Date and time are not stamped on images.

Notes About Date Stamp

- Stamped dates form a permanent part of image data and cannot be deleted. The date and time cannot be stamped on images after they have been captured.
- The date and time cannot be stamped in the following situations:
 - When using **Panorama assist** scene mode
 - When shooting movies
- The stamped date and time may be difficult to read when using a small image size.

Printing a Shooting Date on Images Without a Date Stamp

You can transfer images to a computer and use the ViewNX-i software (\square 97) to imprint the shooting date on the images when they are printed.

Electronic VR

Press the MENU button → 🕆 menu icon → Electronic VR → 👀 button

Choose whether or not to use electronic VR (vibration reduction), which reduces the effects of camera shake during shooting.

Option	Description
(♣)) [@] On	When taking still images, electronic vibration reduction is enabled when all of the conditions below are met. Flash mode is set to Off or Slow sync . The shutter speed is slow. Continuous is set to Single . The subject is dark. When recording movies, electronic vibration reduction is enabled at all times.
Off (default setting)	Electronic vibration reduction is disabled.

Notes About Electronic Vibration Reduction

- The effectiveness of electronic vibration reduction decreases as camera shake increases.
- The image captured using electronic vibration reduction may contain noise.
- Electronic vibration reduction does not function under the following conditions or in the following shooting modes:
 - When slow sync with red-eye reduction (QQ38) is used.
 - When exposure exceeds a certain length of time.
 - When Sports, Night portrait, Dusk/dawn, Night landscape, Fireworks show, or Backlighting scene mode is used.
- Electronic vibration reduction cannot be used in other shooting modes when using certain settings (\$\sum_44\$).
- When Electronic VR is set to On, the angle of view (the area captured in the recorded movie) during movie recording is smaller.

AF Assist

Press the MENU button → 🕆 menu icon → AF assist → 👀 button

Option	Description
AUTO Auto (default setting)	The AF-assist illuminator automatically lights up when you press the shutter-release button under dim lighting. The illuminator has a range of about 1.9 m (6 ft 2 in.) at the maximum wide-angle position and about 1.1 m (3 ft 7 in.) at the maximum telephoto position. Note that for some scene modes or focus areas, the AF-assist illuminator may not light.
Off	The AF-assist illuminator does not light.

Digital Zoom

Press the MENU button \Rightarrow Υ menu icon \Rightarrow Digital zoom \Rightarrow M button

Option	Description
On (default setting)	Digital zoom is enabled.
Off	Digital zoom is disabled.

Notes About Digital Zoom

- Digital zoom cannot be used in the following shooting modes:
 - Portrait, Night portrait, or Pet portrait scene mode
 - Smart portrait mode
- Digital zoom cannot be used in other shooting modes when using certain settings $(\Box\!\!\!\Box 45).$

Sound Settings

Press the MENU button → 🕆 menu icon → Sound settings → 🕟 button

Option	Description
Button sound	When On (default setting) is selected, the camera produces one beep when operations are performed, two beeps when focus is acquired on the subject, and three beeps when an error occurs. The start-up sound is also produced. • Sounds are disabled when using Pet portrait scene mode.
Shutter sound	When On (default setting) is selected, the shutter sound is produced when the shutter is released. The shutter sound is not produced when using continuous shooting mode, when recording movies, or when using Pet portrait scene mode.

Auto Off

Press the MENU button \Rightarrow Υ menu icon \Rightarrow Auto off \Rightarrow N button

Set the amount of time that elapses before the camera enters standby mode $(\square 12)$.

You can select 30 s, 1 min (default setting), 5 min, or 30 min.

Setting the Auto Off Function

The time that passes before the camera enters standby mode is fixed in the following situations:

- When a menu is displayed: 3 minutes (when auto off is set to 30 s or 1 min)
- When shooting using **Pet portrait auto release**: 5 minutes (when auto off is set to **30 s** or **1 min**)
- When shooting using **Smile timer**: 5 minutes (when auto off is set to **30 s** or **1** min)
- When the AC Adapter EH-62G is connected: 30 minutes
- When an audio video cable is connected: 30 minutes

Format Card/Format Memory

Press the MENU button → Y menu icon → Format card/Format memory →
® button

Use this option to format a memory card or the internal memory.

Formatting the memory cards or internal memory permanently deletes all data. Data that has been deleted cannot be recovered. Make sure to save important images to a computer before formatting.

Formatting a Memory Card

- · Insert a memory card into the camera.
- Select **Format card** in the setup menu and then press the **®** button.

Formatting the Internal Memory

- Remove the memory card from the camera.
- Select **Format memory** in the setup menu and then press the **®** button.

To start formatting, select **Format** on the screen that is displayed and press the **®** button.

 Do not turn the camera off or open the battery-chamber/memory card slot cover during formatting.

Language

Press the MENU button → 🕆 menu icon → Language → 🚳 button

Select a language for display of camera menus and messages.

Video Mode

Press the MENU button → Y menu icon → Video mode → 66 button

Adjust settings necessary for connection to a TV.

Select from NTSC and PAL.

Both NTSC and PAL are standards for analog color television broadcasting.

• The available frame rates in **Movie options** (\square 76) vary depending on the video mode setting.

Charge by Computer

Option	Description
AUTO Auto (default setting)	When the camera is connected to a computer that is running (\square 90), the battery inserted into the camera is automatically charged using power supplied by the computer.
Off	The battery inserted into the camera is not charged when the camera is connected to a computer.

Notes About Charging with a Computer

- When connected to a computer, the camera turns on and starts charging. If the camera is turned off, charging stops.
- About 3 hours are required to charge a fully exhausted battery. Charging time increases when images are transferred while the battery is charging.
- The camera turns off automatically if there is no communication with the computer for 30 minutes after the battery has finished charging.

When the Charge Lamp Quickly Flashes Green

Charging cannot be performed, possibly due to one of the reasons described below.

- The ambient temperature is not suited to charging. Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F).
- The USB cable is not connected correctly, or the battery is faulty. Make sure the USB cable is connected correctly or replace the battery if necessary.
- The computer is in sleep mode and is not supplying power. Wake up the computer.
- The battery cannot be charged because the computer cannot supply power to the camera due to the computer's settings or its specifications.

Reset All

Press the MENU button → 🕆 menu icon → Reset all → 🕟 button

When **Reset** is selected, the camera's settings are restored to their default values.

• Some settings, such as **Time zone and date** or **Language**, are not reset.

Resetting File Numbering

To reset file numbering to "0001", delete all images saved on the memory card or in the internal memory (\square 15) before selecting **Reset all**.


Firmware Version

Press the MENU button → 🕆 menu icon → Firmware version → 👀 button

View the current camera firmware version.

Connecting the Camera to a TV, Printer, or Computer

You can enhance your enjoyment of images and movies by connecting the camera to a TV, printer, or computer.





- Before connecting the camera to an external device, make sure the remaining battery level is sufficient and turn the camera off. Before disconnecting, make sure to turn the camera off.
- If the AC Adapter EH-62G (available separately) is used, this camera can be powered from an electrical outlet. Do not use any other make or model of AC adapter as it may cause the camera to heat up or malfunction.
- For information about the connection methods and subsequent operations, refer to the documentation included with the device in addition to this document.



Images and movies captured with the camera can be viewed on a TV.

Connection method: Connect the video and audio plugs of an optional audio video cable to the TV's input jacks.

Printing images without using a computer

193



If you connect the camera to a PictBridge-compatible printer, you can print images without using a computer. Connection method: Connect the camera directly to the printer's USB port with the USB cable.

Viewing and organizing images on a computer

197



You can transfer images and movies to a computer for viewing and editing.


Connection method: Connect the camera to the computer's

USB port with the USB cable.


- Before connecting to a computer, install ViewNX-i on the computer (□197).
- If any USB devices that draw the power from the computer are connected, disconnect them from the computer before you connect the camera to it. Connecting the camera and other USB-powered devices to the same computer simultaneously may cause a camera malfunction or excessive power supply from the computer, which could damage the camera or memory card.

Connecting the Camera to a TV (Playback on a TV)

- 1 Turn off the camera and connect it to the TV.
 - Connect the yellow plug to the video-in jack and the white plug to the audio-in jack on the TV.
 - Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an angle when connecting or disconnecting them.



- **2** Set the TV's input to external video input.
 - See the documentation provided with your TV for details.
- **3** Hold down the ▶ (playback) button to turn on the camera.
 - · Images are displayed on the TV.
 - The camera monitor does not turn on.




Connecting the Camera to a Printer (Direct Print)

Users of PictBridge-compatible printers can connect the camera directly to the printer and print images without using a computer.

Connecting the Camera to a Printer

- 1 Turn on the printer.
- **2** Turn off the camera and connect it to the printer using the USB cable.
 - Make sure that the plugs are properly oriented. Do not insert or remove the plugs at an angle when connecting or disconnecting them.



- **3** The camera is automatically turned on.
 - The PictBridge startup screen (1) is displayed in the camera monitor, followed by the Print selection screen (2).



If the PictBridge Startup Screen Is Not Displayed

When **Auto** is selected for **Charge by computer** (\square 88), it may be impossible to print images with direct connection of the camera to some printers. If the PictBridge startup screen is not displayed after the camera is turned on, turn the camera off and disconnect the USB cable. Set **Charge by computer** to **Off** and reconnect the camera to the printer.

Printing Images One at a Time

- 1 Use the multi selector ◀► to select the desired image and press the [®] button.
 - Move the zoom control toward W (♠) to switch to thumbnail playback or T (Q) to switch to full-frame playback.



- 2 Use ▲▼ to select **Copies** and press the **®** button.
 - Use ▲▼ to set the desired number of copies (up to nine) and press the ௵ button.



- 3 Select Paper size and press the 60 button.

 - To print with the paper size setting configured on the printer, select **Default**.
 - The paper size options available on the camera vary depending on the printer that you use.



- 4 Select **Start print** and press the **®** button.
 - Printing starts.



Printing Multiple Images

When the **Print selection** screen is displayed, press the MENU (menu) button.



Print all images

Paper size

16

- 2 Use the multi selector $\blacktriangle \blacktriangledown$ to select Paper size and press the ® button.
 - Select the desired paper size and press the (K) button.
 - To print with the paper size setting configured on the printer, select **Default**.
 - · The paper size options available on the camera vary depending on the printer that you use.
 - To exit the print menu, press the **MENU** button.
- 3 Select Print selection or Print all images and press the ® button.





Print selection

Select images (up to 99) and the number of copies (up to 9) of each.

- Use the multi selector

 to select images, and use

 to specify the number of copies to be printed.



- Move the zoom control toward T (Q) to switch to full-frame playback or W () to switch to thumbnail playback.
- Press the button when setting is complete. When the screen for
 confirming the number of print copies is displayed, select **Start print**and press the button to start printing.

Print all images

One copy each of all images saved in the internal memory, or on the memory card, is printed.

 When the screen for confirming the number of print copies is displayed, select Start print and press the button to start printing.

Using ViewNX-i (Transferring Images to a Computer)

Installing ViewNX-i

ViewNX-i is free software that enables you to transfer images and movies to your computer for viewing and editing.

To install ViewNX-i, download the latest version of the ViewNX-i installer from the following website and follow the on-screen instructions to complete installation.

ViewNX-i: http://downloadcenter.nikonimglib.com

For system requirements and other information, see the Nikon website for your region.

Transferring Images to a Computer


1 Prepare a memory card that contains images.

You can use any of the methods below to transfer images from the memory card to a computer.

- SD memory card slot/card reader: Insert the memory card into the card slot of your computer or the card reader (commercially available) that is connected to the computer.
- Direct USB connection: Turn the camera off and ensure that the memory card is inserted in the camera. Connect the camera to the computer using the USB cable.

The camera automatically turns on.

To transfer images that are saved in the camera's internal memory, remove the memory card from the camera before connecting it to the computer.



If a message is displayed prompting you to choose a program, select Nikon Transfer 2.

When using Windows 7

If the dialog shown at right is displayed, follow the steps below to select Nikon Transfer 2.

1 Under Import pictures and videos, click Change program. A program selection dialog will be displayed; select Nikon Transfer 2 and click OK.



2 Double-click the Nikon Transfer 2 icon.

• When using Windows 10 or Windows 8.1

If the dialog shown on the right is displayed, click the dialog and then click **Import File/Nikon Transfer 2**.



• When using Mac OS X

If Nikon Transfer 2 does not automatically start, launch the **Image Capture** application that comes bundled with Mac while the camera and your computer are connected, and select Nikon Transfer 2 as the default application to open when the camera is connected to your computer.

If the memory card contains a large number of images, it may take a while for Nikon Transfer 2 to start. Wait until Nikon Transfer 2 starts.

Notes About Connecting the USB Cable

Operation is not guaranteed if the camera is connected to the computer via a USB hub.



Consult online help of ViewNX-i.

2 After Nikon Transfer 2 starts, click **Start Transfer**.



Start Transfer

 Image transfer begins. When image transfer is complete, ViewNX-i starts and the transferred images are displayed.

3 Terminate the connection.

- If you are using a card reader or card slot, choose the appropriate option in the computer operating system to eject the removable disk corresponding to the memory card and then remove the memory card from the card reader or card slot.
- If the camera is connected to the computer, turn the camera off and disconnect the USB cable.

Technical Notes

101
101
102
103
104
105
105
105
106
109
116
117
118
122
124

Caring for the Product

Observe the precautions described below in addition to the warnings in "For Your Safety" (\(\subseteq vi-viii\)) when using or storing the device.

The Camera

Do Not Apply Strong Impact to the Camera

The product may malfunction if subjected to strong shock or vibration. In addition, do not touch or apply force to the lens or lens cover.

Keep Dry

The device will be damaged if immersed in water or subjected to high humidity.

Avoid Sudden Changes in Temperature

Sudden changes in temperature, such as when entering or leaving a heated building on a cold day, can cause condensation to form inside the device. To prevent condensation, place the device in a carrying case or a plastic bag before exposing it to sudden changes in temperature.

Keep Away from Strong Magnetic Fields

Do not use or store this device in the vicinity of equipment that generates strong electromagnetic radiation or magnetic fields. Doing so could result in loss of data or camera malfunction.

Do Not Point the Lens at Strong Light Sources for Extended Periods

Avoid pointing the lens at the sun or other strong light sources for extended periods when using or storing the camera. Intense light may cause the image sensor to deteriorate or produce a white blur effect in photographs.

Turn the Product Off Before Removing or Disconnecting the Power Source or Memory Card

Do not remove the battery while the product is on, or while images are being saved or deleted. Forcibly cutting power in these circumstances could result in loss of data or in damage to product memory or internal circuitry.

Notes About the Monitor

- Monitors and electronic viewfinders are constructed with extremely high precision; at least 99.99% of pixels are effective, with no more than 0.01% being missing or defective. Hence while these displays may contain pixels that are always lit (white, red, blue, or green) or always off (black), this is not a malfunction and has no effect on images recorded with the device.
- Images in the monitor may be difficult to see under bright lighting.
- Do not apply pressure to the monitor, as this could cause damage or malfunction.
 Should the monitor break, care should be taken to avoid injury caused by broken glass and to prevent the liquid crystal from the display touching the skin or entering the eves or mouth.

Notes About Smear

White or colored streaks may be visible when bright subjects are framed in the monitor. This phenomenon, known as "smear," occurs when extremely bright light strikes the image sensor; it is characteristic of image sensors and does not indicate a malfunction. Smear may also take the form of partial discoloration in the monitor during shooting. It does not appear in images saved with the camera except in the cases of movies. When recording movies, we recommend that you avoid bright subjects such as the sun, reflected sunlight, and electric lights.

The Battery

Precautions for Use

- Note that the battery may become hot after use.
- Do not use the battery at ambient temperatures below 0°C (32°F) or above 40°C (104°F) as this could cause damage or malfunction.
- If you notice any abnormalities such as excessive heat, smoke, or an unusual smell coming from the battery, immediately discontinue use and consult your retailer or Nikon-authorized service representative.
- After removing the battery from the camera or optional battery charger, put the battery in a plastic bag, etc. in order to insulate it.

Charging the Battery

Check the battery level before using the camera and replace or charge the battery if necessary.

- Charge the battery indoors with an ambient temperature of 5°C to 35°C (41°F to 95°F) before use.
- A high battery temperature may prevent the battery from charging properly or completely, and may reduce battery performance. Note that the battery may become hot after use; wait for the battery to cool before charging.
 When charging the battery inserted into this camera using the Charging AC Adapter or a computer, the battery is not charged at battery temperatures below 0°C (32°F) or above 45°C (113°F).
- Do not continue charging once the battery is fully charged as this will result in reduced battery performance.
- The battery temperature may increase during charging. However, this is not a malfunction.

Carrying Spare Batteries

Whenever possible, carry fully charged spare batteries when taking pictures on important occasions.

Using the Battery When Cold

On cold days, the capacity of batteries tends to decrease. If an exhausted battery is used at a low temperature, the camera may not turn on. Keep spare batteries in a warm place and exchange as necessary. Once warmed, a cold battery may recover some of its charge.

Battery Terminals

Dirt on the battery terminals may prevent the camera from functioning. Should the battery terminals become dirty, wipe them off with a clean, dry cloth before use.

Charging an Exhausted Battery

Turning the camera on or off while an exhausted battery is inserted in the camera may result in reduced battery life. Charge the exhausted battery before use.

Storing the Battery

- Always remove the battery from the camera or optional battery charger when it is not being used. Minute amounts of current are drawn from the battery while it is in the camera, even when not in use. This may result in excessive battery drain and complete loss of function.
- Recharge the battery at least once every six months and completely exhaust it before returning it to storage.
- Put the battery in a plastic bag, etc. in order to insulate it and store it in a cool place.
 The battery should be stored in a dry location with an ambient temperature of 15°C to 25°C (59°F to 77°F). Do not store the battery in hot or extremely cold locations.

Battery Life

A marked drop in the time a fully charged battery retains its charge, when used at room temperature, indicates that the battery needs to be replaced. Purchase a new battery.

Recycling Used Batteries

Replace the battery when it no longer holds a charge. Used batteries are a valuable resource. Please recycle used batteries in accordance with local regulations.

The Charging AC Adapter

- The Charging AC Adapter EH-72P/EH-72PCH is for use only with compatible devices. Do not use with another make or model of device.
- Do not, under any circumstances, use another make or model of AC adapter other than Charging AC Adapter EH-72P/EH-72PCH or USB-AC adapter. Failure to observe this precaution could result in overheating or in damage to the camera.
- The EH-72P/EH-72PCH is compatible with AC 100–240 V, 50/60 Hz electrical outlets. When using in other countries, use a plug adapter (commercially available) as necessary. For more information about plug adapters, consult your travel agency.

Memory Cards

Precautions for Use

- Use only Secure Digital memory cards (QQ 122).
- Be sure to follow the precautions described in the documentation included with the memory card.
- Do not put labels or stickers on memory cards.

Formatting

- Do not format the memory card using a computer.
- The first time you insert a memory card that has been used in another device into this camera, be sure to format it with this camera. We recommend formatting new memory cards with this camera before using them with this camera.
- Note that formatting a memory card permanently deletes all images and other data on the memory card. Be sure to make copies of any images you wish to keep before formatting the memory card.
- If the message Card is not formatted. Format card? is displayed when the
 camera is turned on, the memory card must be formatted. If there is data that you
 do not want to delete, select No. Copy the necessary data to a computer, etc. If you
 want to format the memory card, select Yes. The confirmation dialog will be
 displayed. To start formatting, press the W button.
- Do not perform the following during formatting, while data is being written to or deleted from the memory card, or during data transfer to a computer. Failure to observe this precaution could result in the loss of data or in damage to the camera or memory card:
 - Open the battery-chamber/memory card slot cover to remove/insert the battery or memory card.
 - Turn off the camera.
 - Disconnect the AC adapter.

Cleaning and Storage

Cleaning

Do not use alcohol, thinner, or other volatile chemicals.

Lens	Avoid touching glass parts with your fingers. Remove dust or lint with a blower (typically a small device with a rubber bulb attached to one end that is pumped to produce a stream of air out the other end). To remove fingerprints or other stains that cannot be removed with a blower, wipe the lens with a soft cloth, using a spiral motion that starts at the center of the lens and working toward the edges. If this fails, clean the lens using a cloth lightly dampened with commercial lens cleaner.
Monitor	Remove dust or lint with a blower. To remove fingerprints and other stains, clean the monitor with a soft, dry cloth, being careful not to apply pressure.
Body	Use a blower to remove dust, dirt, or sand, then wipe gently with a soft, dry cloth. After using the camera at the beach or other sandy or dusty environment, wipe off any sand, dust, or salt with a dry cloth lightly dampened with fresh water and dry thoroughly. Note that foreign matter inside the camera could cause damage not covered by the warranty.

Storage

Remove the battery if the camera will not be used for an extended period. To prevent mold or mildew, take the camera out of storage at least once a month. Turn the camera on and release the shutter a few times before putting the camera away again. Do not store the camera in any of the following locations:

- Places that are poorly ventilated or subject to humidity of over 60%
- Exposed to temperatures above 50°C (122°F) or below −10°C (14°F)
- Next to equipment that produces strong electromagnetic fields, such as televisions or radios

For storing the battery, follow the precautions in "The Battery" (\square 102) in "Caring for the Product" (\square 101).

Error Messages

Refer to the table below if an error message is displayed.

Display	Cause/Solution	Щ
Battery temperature is elevated. The camera will turn off.	The camera turns off automatically. Wait until the camera or battery temperature has cooled before resuming use.	-
The camera will turn off to prevent overheating.	mas cooled before resultning use.	
Memory card is write protected.	The write-protect switch is in the "lock" position. Slide the write-protect switch to the "write" position.	-
This card cannot be used.	An error occurred while accessing the	
This card cannot be read.	memory card. Use an approved memory card. Check that the terminals are clean. Confirm that the memory card is correctly inserted.	6, 122
Card is not formatted. Format card?	The memory card has not been formatted for use in the camera. Formatting deletes all data saved on the memory card. If you need to keep copies of any images, make sure to select No and save the copies to a computer or other medium before formatting the memory card. Select Yes and press the 3 button to format the memory card.	104
Out of memory.	Delete images or insert a new memory card.	6, 15
	An error occurred while saving the image. Insert a new memory card or format the memory card or internal memory.	86
Image cannot be saved.	The camera has run out of file numbers. Insert a new memory card or format the memory card or internal memory.	86
	There is insufficient space to save the copy. Delete images from the destination.	15

Display	Cause/Solution	Ф
Image cannot be modified.	Check that the images can be edited.	49, 114
Cannot record movie.	A time-out error occurred while saving the movie on the memory card. Select a memory card with a faster write speed.	57, 122
Memory contains no images.	There are no images in the internal memory or on the memory card. Remove the memory card to play back images in the internal memory. To copy the images saved in the camera's internal memory to the memory card, press the MENU button to select Copy in the playback menu.	6 74
File contains no image data.	The file was not created or edited with this camera.	
This file cannot be played back.	The file cannot be viewed on this camera. View the file using a computer or the device used to create or edit this file.	_
All images are hidden.	There are no images available for a slide show, etc.	72
This image cannot be deleted.	The image is protected. Disable protection.	73
Lens error. Try again after turning the camera off and on.	If the error persists, contact your retailer or Nikon-authorized service representative.	109
Communications error	An error occurred while communicating with the printer. Turn the camera off and reconnect the USB cable.	93
System error	An error occurred in the camera's internal circuitry. Turn the camera off, remove and reinsert the battery, and turn the camera on. If the error persists, contact your retailer or Nikon-authorized service representative.	109

Display	Cause/Solution	Ф
Printer error: check printer status.	After solving the problem, select Resume and press the ® button to resume printing.*	-
Printer error: check paper.	Load the specified size of paper, select Resume , and press the ® button to resume printing.*	-
Printer error: paper jam.	Remove the jammed paper, select Resume , and press the ® button to resume printing.*	-
Printer error: out of paper.	Load the specified size of paper, select Resume , and press the ® button to resume printing.*	-
Printer error: check ink.	There is a problem with the printer's ink. Check the ink, select Resume , and press the ® button to resume printing.*	-
Printer error: out of ink.	Replace the ink cartridge, select Resume , and press the ® button to resume printing.*	-
Printer error: file corrupt.	There is a problem with the image file to be printed. Select Cancel and press the ® button to cancel printing.	_

^{*} See the documentation provided with your printer for further guidance and information.

Troubleshooting

If the camera fails to function as expected, check the list of common problems below before consulting your retailer or Nikon-authorized service representative.

Power, Display, Settings Issues

Problem	Cause/Solution	Ш
The camera is on but does not respond.	Wait for recording to end. If the problem persists, turn the camera off. If the camera does not turn off, remove and reinsert the battery or batteries or, if you are using an AC adapter, disconnect and reconnect the AC adapter. Note that although any data currently being recorded will be lost, data that have already been recorded will not be affected by removing or disconnecting the power source.	-
The camera cannot be turned on.	The battery is exhausted.	6, 7, 103
The camera turns off without warning.	The camera automatically turns off to save power (auto off function). The camera and battery may not work properly at low temperatures. The inside of the camera has become hot. Leave the camera off until the inside of the camera has cooled, and then try turning it on again.	12 102 -
The monitor is blank.	The camera is off. The camera automatically turns off to save power (auto off function). The flash lamp flashes while the flash is charging. Wait until charging is complete. The camera is connected to a TV or computer.	9 12 - -
The camera becomes hot.	The camera may become hot when used for an extended period of time to shoot movies or when used in a hot environment; this is not a malfunction.	-

Problem	Cause/Solution	m
	Confirm all connections. When connected to a computer, the camera may not charge for any of the reasons described below.	7
	Off is selected for Charge by computer in the setup menu. Battery charging stops if the camera is turned off.	59, 88
The battery inserted in the camera cannot be charged.	oll. Battery charging is not possible if the camera's display language and date and time have not been set, or the date and time were reset after the camera's clock battery was exhausted. Use the Charging AC Adapter to charge the battery.	9, 10
	Battery charging may stop when the computer enters sleep mode. Depending on the computer specifications, settings, and status, battery charging may not be possible.	_
The monitor is hard to read.	Adjust the monitor brightness. The monitor is dirty. Clean the monitor.	80 105
flashes on the screen.	If the camera clock has not been set, fishes on the shooting screen, and images and movies	
Date and time of recording are not correct.	saved before the clock is set are dated "00/00/0000 00:00" and "01/01/2016 00:00" respectively. Set the correct time and date for Time zone and date in the setup menu. The camera clock is not as accurate as ordinary watches or clocks. Periodically compare the time of the camera clock with that of a more accurate timepiece, and reset as required.	4, 78
No indicators displayed in monitor.	Hide info is selected for Photo info in Monitor settings in the setup menu.	80
Date stamp not available.	Time zone and date has not been set in the setup menu.	78
Date not stamped on images even when Date stamp is enabled.	The current shooting mode does not support Date stamp. The date cannot be stamped on movies.	82

Problem	Cause/Solution	Φ
Screen for setting time zone and date is displayed when the camera is turned on.	The clock battery is exhausted; all settings were restored to their default values.	9, 10
The camera settings reset.		
The camera makes sound.	When Autofocus mode is set to Full-time AF or while in some shooting modes, the camera may produce an audible focusing sound.	17, 70, 77

Shooting Issues

Problem	Cause/Solution	ш
Cannot switch to shooting mode.	The camera cannot be switched to shooting mode while connected to a power outlet via the Charging AC Adapter.	90
Cannot take pictures or record movies.	When the camera is in playback mode, press the button, Shutter-release button, or ● (*★) button. When menus are displayed, press the MENU button. The flash is charging while the flash lamp is flashing. The battery is exhausted.	1, 14 59 32 6, 7, 103
The camera cannot focus.	The subject is too close. Try shooting using scene auto selector mode, Close-up scene mode, or macro mode. The subject is hard to focus on. Set AF assist in the setup menu to Auto. Turn the camera off and then on again.	17, 18, 19, 21, 35 42 84
lmages are blurred.	Use the flash. Increase the ISO sensitivity value. Use Electronic VR. Use a tripod to stabilize the camera (using the self-timer at the same time is more effective).	32 66 83 34

Problem	Cause/Solution	Ш
Streaks of light or partial discoloration are visible in the monitor.	Smear may occur when extremely bright light strikes the image sensor. When recording movies, avoiding bright objects, such as the sun, reflections of the sun, and electric lights is recommended.	57, 102
Bright specks appear in images captured with flash.	The flash is reflecting off particles in the air. Set the flash mode setting to ③ (off).	32
Flash does not fire.	 The flash mode is set to ③ (off). A scene mode that restricts the flash is selected. A function that restricts the flash is enabled. 	32 37 44
Optical zoom cannot be used.	Optical zoom cannot be used while recording movies.	57
Digital zoom cannot be used.	Digital zoom is set to Off in the setup menu. Digital zoom cannot be used with certain shooting modes or when using certain settings in other functions.	84 45, 84
Image mode not available.	A function that restricts Image mode is enabled.	44
No sound when the shutter is released.	Off is selected for Shutter sound in Sound settings in the setup menu. No sound is produced with some shooting modes and settings, even when On is selected.	85
AF-assist illuminator does not light.	Off is selected for AF assist in the setup menu. AF-assist illuminator may not light depending on the position of the focus area or the current scene mode, even when Auto is selected.	84
Images appear smeared.	The lens is dirty. Clean the lens.	105
Colors are unnatural.	White balance or hue is not adjusted properly.	22, 63
Randomly spaced bright pixels ("noise") appear in image.	The subject is dark and the shutter speed is too slow, or ISO sensitivity is too high. Noise can be reduced by: • Using the flash • Specifying a lower ISO sensitivity setting	32 66

Problem	Cause/Solution	Щ
Randomly spaced bright pixels ("noise") appear in movies.	When recording movies in dim lighting, the image may contain noise. This occurs when the ISO sensitivity increases, and it does not indicate a malfunction.	-
Images are too dark (underexposed).	 The flash mode is set to ③ (off). The flash window is blocked. The subject is beyond the range of the flash. Adjust exposure compensation. Increase ISO sensitivity. The subject is backlit. Select Backlighting scene mode or set the flash mode setting to ⑤ (fill flash). 	32 11 119 36 66 22, 32
Images are too bright (overexposed).	Adjust exposure compensation.	36
Unexpected results when flash set to \$ (auto with red-eye reduction).	Use any scene mode other than Night portrait , and change the flash mode to any setting other than \$ (auto with red-eye reduction) and try taking the picture again.	32, 37
Skin tones are not softened.	In some shooting conditions, facial skin tones may not be softened. For images containing four or more faces, try using the Skin softening effect in Glamour retouch in the playback menu.	40 52
Saving images takes time.	It may take more time to save images in the following situations: • When the noise reduction function is in operation, such as when shooting in a dark environment • When the flash mode is set to \$ (auto with red-eye reduction) • When the skin softening function is applied while shooting • When using continuous shooting mode	- 33 40 65
Colored circles or light streaks appear in the monitor or images.	When shooting with backlighting or when a very strong light source (such as sunlight) is in the frame, colored circles or light streaks (ghosting) may occur. Change the position of the light source, or frame the image so that the light source does not enter the frame, and try again.	-

Playback Issues

Problem	Cause/Solution	ш
File cannot be played back.	This camera may not be able to play back images saved with another make or model of digital camera. This camera cannot play back movies recorded with another make or model of digital camera. This camera may not be able to play back data edited on a computer.	-
Cannot zoom in on image.	Playback zoom cannot be used with movies. For small images, the magnification rate displayed on the screen may not be compatible with the actual magnification rate. This camera may not be able to zoom in on images captured with another make or model of digital camera.	_
Cannot edit images.	Some images cannot be edited. Images that have already been edited may not be edited again. There is not enough free space on the memory card or in the internal memory. This camera is unable to edit images captured with other cameras. Editing functions used for images are not available for movies.	26, 49 - -
Images are not displayed on TV.	Video mode is not correctly set in the setup menu. The memory card contains no images. Remove the memory card to play back images in the internal memory.	59, 87 - 6
Nikon Transfer 2 does not start when the camera is connected to a computer.	The camera is off. The battery is exhausted. The USB cable is not correctly connected. The camera is not recognized by the computer. The computer is not set to start Nikon Transfer 2 automatically. For more information about Nikon Transfer 2, refer to help information contained in ViewNX-i.	- 88, 90 90, 97 - -

Problem	Cause/Solution	
The PictBridge startup screen is not displayed when the camera is connected to a printer.	With some PictBridge-compatible printers, the PictBridge startup screen may not be displayed and it may be impossible to print images when Auto is selected for Charge by computer in the setup menu. Set Charge by computer to Off and reconnect the camera to the printer.	59, 88
Images to be printed are not displayed.	The memory card contains no images. Remove the memory card to print images in the internal memory.	- 6
Cannot select paper size with the camera.	The camera cannot be used to select the paper size in the following situations, even when printing from a PictBridge-compatible printer. Use the printer to select the paper size. • The printer does not support the paper sizes specified by the camera. • The printer automatically selects the paper size.	-

File Names

Images or movies are assigned file names as follows.

File name: DSCN 0001.JPG

(1) (2) (3)

(1) Identifier	Not shown on the screen of the camera. DSCN: Original still images, movies SSCN: Small picture copies RSCN: Cropped copies FSCN: Images created by an image editing function other than crop and small picture
(2) File number	Assigned in ascending order, starting with "0001" and ending with "9999."
(3) Extension	Indicates file format. • JPG: Still images • .AVI: Movies

Optional Accessories

Battery charger	Battery Charger MH-66 It takes about 1 hour and 50 minutes to charge a fully exhausted battery.	
AC adapter	AC Adapter EH-62G (connect as shown) Make sure that the power connector cable is fully inserted in the power connector slot before inserting the AC adapter into the battery chamber. In addition, make sure that the power connector cable is fully inserted in the battery chamber slot before closing the battery-chamber/memory card slot cover. If part of the cable protrudes from the slots, the cover or cable may be damaged when the cover is closed.	
Audio video cable	Audio Video Cable EG-CP14	

Availability may vary with country or region.

See our website or brochures for the latest information.

Specifications

Nikon COOLPIX A100 Digital Camera

Type		Compact digital camera		
N	umber of effective pixels	20.1 million (Image processing may reduce the number of effective pixels.)		
In	nage sensor	¹ /2.3-in. type CCD; approx. 20.48 million total pixels		
Le	ens	NIKKOR lens with 5× optical zoom		
	Focal length	4.6–23.0 mm (angle of view equivalent to that of 26–130 mm lens in 35mm [135] format)		
	f/-number	f/3.2-6.5		
	Construction	6 elements in 5 groups		
D	igital zoom magnification	Up to 4× (angle of view equivalent to that of approx. 520 mm lens in 35mm [135] format)		
Vi	bration reduction	Electronic VR (movies)		
M	otion blur reduction	Electronic VR (still images)		
Autofocus (AF)		Contrast-detect AF		
Focus range		[W]: Approx. 50 cm (1 ft 8 in.)—∞, [T]: Approx. 80 cm (2 ft 8 in.)—∞ Macro mode: Approx. 10 cm (4 in.)—∞ (wideangle position) (All distances measured from center of front surface of lens)		
	Focus-area selection	Face priority, center, manual with 99 focus areas, subject tracking, target finding AF		
M	onitor	6.7 cm (2.7-in.), approx. 230k-dot, TFT LCD, and 5-level brightness adjustment		
	Frame coverage (shooting mode)	Approx. 98% horizontal and vertical (compared to actual picture)		
	Frame coverage (playback mode)	Approx. 98% horizontal and vertical (compared to actual picture)		

Storage		
Media		Internal memory (approx. 25 MB), SD/SDHC/SDXC memory card
	File system	DCF and Exif 2.3 compliant
	File formats	Still images: JPEG Movies: AVI (Motion-JPEG compliant)
	nage size nixels)	 20M (High) [5152 x 3864 ★] 20M [5152 x 3864] 10M [3648 x 2736] 4M [2272 x 1704] 2M [1600 x 1200] VGA [640 x 480] 16:9 (14M) [5120 x 2880] 1:1 [3864 x 3864]
ISO sensitivity (Standard output sensitivity)		ISO 80–1600 ISO 3200 (available when using Auto mode)
Exposure		
Metering mode		Matrix, center-weighted (digital zoom less than 2x), spot (digital zoom 2x or more)
	Exposure control	Programmed auto exposure and exposure compensation (-2.0 - +2.0 EV in steps of ¹ /3 EV)
Sł	nutter	Mechanical and CCD electronic shutter
	Speed	 1/2000–1 s 4 s (Fireworks show scene mode)
Aperture		Electromagnetic ND filter (-2.6 AV) selection
	Range	2 steps (f/3.2 and f/8 [W])
Se	elf-timer	Can be selected from 10 s and 2 s
FI	ash	
	Range (approx.) (ISO sensitivity: Auto)	[W]: 0.5–4.0 m (1 ft 8 in.–13 ft) [T]: 0.8–2.0 m (2 ft 8 in.–6 ft 6 in.)

TTL auto flash with monitor preflashes

Flash control

Interface		
USB connector	Hi-Speed USB Supports Direct Print (PictBridge) Also used as audio/video output connector (NTSC or PAL can be selected for video output.)	
Supported languages	Arabic, Bengali, Bulgarian, Chinese (Simplified and Traditional), Czech, Danish, Dutch, English, Finnish, French, German, Greek, Hindi, Hungarian, Indonesian, Italian, Japanese, Korean, Marathi, Norwegian, Persian, Polish, Portuguese (European and Brazilian), Romanian, Russian, Serbian, Spanish, Swedish, Tamil, Telugu, Thai, Turkish, Ukrainian, Vietnamese	
Power sources	One Rechargeable Li-ion Battery EN-EL19 (included) AC Adapter EH-62G (available separately)	
Charging time	Approx. 3 h (when using Charging AC Adapter EH-72P/EH-72PCH and when no charge remains)	
Battery life ¹		
Still images	Approx. 250 shots when using EN-EL19	
Movies (actual battery life for recording) ²	Approx. 1 h 5 min when using EN-EL19	
Tripod socket	1/4 (ISO 1222)	
Dimensions (W \times H \times D)	Approx. $94.5 \times 58.6 \times 19.8$ mm $(3.8 \times 2.4 \times 0.8$ in.) (excluding projections)	
Weight	Approx. 119 g (4.2 oz) (including battery and memory card)	

0	perating environment	
	Temperature	0°C-40°C (32°F-104°F)
	Humidity	85% or less (no condensation)

- Unless otherwise stated, all figures assume a fully-charged battery and an ambient temperature of 23 ±3°C (73.4 ±5.4°F) as specified by the Camera and Imaging Products Association (CIPA).
- Battery life may vary depending on conditions of use, such as the interval between shots or the length of time that menus and images are displayed.
- Individual movie files cannot exceed 2 GB in size or 29 minutes in length. Recording may end before this limit is reached if camera temperature becomes elevated.

Rechargeable Li-ion Battery EN-EL19

Туре	Rechargeable lithium-ion battery
Rated capacity	DC 3.7 V, 700 mAh
Operating temperature	0°C-40°C (32°F-104°F)
Dimensions (W \times H \times D)	Approx. $31.5 \times 39.5 \times 6 \text{ mm} (1.3 \times 1.6 \times 0.3 \text{ in.})$
Weight	Approx. 14.5 g (0.5 oz)

Charging AC Adapter EH-72P/EH-72PCH

Rated input	AC 100-240 V, 50/60 Hz, 0.07-0.04 A
Rated output	DC 5.0 V, 550 mA
Operating temperature	0°C-40°C (32°F-104°F)
Dimensions (W \times H \times D)	Approx. $55 \times 22 \times 54$ mm (2.2 \times 0.9 \times 2.2 in.) (excluding plug adapter) For Argentina: Approx. $55 \times 63 \times 59$ mm (2.2 \times 2.5 \times 2.4 in.) For India: Approx. $55 \times 63.5 \times 59$ mm For Korea: Approx. $55 \times 67 \times 59$ mm
Weight	Approx. 46 g (1.7 oz) (excluding plug adapter) For Argentina, India, and Korea: Approx. 71 g (2.6 oz)

The symbols on this product represent the following: \sim AC, == DC, \square Class II equipment (The construction of the product is double-insulated.)

- Nikon will not be held liable for any errors this manual may contain.
- The appearance of this product and its specifications are subject to change without notice.

Memory Cards That Can Be Used

The camera supports SD, SDHC, and SDXC memory cards.

- Memory cards with an SD Speed Class rating of 6 or faster are recommended for recording movies. When using a memory card with a lower Speed Class rating, movie recording may stop unexpectedly.
- If you use a card reader, make sure that it is compatible with your memory card.
- Contact the manufacturer for information on features, operation, and limitations on use.

Trademark Information

- Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries.
- Adobe, the Adobe logo, and Reader are either trademarks or registered trademarks of Adobe Systems Incorporated in the United States and/or other countries
- SDXC, SDHC, and SD Logos are trademarks of SD-3C, LLC.



- PictBridge is a trademark.
- All other trade names mentioned in this manual or the other documentation provided with your Nikon product are the trademarks or registered trademarks of their respective holders.

AVC Patent Portfolio License

This product is licensed under the AVC Patent Portfolio License for the personal and non-commercial use of a consumer to (i) encode video in compliance with the AVC standard ("AVC video") and/or (ii) decode AVC video that was encoded by a consumer engaged in a personal and non-commercial activity and/or was obtained from a video provider licensed to provide AVC video. No license is granted or shall be implied for any other use. Additional information may be obtained from MPEG LA, L.L.C. See http://www.mpegla.com.

FreeType License (FreeType2)

 Portions of this software are copyright © 2012 The FreeType Project (http://www.freetype.org). All rights reserved.

MIT License (HarfBuzz)

 Portions of this software are copyright © 2016 The HarfBuzz Project (http://www.freedesktop.org/wiki/Software/HarfBuzz). All rights reserved. Inday

IIIGEX	
Symbols	Auto off 12, 85
Scene auto selector mode	Auto with red-eye reduction 33
17, 1	19 Autofocus 57, 70, 77
Scene mode 17, 2	20 Autofocus mode 70, 77
Special effects mode 17, 2	27 B
Smart portrait mode 17, 2	
Auto mode 17, 3	Bo Battery 6, 7, 10, 12
▶ Playback mode 1	
List by date mode4	
Y Setup menu 59 , 7	8 Battery latch
T (Telephoto) 13, 1	
W (Wide-angle) 13, 1	Duttery level into leater minimum 14
Q Playback zoom 14 , 4	
Thumbnail playback 14, 4	-
9 Help	
Shooting mode button 2,	17 Brightness
Playback button 2, 1	4 Built-in microphone
● (►▼ movie-record) button	Button sound85
	IQ.
Apply selection button	2 Calandar Display
MENU Menu button 2, 5	Caleridai Dispiay 47
Delete button 2,	criarge by corributer oc
5 Flash mode 18, 3	Charge lamp
S Self-timer 18, 3	7, 00
Macro mode 18, 3	Charging AC Adapter 7, 12
Exposure compensation	C103e-up Wb 20, 2
18, 3	Cloudy
AE/AF-L	Compression ratio 6
Α	Computer91, 97
AC adapter 90, 1	Connector cover
AF area mode6	
AF assist	copyring irriages
Aperture value	
Audio video cable 91, 92, 1	
Auto flash 31, 32, 1	C1033 P10CC33 D
Auto manda 17 3	

<u>D</u>		Format memory cards	6, 86
Date and time9	9, 78	Formatting	
Date format9	9, 78	Full-frame playback	46
Date stamp	82	Full-time AF	
Daylight		Functions that cannot be	used
Daylight saving time 9, 10), 78	simultaneously	44
Delete		G	
Digital zoom 1 3	8,84	Glamour retouch	28, 52
Direct print	93	Н	
D-Lighting		н	20
Dusk/dawn 👛	20	High-contrast monochron	
Dynamic Fine Zoom	13		
E		_	27
 Editing images	. 49	<u> </u> Image mode	61
EH-72P/EH-72PCH	121	Image mode	
Electronic VR	83	Image review	
EN-EL19	121	Incandescent	
Exposure compensation	36	Internal memory	
Eyelet for camera strap	1	Internal memory indicator	
F		ISO sensitivity	
- Face detection	39	150 3C1131t1V1ty	00
Face priority		<u>L</u>	20
File names	116	Landscape	
Fill flash		Language	
Fireworks show 💸 20		Lens	
Firmware version		Lens cover	
Fixed range auto	. 66	List by date mode	40
Flash '	1, 32	M	
Flash lamp 2	2, 32	Macro mode	
Flash mode 32	2, 33	Memory card	
Flash off	33	Memory card slot	
Fluorescent	63	Monitor	
Focus	67	Monitor settings	
Focus area	39	Movie menu	
Focus indicator	3, 12	Movie options	
Focus lock		Movie playback	
Food 20), 22	Movie recording	
Format internal memory	. 86	Multi selector	2, 59

N		Red-eye correction	51
Night landscape 🖼 2	0, 21	Remaining movie record	ing time
Night portrait 🗷	20		55, 56
Nikon Transfer 2		Reset all	89
Nostalgic sepia SE	27	Rotate image	73
Number of exposures remainir		S	
10	0, 62	Scene mode	20
0		SD memory card	
<u>o</u> Optical zoom	13	Selective color 🧪	
Optional accessories		Self-timer	
D		Self-timer lamp	
<u>r.</u> Panorama assist playback	26	Setup menu	
Panorama assist 🔟 20		Shooting	
Paper size		Shooting menu	
Party/indoor 🎇 2		Shooting mode	
Pet portrait auto release		Shutter sound	85
Pet portrait %		Shutter speed	
Photo info		Shutter-release button	1
PictBridge9		Single	65
Playback		Single AF	
Playback menu 5'		Skin softening	40
Playback mode		Slide show	72
Playback zoom 14		Slow sync	33
Pop POP		Small picture	53
Portrait ½		Smart portrait menu	59, 71
 Power switch		Smart portrait mode	28
Power-on lamp		Smile timer	29
Preset manual		Snow 8	20
Pressing halfway		Soft SO	27
Print 91, 94		Sound settings	85
Printer9		Speaker	2
Protect		Special effects mode	
Q		Sports ধ	20, 21
<u> </u>	49	Strap	ii
Quick retouch		Subject tracking	
_	55	Sunset 🚢	20
<u>K</u> Rechargeable Li-ion battery	121	I	
necriargeable Li-1011 ballery	121	Target finding AF	41, 68
		-	

Televisions Thumbnail playback Time difference	
	14.47
Time difference	
	78
Time zone	10, 78
Time zone and date	9, 78
Toy camera effect 1 鼠 1	
Toy camera effect 2 2.	
Tripod socket	
U	,
<u>U</u> USB cable 7	91 93 97
USB/audio/video output	
_	07
Volume	58
<u>W</u>	
White balance	63
Wide-angle	13
	77
Wind noise reduction	77
Y Video mode ViewNX-i Volume	2 87 97

No reproduction in any form of this manual, in whole or in part (except for brief quotation in critical articles or reviews), may be made without written authorization from NIKON CORPORATION.