


Media Tower

Assembly Instructions - Please keep for future reference

875/4664



Dimensions

Width - 23.6cm

Depth - 20.1cm

Height - 97.6cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not use this item if any components are missing or damaged.

- Do not stand on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws,**

as this could damage the unit.
Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.


Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**


Please check you have all the panels listed below




1 Middle support
(16.7 x 11.8cm)




2 Shelf panel x 4
(16.7 x 11.8cm)



3 Top panel
(19.8 x 14.8cm)




4 Bottom panel
(23.5 x 19.8cm)




5 Right side panel
(13.1 x 94.5cm)

← Finished front edge →



6 Left side panel
(13.1 x 94.5cm)











7 Back panel
(19.5 x 97.2cm)

Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  40mm Screw x 12	B  20mm Dowel x 16	C  Nail x 17
D  14mm Screw x 1	E  (This screw is included in the bag of wall strap) Wall strap x 1  x 1	F  Wall plug x 1
G  Screw cover x 4		

Tools required



Phillips screwdriver
(medium & large)



Eye protection
(when using a
hammer or glue)




Small
hammer



Ruler/tape
measure

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fitting the unit


a: Use Screws **A** to fix the Middle support **1** onto the Right side panel **5** and Left side panel **6**.

a:




b: Use Screws **A** to fix the Top panel **3** onto the Right side panel **5** and Left side panel **6**.

b:



c: Use Screws **A** to fix the Bottom panel **4** onto the Right side panel **5** and Left side panel **6**.

c:



Use Screw covers **G** to cover the screw heads.

Assembly Instructions

Step 2




Fixing back panel

Attach back panel **7** to back of chest using nails **C**.



Important:

The cabinet **MUST** be 'square' when the back is attached.




Step 3

Attaching the shelves

a: Insert the Dowels **B** into the unit.

Ensure they are well fitted before inserting the shelves.

a:



Continued on next page.

Assembly Instructions

Step 3 - continued

b: Slide Shelves **2** into the unit.

Step 4

Fixing to wall

It is recommended that the media tower is fixed to a wall.

Fix Wall strap **E** to back of top panel using Screw **D**.

With help, move media tower into position.



Warning:

The media tower is heavy.

Lift with care.

Mark fixing hole on wall and remove media tower.

Drill a hole and insert Wall plug **F**.





Warning:

Before drilling, check wall for hidden pipes and cables.


Reposition media tower and fix wall strap using Screw **E**.

Assembly is complete.




b:

Finished front edge



Note: Wall plugs supplied are for solid wall only.

The correct type of fixing must be used for your wall, seek professional advice if in doubt



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.