

# morphy richards®

Instruction Manual - Please keep for future reference

## ROTISSERIE MINI OVEN



KWS1523X-F2UB

## CAUTION

Read all the instructions carefully before using and retain this for further reference.

The temperature of accessible surfaces may get hot when the appliance is operating especially the metal top area and the warming rack if any.

This appliance is not intended for use by young children and persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved by a person responsible for their safety. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

Keep the appliance and its cord out of reach of children less than 8 years.

Children should be supervised to ensure that they do not play with the appliance.

The appliance is not intended to be operated by means of an external timer or separate remote-control system.

# IMPORTANT SAFETY INSTRUCTIONS

When using electric appliances, basic safety precautions should always be followed, including the following:



1. Read all instructions before use
2. Do not touch hot surfaces. Use handle or knobs.
3. Close supervision is necessary when any appliance is used by or near children.
4. To protect against electric shock, do not immerse cord, plug, or any parts of the oven in water or other liquids.
5. Do not let cord hang over edge of table or counter, or touch hot surfaces.
6. Do not operate appliance with damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner, return the appliance to the nearest Authorized Service Center for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause hazard or injury.
8. Do not place on or near a hot gas or electric burner, or in a heated oven, or in a microwave oven.
9. When operating the oven, keep at least 12 cm of space on all sides of the oven to allow for adequate air circulation.
10. Unplug from outlet when not in use, or before cleaning. Let it to cool down before putting on or taking off parts, or before cleaning.
11. Do not cover CRUMB TRAY or any part of the oven with metal foil. This may cause overheating of the oven.
12. Extreme caution should be exercised when removing tray or disposing of hot grease or other hot liquids.
13. Do not clean the oven with metal scouring pads. Metal chippings would touch electrical parts, and endanger a risk of electric shock.
14. A fire may occur if the oven is covered by or placed near the flammable material, including curtains, draperies, walls, and the like, when in operation. Do not store any item on the oven during operation.
15. Extreme caution should be exercised when using containers constructed of anything other than metal or glass.
16. Do not place any of the following materials in the oven: cardboard, plastic, paper, or anything similar.
17. Do not store any materials, other than manufacturers recommended accessories, in this oven when not in use.
18. To disconnect, turn any control to "off", then remove plug from wall outlet. Always hold the plug, but never pull the cord.
19. Always wear protective, insulated oven mitts when inserting or removing items from the hot oven.
20. This appliance has a tempered, safety glass door. The glass is stronger than ordinary glass and more resistant to breakage. Avoid scratching door surface or nicking edges. If the door glass has a scratch or nick, contact the nearest Authorized Service Center for examination and repair.
21. Do not use outdoors.
22. Do not use appliance for other than intended use.
23. This appliance is for HOUSEHOLD USE ONLY.
24. The accessible surfaces are liable to get hot when the appliance is operating.
25. Glass Door cannot support goods in the fully open position.
26. The appliance is not intended to be controlled by an external timer or separate remote-control system
27. If the surface of the hotplate is cracked, switch off the appliance to avoid the possibility of electric shock. Return appliance to the nearest Authorized Service Center for repair.
28. For appliance with type Y attachment, if the supply cord is damaged, it must be replaced by the manufacturer, its services agent or similarly qualified persons in order to avoid a hazard.
29. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
30. Children should be supervised to ensure that they do not play with the appliance.
31. NOTE-This product may emit some odour/smoke when it is first used. This is due to lubricant on the elements burning off and is NORMAL. It will not continue following further use.








**SAVE THESE INSTRUCTIONS**

# CONTENTS

<b>Know Your Machine .....</b>	<b>3</b>
<b>Operation.....</b>	<b>4</b>
<b>Care and Cleaning.....</b>	<b>9</b>
<b>Specifications.....</b>	<b>10</b>

# KNOW YOUR MACHINE



# OPERATION



## IMPORTANT:

Please read the important safety instructions before use.




fig. 1

## Before First Use

### Preparing the Oven

- The oven, Grill Rack (J) Food Tray (K) are coated in oil that needs to be burnt off before using the oven.

1. Insert the Grill Rack (J) Food Tray (K) into the oven.

**See fig. 1.**

2. Set the Function dial (C) to  to turn the oven on, and then set the Oven Temperature dial (B) to maximum.

**See fig. 2.**

3. After a few minutes a small amount of smoke and the smell of burning oil should come from the oven. Open windows or doors, or use an extraction fan if you have one to remove the smell.

4. Once the oven has stopped smoking and the smell has gone, Set the Oven Temperature dial (B) to LOW and Time dial (D) to OFF.

**See fig. 2.**




fig. 2

# OPERATION (OVEN)

## Oven Operation

1. Plug into the mains socket.
2. The Oven Power Indicator (E) will light up.

**See fig. 4.**

3. Place the food on Grill Rack (J) or Food Tray (K) and close the Glass Door (F).

**See fig. 3.**

- a. Do not use any paper or plastic containers.
- b. Use food tray for any food that is small in size or likely to drip while cooking.
- c. Place the food evenly on the grill rack.

4. Set the Oven Temperature dial (B) to desired temperature.

5. Set the Function dial (C) to desired position:

- Upper Heating.
- Lower Heating.
- Upper Heating & Lower Heating.
- Upper Heating & Rotisserie.
- Upper Heating & Lower Heating & Rotisserie.

**See fig. 4.**

6. When food is ready, you should:
  - a. Use accessory handle (L) or oven gloves to remove hot food to avoid burning hands.

- b. Turn the Oven Temperature dial (B) to "LOW" position and Time dial (D) to OFF.

**See fig. 4.**

7. Remove the power plug from the socket when not in use.




fig. 3




fig. 4

# OPERATION (OVEN)

## Oven Cooking Guide:

1. Cooking time may vary depending on food ingredients, temperature, mass and portion. Please adjust the recipe cooking times accordingly.
2. If cooking for long periods, cooking times may need to be adjusted. It is advisable to check the food periodically.

**NOTE: For more accurate cooking times avoid removing food from oven for extended periods or frequently opening the oven door.**

3. Remove the Food Tray (K) from the oven and Grill Rack (J) if not required.  
**See fig. 3.**

4. Set the temperature of the oven by turning the Oven Temperature dial (B) to desired temperature .  
**See fig. 5.**

5. Allow a few minutes for the oven to heat up, then place the food in the oven using the Food Tray or grill rack.

**NOTE: Exercise caution when handling items from the oven, use oven gloves to avoid burning hands and place items removed onto heat resistant surfaces.**




fig. 5



# OPERATION (Grill)

## Operating the Grill

1. Use Door Handle (G) to open Glass Door (F).  
**See fig. 6.**
2. Remove Grill Rack (J).
3. Place Food Tray (K) into the slot nearest to the bottom of the oven, this will act as a drip tray.  
**See fig. 7.**
4. Turn the Function dial (C) to the upper heater setting  and temperature dial (B) to require temperature, i.e. 230 °C and wait a few minutes for the grill to heat up.
5. Place food to be grilled onto rack. Spread out evenly for better cooking results.
6. Attach Handle (L) to the rack and use the handle to insert the rack into the oven, sliding into the slots nearest to the top of the oven. Detach handle from rack as it may become very hot during cooking.
7. Rotisserie Handle: Allows you to pick up Rotisserie Spit.
8. Rotisserie Spit: Use to roast a variety of meats and poultry.

**See fig. 8.**

**NOTE: Make sure there is sufficient gap between the grill elements and the food to prevent burning.**



(O) Rotisserie Handle

(I) Rotisserie Spit




fig. 8

## OPERATION (Grill)

9. Use Rotisserie Spit (I) to roast a variety of meats and poultry., then use the rotisserie handle (O) pick up rotisserie spit (I) put into oven, and set up the function dial (C) to  or  and temperature dial (B) to “230” When the food had finished roast, use the rotisserie handle (O) take out the rotisserie spit (I) from the oven.

See fig. 9 .

10. Check food periodically - do not leave unattended, when food is ready, reattach handle and carefully remove rack from the oven, placing it on a heat resistant surface.

**NOTE: Clean the oven, grill rack and baking tray after use. Please ensure they are fully cooled before cleaning**




fig.9




fig.10

# CARE AND CLEANING



## NOTE:

**Always Unplug and allow to cool before cleaning**

- Wipe the surfaces with damp sponge or cloth.
- Do not use steel wool scouring pads, abrasive cleaners or scrape surfaces with metal utensils as this may damage the unit.
- Wash all accessories in hot water or in a dishwasher.
- Wipe the door and clean with a damp sponge. Dry with a paper or cloth towel.

**NOTE: Do not immerse in water or any liquid**




fig. 11

CE



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

# SPECIFICATIONS

## Technical Data

Power Consumption	220-240V~50Hz
Total Power	1500W
Electric Oven Capacity	23 Litres

## Connecting to Power

Check that the voltage marked on the product corresponds with your supply voltage. This product is fitted with a 13A plug complying with BS1363. If this plug is unsuitable or needs to be replaced, please note the following :

## Plug Replacement

If you need to replace the fitted plug.



### WARNING :

Never connect live or neutral wires to the earth terminal of the plug. Only fit an approved 13 Amp BS1363/A plug and the correct rated fuse. If in doubt, consult a qualified electrician.

This unit is a Class 1 Appliance and must be fitted with an Earthed Plug fitted with a 13A fuse.

The wires in this mains lead are coloured as follows:


Yellow & Green-Earth

Blue-Neutral

Brown-Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows:

The wire which is Coloured Yellow & Green must be connected to the terminal which is marked E or coloured Yellow or Green. The wire which is coloured blue must be connected to the terminal which is marked with N or coloured blue. The wire which is coloured brown must be connected to the terminal which is marked L or coloured brown. Always ensure that the plug cord grip is fastened correctly. If a 13A (BS1363) fused plug is used it must be fitted with a 13A fuse conforming to BS1362 and be ASTA approved. If in doubt contact a qualified electrician.





## PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



Year

This product is guaranteed for twelve months from the date of original purchase.

Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd  
489 - 499 Avebury Boulevard  
Central Milton Keynes  
MK9 2NW