


Vintage Shelf

Assembly Instructions - Please keep for future reference

338/8293



Dimensions

Width - 80cm

Depth - 20cm

Height - 18cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**

Argos = 03456 400800



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



power drill is set on a low torque setting.

- To reduce the likelihood of damaging your product please ensure that your

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Handy Hint

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 03456 400800**

Please check you have all the panels listed below



1 Shelf (80x20cm)








2 Side Panel x 2
(18x16.5cm)

Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<p>A</p>  <p>Wooden Dowel x 4</p>	<p>B</p>  <p>32mm Screw x 4</p>	<p>C</p>  <p>38mm Wall Screw x 2</p>
<p>D</p>  <p>Wall plug (for solid walls only) x 2</p>	<p>E</p>  <p>Paper template x 1</p>	


Tools required




Phillips screwdriver
(medium)



Drill



Small
hammer




6mm drill bit (which
is suitable for the wall
plugs supplied)



Eye protection
(when using a
hammer)

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Attaching side panel

Attach side panel **2** to the shelf **1** with wooden dowel **A** and screw **B**.



Step 2

Using paper template

Stick the paper template **E** onto the wall.

Fixing to wall

Drill 6mm holes for the wall plugs **D** onto paper template **E**.



Warning:


Before drilling, check wall for hidden pipes and cables.

Insert the wall plugs **D** into the drilled holes, and fix the wall screws **C** into the wall plugs **D**. Fit the unit to the wall through the metal hanger supports shown.



Warning:

The maximum load allowed on the unit is 10Kg.



If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 03456 400800

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.