

BUSH

Instruction manual

411009





You'll soon be enjoying your new Outdoor DAB Radio.

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.



Help and Guidance

We're here to help you get the most from your Outdoor DAB Radio. Should you require any guidance, a simple solution can often be found online at:

www.argos-support.co.uk

If you still require further assistance, call one of our experts on **0345 600 3021**.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

BUSH



Contents

1 Safety information

Safety information 6

2 Getting to know your Outdoor DAB Radio

Ready? Let's begin 12

Connecting the antenna 16

Power connection 16

Inserting batteries (optional) 16

Initial set-up 17

Adjusting the volume 17

Time and date 17

Change the mode 18

Connect to a Bluetooth device 18

USB charging 19

3 Using your Outdoor DAB Radio

Radio antenna 22

DAB Radio mode 22

Changing DAB stations 22

Scanning for DAB stations 22

Prune DAB stations 23

Storing a DAB station preset 23

Tune to a DAB station preset 23

DAB display information 24

Dynamic range control (DRC) 25

FM Radio mode 26

Tuning to an FM station 26

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

Contents

| | |
|-------------------------------|----|
| Changing the Scan setting | 26 |
| Audio mode | 27 |
| Storing an FM station preset | 27 |
| Tune to an FM station preset | 28 |
| FM display information | 28 |
| Bluetooth mode | 29 |
| Connect to a Bluetooth device | 29 |
| Setting the alarm | 31 |
| Stop the Alarm | 32 |
| Snooze | 32 |
| Turn off the Alarm | 33 |
| Sleep timer | 33 |
| Cancel the Sleep timer | 33 |
| Display backlight timeout | 34 |
| Display language | 34 |
| Software version | 35 |
| Factory reset | 35 |

4 Other information

| | |
|-------------------------|----|
| Technical specification | 38 |
|-------------------------|----|

5 Product support

| | |
|---------------------|----|
| Troubleshooting | 42 |
| Help and assistance | 44 |
| Disposal | 45 |
| Guarantee | 46 |

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

This page is left intentionally blank

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021




This page is left intentionally blank



Safety information

1





Safety information

Important - Please read these instructions fully before installing or operating

Power source

- Only use the power supply that came with the product. Using an unauthorised power supply will invalidate your guarantee and may irrecoverably damage the product.
- Disconnect your Radio from the mains power supply during thunderstorms.
- Always check that you have completely switched off your Radio, before you change or disconnect the power supply.
- Where the mains power plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- If the Radio will not be used for a long period of time, make sure that all of the batteries are removed from the battery compartment and the mains power is unplugged.
- Only use recommended batteries or those of the same or equivalent type.
- Do not mix old and new batteries or batteries of different types.
- Batteries are to be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Remove the batteries from the Radio if they will not be used for an extended period of time.
- Never throw batteries in a fire or attempt to open the outer casing.
- Batteries are harmful if swallowed, so keep away from young children.
- CAUTION: Danger of explosion if batteries are incorrectly replaced. Replace only with the same or equivalent type.

Moisture and water

This product has been designed and tested to meet the IPX4 standard and is safe to use in a light shower of rain, where it is likely to be splashed with water. It has not been designed to be fully immersed in water as this will result in permanent damage to the product circuitry.

- Do not leave it in low temperatures as moisture can form inside the product, which may damage the circuit board.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**



Safety information

Important - Please read these instructions fully before installing or operating

Heat sources and flames

Do not leave it in high temperatures as electronic devices and plastic parts may warp in heat.

Ventilation

Do not block or cover slots, holes or openings on the product by placing on soft furnishings such as carpets, rugs or beds as these are provided for functionality and/or ventilation to ensure safe operation of the product.

Positioning the Outdoor DAB Radio

It is important that you consider carefully in advance where your Radio will be situated and make sure that it is:

- on a flat and stable surface.
- within 1.4 metres of a power socket (if using mains power). Please ensure that the mains power lead is not a trip hazard.
- at least 1 metre away from other electrical appliances to avoid interference.
- where it will be in range of the connected or 'paired' bluetooth device (e.g. iPod/iPhone/iPad/Android/other phone/computer, which is about 10 metres or less (33 feet or less) in line of sight.
- where there is enough height for the radio antenna.
- Never place your Radio directly onto antique or polished surfaces.



Caution

To avoid possible hearing damage, do not listen to this radio at high volume levels for long periods of time. Always keep the volume within reasonable limits.



Safety information

Important - Please read these instructions fully before installing or operating

General safety information

- Keep the product and all its parts out of reach of small children.
- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Do not attempt to open the product. This product does not contain any user serviceable parts. Unauthorised handling of the device may damage it and will void your warranty.
- Do not use your Radio near emergency/intensive care medical equipment; if you have a pacemaker fitted or during an electrical storm.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

This page is left intentionally blank

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021




This page is left intentionally blank



Getting to know your Outdoor DAB Radio

2





Getting to know your Outdoor DAB Radio

You'll be up and running in no time

Ready? Let's begin...

Please read these instructions carefully. They contain important information which will help you get the best from your product and ensure safe and correct installation and operation.

If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Getting to know your Outdoor DAB Radio

You'll be up and running in no time




Fig 1.

- | | |
|--|---------------------------------------|
| 1. Volume jog control - rotate and release | 10. Snooze |
| 2. Radio antenna | 11. Scan for radio stations |
| 3. Power on/standby | 12. Skip back |
| 4. Backlit display | 13. Skip forward |
| 5. Mode (DAB/FM/Bluetooth) | 14. Battery compartment |
| 6. Tune jog control - rotate and release | 15. Power on/off switch (under cover) |
| 7. Enter/Play pause | 16. Rubber cover |
| 8. Menu/Info | 17. USB charging (under cover) |
| 9. Radio presets | 18. Power lead socket (under cover) |

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

Getting to know your Outdoor DAB Radio

You'll be up and running in no time

Connecting the antenna


Screw the separate radio antenna into the top of the radio, just above the volume control.

Power connection

1. Connect the mains power lead into the socket, underneath the rubber cover on the back of the Radio,
2. Plug the power adaptor into the mains power wall socket and switch on.
3. Press and release the On/Off power switch, underneath the rubber cover on the back of the radio. The product display will light up and your radio will now be in Standby mode.

Inserting batteries (optional)

1. Before installing the batteries (not included) please ensure that the Radio is switched off, using the On/Off power switch, underneath the rubber cover on the back of the radio and has been unplugged from the mains power supply.
2. On the back of the Radio, turn the battery compartment catch to 'Open' and remove the battery cover.
3. Insert 4 x 1.5V C-size (also known as LR-14) batteries, making sure to note the '+' and '-' markings and position the batteries the correct way around.



4. Replace the battery cover and turn the battery compartment catch to 'Close'.

Note: For battery operation, please ensure that the mains power is switched off and remove the mains power plug from the socket, underneath the rubber cover, on the back of the Radio.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Getting to know your Outdoor DAB Radio

You'll be up and running in no time

Initial set-up

1. Press and release the Standby button on the top of your radio. Your radio will switch on and begin an automatic scan for DAB stations. A progress bar will show the progress of the scan and the number of stations found during the scan will also be displayed.
2. When the scan is complete your radio will select the first available station and begin to play. Stations are listed in numerical and then alphabetical order by default.

Note: The DAB radio station list is stored in the memory and so the next time you switch your radio on, the station search does not take place. It is possible to scan manually for stations by pressing and releasing the Scan button.

3. Turn and release the Tune control to scroll through the available stations in the station list.
4. When the station that you would like to listen is displayed, press and release the Enter button to select. There will be a short delay whilst your radio tunes to your selected station.

Adjusting the volume

The volume is a 'jog' control. Please turn it to the 'stop' and then release. To progressively increase or decrease the volume, turn it to the 'stop' and then hold.

Turn clockwise to increase the volume.

Turn anti-clockwise to decrease the volume.

Check the display, which will confirm the volume setting.

Time and date

The first time you listen to DAB radio, the time and date of your product will be synchronised automatically to that broadcast by the DAB service in 24 hour mode; which is in line with daylight saving, so there is no need to set the time and date manually.

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

Getting to know your Outdoor DAB Radio

You'll be up and running in no time

If you do wish to set the time and date manually, turn on the radio and follow the steps below:

1. Press and hold the Menu/Info button until <Full scan> is displayed.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Time>. Press and release the Enter button. <Set Time/Date> is displayed. Press and release the Enter button.
4. Set time is displayed and the hour digits will flash. Use the Tune control to scroll to the correct hour. Press the Enter button.
5. The minutes will now flash. Use the Tune control to scroll to the correct minutes. Press the Enter button.
6. Set date is displayed and the day will flash. Use the Tune control, together with the Enter button, to select and confirm the day, month and year, using the same method as you used to set the time.

When you confirm the correct date. 'Time Saved' is displayed and the display returns to <Set Time/Date>.

You can now use the Tune control to scroll and the Enter button to select, as you did to set the time and date to change the settings for:

12/24 hour clock display. The date format, DD-MM-YYYY or MM-DD-YYYY and to auto update the time from the DAB signal, FM signal, DAB or FM signal or no update.

Change the mode

Press and release the Mode button to change between DAB, FM and Bluetooth modes. Please check the display, which will confirm the mode.

Connect to a Bluetooth device

Check that your Radio is in Bluetooth mode. If you are not already in Bluetooth mode, press and release the Mode button until you are in Bluetooth mode (check the display). 'Searching...' will flash in the display.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Getting to know your Outdoor DAB Radio

You'll be up and running in no time

In Bluetooth (BT) Mode:

1. 'Searching...' will flash in the display.
2. On the device that you would like to connect to your Radio via Bluetooth (e.g. iPhone/iPad/Android/other phone/Tablet/Computer), turn on Bluetooth connectivity and ensure that it is 'discoverable'.

Note: If necessary, refer to the instructions for your device to add or set up Bluetooth.

3. Select to 'Add new device', if necessary.

Note: Some products will automatically search for a new device and so the 'Add new device' option is not available.

4. When found, your Radio will be displayed as 'BUSH OUTDOOR'. Select the device name to begin pairing.
5. When pairing is complete 'Search...' will stop flashing in the display, Connected will be displayed and a short tone will sound.
6. Now that you have paired your device with the Radio, it will connect to it when it is within range, which is about 10 metres or less (33 feet or less), line of sight.
7. Your device will remain paired with the Radio unless you decide to disconnect or 'unpair' it.

Note: You can press and hold the Enter button for 3 seconds, to unpair and pair your connected device.

USB charging

On the back of your radio, under the rubber cover, you will find a USB socket which can charge devices that need a USB 5V 500mA supply, such as mobile phones.

Using a USB cable, connect the device that you wish to charge and check the display.

Note: Your radio must be connected to mains power to be able to charge devices via the USB charging socket.

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021




This page is left intentionally blank



Using your Outdoor DAB Radio

3



Using your Outdoor DAB Radio

Let's get started

Radio antenna

Before you use the radio, you must first screw the separate radio antenna into the top of the radio, just above the volume control.

DAB Radio mode

Check that your Radio is in DAB mode. If you are not already in DAB mode, press and release the Mode button until you are in DAB mode (check the display).

The first time you use the Radio or if the station list is empty, your radio will automatically begin to scan for DAB radio stations. A progress bar will show the progress of the scan and the number of stations found during the scan will also be displayed.

If you were listening to a DAB station when you switched the radio off, then this station will automatically be selected when you switch the radio back on.

Changing DAB stations

1. Turn and release the Tune control to scroll through the available stations.
2. When the station that you would like to listen to is displayed, press the Enter button to select it. There will be a short delay whilst your radio tunes to your selected station.

Scanning for DAB stations

With DAB radio, additional stations and services regularly become available so it's a good idea to carry out a manual scan every now and then to make sure that you have the most up to date station listing stored within the memory of your Radio. If you have moved your Radio to another location, e.g.: if you go on holiday, then it's also a good idea to carry out a manual scan.

In DAB mode:

1. Press and release the Scan button to begin a search for stations. The display will change to 'Scanning...'. A progress bar will show the progress of the scan and the number of stations found during the scan will also be displayed.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Prune DAB stations

You can remove the DAB stations in the station list that cannot be received in your area. These are listed with a '?' prefix.

In DAB mode:

1. Press and hold the Menu/Info button until <Full scan> is displayed
2. Use the Tune control to scroll to <Prune>. Press and release the Enter button.
3. Prune? <No> Yes is displayed. Use the Tune control to scroll to Yes. Press and release the Enter button to confirm and prune the station list. Stations with a '?' prefix will now no longer be displayed.

Storing a DAB station preset

Your Radio can store up to 10 DAB radio stations in its preset memories for instant access to your favourite stations.

1. Tune the Radio to the DAB radio station that you wish to preset.
2. Press and hold the Preset button for approximately 2 seconds until Preset Store <1:(Empty)> is displayed.
3. Use the Tune control to move to the preset location that you would like to store the radio station to (1-10).
4. Press and release the Enter button, the display will confirm Preset X stored, where 'X' is the number of the preset (1-10).

Note: If there is already an existing DAB station stored under a preset, it will be over written when you store the new station.

Tune to a DAB station preset

In DAB mode:

1. Press and release the Preset button. Preset Recall <1:> is displayed together with the name or frequency of the station stored there, or (Empty) if no previous station has been stored.

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

Using your Outdoor DAB Radio

Let's get started

2. Use the Tune control to move to the Preset location and station that you would like to listen to (1-10).
3. Press and release the Enter button. The radio will instantly tune to that station and begin to play.

Note: If no DAB station has been stored under the preset button, 'Preset Empty' will be displayed, then the radio will revert to the previously selected radio station.

DAB display information

When listening to a DAB station you can change the information that will appear on the display. There are several different types of information that are sent by the broadcaster.

Dynamic Label Segment (DLS) - this is scrolling text information supplied by the broadcaster. Information could be the name of an artist or music title, DJ's name, contact details for the radio station etc.

Signal Strength - An empty will appear on the display to indicate the minimum signal strength for acceptable listening. The row of solid rectangles indicate the actual signal strength that you are receiving. The stronger the signal, the further to the right the row of solid rectangles will be.

Program Type (PTY) - such as 'Rock', 'Pop', 'Talk' or 'News'

Multiplex Name - displays the broadcasting area and collection of radio stations on this frequency e.g.: BBC National DAB, Digital 1 Network.

Channel and Frequency - e.g.: 12B 225.648 MHz

Signal error - This is displayed as a number between 0-99. It would not be possible to satisfactorily listen to a radio station with a signal error rate of 30 or above. Try adjusting the aerial or relocating your radio to improve reception.

Signal information - The data rate at which the signal is being transmitted.

Time and date - supplied by the broadcaster.

1. Repeatedly press and release the Menu/Info button to cycle through the different information options.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Dynamic range control (DRC)

In DAB mode:

The dynamic range for each radio programme is set by the broadcaster for each radio station and may be different for the types of programme broadcast, such as pop or classical music or a chat show. The dynamic range control signal is transmitted in parallel with the audio signal for each programme and with your radio you can use this control signal to expand or compress the dynamic range (the difference between the loudest and quietest sounds) of the reproduced audio signal. Changing the dynamic range can affect the 'loudness' and/or 'quality of sound' of the programme that you hear so that it will be more suited to your listening conditions and your own personal listening requirements. e.g. in a noisy environment, where quiet sounds might be swamped, setting the compression to maximum will 'boost' the quiet sounds, whilst keeping the loudest sounds at their original level.

There are 3 levels of compression:

DRC off - no compression. This is the default setting.

DRC low - medium compression.

DRC high - maximum compression.

1. Press and hold the Menu/Info button until <Full scan> is displayed.
2. Use the Tune control to scroll to <DRC>. Press and release the Enter button.
The current DRC setting will have an '*' next to it.
3. Use the Tune control to scroll through the options and press and release the Enter button to confirm.

Using your Outdoor DAB Radio

Let's get started

FM Radio mode

If you are not already in FM mode, press and release the Mode button to go to FM mode (check the display).

If you were listening to an FM station when you switched the Radio off then this station will be automatically selected when you switch the Radio back on.

Tuning to an FM station

Press and release the Scan button to scan up the frequency band. Use the Tune control to fine tune each frequency in 0.05MHz steps.

Note: If reception is still poor try moving the radio to another location.

Changing the Scan setting

In FM mode:

1. Press and hold the Menu/Info button until FM <Scan setting> is displayed. Press and release the Enter button. The current Scan setting will have an '*' in the top right of the display.

There are two different options to choose from:

Strong stations: The scan will only stop when a strong signal strength is received which should also result in a better audio quality. It is possible that the station you are scanning for may be missed using this option.

All stations: The scan will stop for every station it receives, even if the signal strength is poor.

2. Use the Tune control to choose from the two options available and press and release the Enter button to confirm.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Audio mode

The radio will automatically switch between Stereo and Mono, depending on the quality of the signal being received but you can override this function and manually switch between Stereo and Mono.

1. Press and hold the Menu/Info button until FM <Scan setting> is displayed.
2. Use the Tune control to scroll to <Audio setting>. Press and release the Enter button.

There are now two different options of 'Forced mono' and 'Stereo allowed' and the current setting will have an '*' in the top right of the display.

3. Use the Tune control to choose from the two options available. Press and release the Enter button to confirm.

Storing an FM station preset

Your Radio can store up to 10 FM radio stations in its preset memories for instant access to your favourite stations.

1. Tune the Radio to the FM radio station that you wish to preset.
2. Press and hold the Preset button for approximately 2 seconds until Preset Store <1:(Empty)> is displayed.
3. Use the Tune control to move to the preset location that you would like to store the radio station to (1-10).
4. Press and release the Enter button, the display will confirm Preset X stored, where 'X' is the number of the preset (1-10).

Note: If there is already an existing FM station stored under a preset, it will be overwritten when you store the new station.

Using your Outdoor DAB Radio

Let's get started

Tune to an FM station preset

In FM mode:

1. Press and release the Preset button. Preset Recall <1:> is displayed together with the name or frequency of the station stored there, or (Empty) if no previous station has been stored.
2. Use the Tune control to move to the Preset location and station that you would like to listen to (1-10).
3. Press and release the Enter button. The radio will instantly tune to that station and begin to play.

Note: If no FM station has been stored under the preset button, Preset Empty will be displayed, then the radio will revert to the previously selected radio station.

FM display information

When listening to an FM station you can change the information that will appear on the second line of the display.

Radiotext (RT) - This is scrolling text information supplied by the broadcaster. Information could be the name of an artist or music title, DJ's name, contact details for the radio station etc.

Program Type (PTY) - Such as 'Rock', 'Pop', 'Talk' or 'News'

Station name or frequency - Such as BBC R4 or 93.30MHz

Audio mode - Stereo or Mono

Time and date - Supplied by the broadcaster.

1. Repeatedly press and release the Menu/Info button to cycle through the different information options.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Bluetooth mode

Check that your Radio is in Bluetooth mode. If you are not already in Bluetooth mode, press and release the Mode button until you are in Bluetooth mode (check the display). 'Searching...' will flash in the display.

Connect to a Bluetooth device

In Bluetooth (BT) Mode:

1. 'Searching...' will flash in the display.
2. On the device that you would like to connect to your Radio via Bluetooth (e.g. iPhone/iPad/Android/other phone/Tablet/Computer), turn on Bluetooth connectivity and ensure that it is 'discoverable'.

Note: If necessary, refer to the instructions for your device to add or set up Bluetooth.

3. Select to 'Add new device', if necessary.

Note: Some products will automatically search for a new device and so the 'Add new device' option is not available.

4. When found, your Radio will be displayed as 'BUSH OUTDOOR'. Select the device name to begin pairing.
5. When pairing is complete 'Search...' will stop flashing in the display, Connected will be displayed and a short tone will sound.
6. Now that you have paired your device with the Radio, it will connect to it when it is within range, which is about 10 metres or less (33 feet or less), line of sight.
7. Your device will remain paired with the Radio unless you decide to disconnect or 'unpair' it.

Note: You can press and hold the Enter button for 3 seconds, to unpair and pair your connected device.

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

Using your Outdoor DAB Radio

Let's get started

Listening to Music/Audio using Bluetooth

In Bluetooth mode:

1. Select and start the music or audio that you wish to listen to on your paired Bluetooth device, it will now be heard through the radio speakers. Adjust the volume on the connected device and/or your radio

Note: If your previously paired device is within range but does not automatically connect, go to the Bluetooth connectivity settings on your device and select BUSH OUTDOOR to reconnect.

2. You can use the controls on your paired Bluetooth device as well as those on your radio.

Controls available on your Radio:

- Volume:
Turn and release the volume control clockwise to increase sound and anti-clockwise to decrease sound.
- Play/Pause:
Press and release to play/pause.
Press and hold for 3 seconds to unpair and pair the current connected device.
- Skip back:
⏮ Press and release to skip back to the previous track.
- Skip forward:
⏭ Press and release to skip forward to the next track.

Note: If you do not use your radio for approximately 15 minutes and no audio signal is received, it will automatically go to Standby mode. Press and release the Standby button to switch the radio back on.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Setting the alarm

Note: Check that the radio has the correct time and date before you set an alarm.

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options..
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Alarm 1> or <Alarm 2> as required. Press and release the Enter button.
4. Alarm 1 (or 2) Setup is displayed. Press and release the Enter button.
5. Alarm 1 (or 2) Wizard On time is displayed and the hour digits for the alarm will flash.
6. Use the Tune control to scroll to the hour for the alarm and press and release the Enter button.
7. The minutes will now flash. Use the Tune control to scroll to the minutes for the alarm and press and release the Enter button. The duration time will now flash.
8. Use the Tune control to scroll to the duration for the alarm. You can choose from 15, 30, 45, 60 and 90 minutes. Press and release the Enter button. The source for the alarm will now flash.
9. Use the Tune control to scroll to the sound source for the alarm. You can choose from Buzzer, DAB or FM. Press and release the Enter button.

Note: If you select DAB or FM radio for the alarm source, 'Last listened' will flash in the display. Press the Enter button and the last listened to radio station in DAB or FM, as appropriate, will be used for your alarm.

10. Use the 'Tune/Select' rotary control to scroll to the frequency for the alarm. You can choose from Daily, Once, Weekends or Weekdays. Press and release the Enter button.

Note: If you select 'Once', you will then be prompted to set the date for your alarm.

Using your Outdoor DAB Radio

Let's get started

11. Use the Tune control to set the volume for your alarm. Press and release the Enter button.

Note: Remember to set the alarm radio volume to one that will wake you. The alarm volume will increase progressively until it reaches the alarm volume you have set.

12. Alarm 1 Wizard is displayed again, together with Alarm Off (or On). Use the Tune control to choose Alarm On or Off and press and release the Enter button to confirm. Alarm Saved is displayed.
13. A bell symbol in the top right of the radio display, together with the digit '1' or '2' as appropriate, will confirm that an alarm has been set.

Note: If the time is not set or has failed to update from the radio signal, Time is not set will be displayed when you try to set the alarm. The radio will then prompt you to set the time. An alarm can only be set after the time has been set.

Stop the Alarm

When the alarm sounds, press and release the Standby button, Alarm off is displayed. Alternatively, you can press and release the Snooze button (see Snooze function below).

Note: If you press the Standby button to stop the alarm, the alarm symbol will remain in the display and the alarm will sound again at the same time the next day, unless it was set for 'Once' only.

Snooze

When the alarm sounds you can press and release the Snooze button. Snooze 5 minutes will be displayed, followed by the snooze time countdown, until the alarm sounds again.

Turn off the Alarm

Follow the steps for 'Setting an Alarm' and select 'Off' in step 12.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

Sleep timer

You can set your radio to turn off automatically using the sleep timer. You can choose from Sleep off, 15, 30, 45, 60 and 90 minutes.

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Sleep>. Press and release the Enter button.
4. Use the Tune control to scroll through the available options. Stop when the sleep time you would like is displayed and press and release the Enter button. <Sleep> will be displayed.
5. The sleep time minutes that you have selected will be displayed on the top line of the radio display and will countdown until the radio switches off.

Cancel the Sleep timer

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Sleep>. Press and release the Enter button.
4. Use the Tune control to scroll to Sleep off. Press and release the Enter button. <Sleep> will be displayed.

Display backlight timeout

You can adjust the display backlight timeout. Options of permanently On, 10, 20, 30, 45, 60, 90, 120, and 180 seconds are available. An '*' will be displayed next to the current

Using your Outdoor DAB Radio

Let's get started

setting.

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Backlight>. Press and release the Enter button.
4. <Timeout> is displayed. Press and release the Enter button. Use the Tune control to scroll through the available backlight timeout options of On, 10, 20, 30, 45, 60, 90, 120 or 180 seconds. Stop when the backlight timeout you would like is displayed and press and release the Enter button. <Timeout> will be displayed.

You can now use the Tune control to scroll and the Enter button to select, as you did to set the Backlight timeout, to change the settings for the backlight brightness for the <Dim level> and <On level>. There are 3 options available, High, Medium and Low.

Display language

You can change the display language of your radio, there are 4 options available; English, French, German and Italian. An '*' will be displayed next to the current setting.

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Language>. Press and release the Enter button.
4. Use the Tune control to scroll to the language you would like. Press and release the Enter button to confirm.

Software version

You can check the software version of your radio.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Outdoor DAB Radio

Let's get started

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <SW Version>. Press and release the Enter button.

The software version will be displayed and you may wish to make a note of it here:

.....

Factory reset

You can reset your radio and restore all of the original factory settings.

Note: If you reset your radio all of your stored station presets will be deleted.

With your radio switched on (not in Standby mode):

1. Press and hold the Menu/Info button to enter the menu options.
2. Use the Tune control to scroll to <System>. Press and release the Enter button.
3. Use the Tune control to scroll to <Factory reset>. Press and release the Enter button. Factory Reset? <No> Yes will be displayed.
4. Use the Tune control to scroll to <Yes>. Press and release the Enter button.
5. Restarting... will be displayed. After a few seconds the display will change to Welcome to Digital Radio and will then go to Standby mode. When you next power on your radio from Standby mode, it will begin an automatic scan for DAB stations. A progress bar will show the progress of the scan and the number of stations found during the scan will also be displayed. When the scan is complete your radio will select the first available station and begin to play. Stations are listed in numerical and then alphabetical order by default.




This page is left intentionally blank



Other information

4



Other information

Helpful technical information

Technical specification

| | |
|-------------------------|---|
| Power adaptor: | Output DC 5.9V 1A Input AC 100-240V 50/60Hz 0.2A |
| Batteries: | 4 x 1.5V C size (LR14) (Optional, not supplied) |
| Audio output: | 2 x 1.5W RMS |
| USB socket: | 5V 500mA |
| Water resistance level: | IPX4 (protected against splashing water) |
| Frequency range: | |
| DAB: | Band III, 174 MHz to 240 MHz |
| FM: | 87.5 MHz to 108 MHz |
| Bluetooth: | 2.4GHz-2.480GHz |
| Bluetooth version: | 2.1 |
| Pairing name: | BUSH OUTDOOR |
| Profiles | HFPV1.5, A2DPV1.2, AVRCPV1.4, HSP1.2, GAVDP1.2, IOP |

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

This page is left intentionally blank

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021




This page is left intentionally blank



Product support

5



Product support

Help is always at hand

Troubleshooting

No sound / power:

Adjust the volume.

Check that the mains power wall socket is switched on and that your radio is not in Standby mode.

If you are using a Bluetooth connected device, increase the volume on the secondary device and on your radio.

If you have batteries fitted, they may be exhausted and need to be replaced. Please use only good quality C size batteries.

Radio reception is poor:

Make sure that you connect the radio antenna.

Retune for radio stations, see pages 22 and 26.

Try moving your radio to another location to see if reception improves.

Check that you do not have other electrical equipment too close to your Radio, causing interference.

Visit www.digitalradionow.com for information about DAB reception in your area.

Unable to pair with a Bluetooth device:

Check that you are in Bluetooth mode.

Ensure that you are within range of the radio for Bluetooth functionality, 10 metres or less (33 feet or less).

Move the radio and Bluetooth device away from other Bluetooth devices/electrical equipment.

If possible, turn off other nearby Bluetooth devices or disable their Bluetooth functionality.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support

Help is always at hand

The function buttons do not respond:

- Check that the mains power lead is connected at the back of your radio and the mains power wall socket is switched on. Press and release the Standby button.
- Check that you are trying to use the function buttons for the mode that you are in. (Play/pause, Skip forward and Skip back will only work in Bluetooth mode).
- If you are using batteries, they may be exhausted and need to be replaced.
- Unplug the mains power and remove the batteries. Leave the radio for 3 minutes and then reconnect the power.
- Try a reset to factory defaults. See page 35.

Note: All of your settings, including the radio station list and any presets will be deleted when you reset the Radio.

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your Outdoor DAB Radio is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions or online at www.argos-support.co.uk

If you still require further assistance, call one of our experts on **0345 600 3021***. To help give us give you a fast and efficient service please have the following information ready:

Model Ref.

Serial number

You can find these on the rating plate - a small information panel (usually a sticker or metal plate) on the rear of your product.

Date of purchase

This will be shown on your receipt

Local call rates applies*

Lines open 8am-7pm Monday to Saturday and 10am-4pm Sunday.

*Calls to Argos enquiry lines may attract a charge and set up fee from residential lines depending on your call plan/tariff. Mobile and other providers costs may vary, see www.bt.com/pricing for details.

For security and training purposes, telephone calls to and from customer service centres may be recorded and monitored. Calls from Republic of Ireland will attract international call charges.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support

Help is always at hand

Disposal



- This product should not be treated as normal household waste and it should be recycled. Please take it to your nearest collection facility or for further details contact your local council or visit www.recycle-more.co.uk
- Batteries contain substances that may be harmful to the environment and human health. Keep out of the reach of children and seek immediate medical help if swallowed.
- Batteries should not be disposed of in the normal household waste but taken to appropriate local recycling facilities, where and when these are available.
- Never throw batteries in a fire or attempt to open the outer casing

Product support

Help is always at hand

BUSH

Call us now and activate your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bushregistration.co.uk

FREEPHONE*

0800 597 8548

Lines are open 8am - 8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Important Data Protection Information

If you provide us with information about another person, you confirm that they have appointed you to act for them, to consent to the processing of their personal data including sensitive personal data and that you have informed them of our identity and the purposes (as set out in the Important Data Privacy notice displayed overleaf) for which their personal data will be processed.

You are entitled to ask for a copy of the information we hold about you (for which we may charge a small fee) and to have any inaccuracies in your information corrected.

For quality control and training purposes, we may monitor or record your communications with us.

If your personal details change, if you change your mind about any of your marketing preferences or if you have any queries about how we use your information, please let us know by contacting our Data Protection Officer, Domestic & General, Leicester House 17 Leicester Street, Bedworth, Warwickshire CV12 8JP.

Guarantor: Argos Limited - 489 - 499 Avebury Blvd. - Milton Keynes - MK9 2NW

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

This page is left intentionally blank

section of these instructions, or online at www.argos-support.co.uk If you still require further assistance, call one of our experts on 0345 600 3021

BUSH

Contact:

www.argos-support.co.uk

Helpline: 0345 600 3021

 DAB Digital
Radio