

cookworks

SEMI PROFESSIONAL FRYER

Model No. XJ-10302(2000W)



Care & Instruction Manual

For household and indoor use only

Please read these instructions before use and retain for future reference



ELECTRICAL SAFETY

- You should only plug the appliance into a 220V-240V AC, 50-60Hz supply. Connecting it to other power sources may damage the appliance and will invalidate the guarantee.
- This deep fat fryer is designed for domestic use. Don't use it in wet or damp locations.
- Switch off and unplug when not in use and before cleaning the appliance.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- Children shall not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep control housing, cable, and plug dry and away from areas where it is likely to get splashed. Never immerse in water.
- Do not pull on the cable to disconnect from the mains supply.
- Do not operate the appliance if damaged or after it malfunctions. In the event the supply cord is damaged; in order to avoid a hazard, it must only be replaced by a qualified service engineer, with a suitably approved part.
- This appliance must be positioned so that the plug is accessible, and the plug socket is within easy reach of the power cord.
- This appliance must be plugged in to an earthed socket outlet.


WARNING!

- This appliance is intended exclusively for use in domestic households. It is not suitable for commercial use.
- Do not operate this appliance with the storage lid fitted.
- Cooking appliances should be positioned in a stable situation with handles positioned to avoid spillage of hot liquids.
- Never leave the fryer unattended during use or move the fryer when the oil is hot.
-  The surfaces of the fryer will become hot during use. Do not touch; wear oven gloves when handling the appliance during and immediately after use and use long handled utensils when checking the food. Note the fryer and heating element is subject to residual heat after use.
- Do not use the fryer on, near or under surfaces that are heat sensitive or those that may be damaged by steam or by hot oil.
- Do not fill the oil tank above maximum level marked or below the minimum level. Check the oil level before each use.
- Do not over fill the frying basket. Take care not to fill beyond $\frac{2}{3}$ full for most foods and a maximum of 600g of chips.
- Do not reach over the appliance while it is in operation.
- Only use with the parts provided and to heat cooking oil. This appliance can cause personal injury if misused.
- Do not operate the fryer using a timer or separate remote control.
- Do not mix different types of oil and never use solid fats.
- Do not cover and allow the fryer to cool completely before storing.
- In the unlikely event that a fat fire occurs, fit the lid. Unplug the fryer and smother the flames with a damp cloth.

FOOD SAFETY

- Thoroughly defrost frozen meat, poultry, fish and seafood in the refrigerator before cooking unless cooking from frozen advice is provided by the food packaging.
- Keep raw meat and poultry separate from cooked foods.
- Always wash hands after handling raw meat and poultry, before handling any ready to eat foods.
- Wipe and disinfect surfaces that have been in contact with raw meat and poultry.
- Use separate utensils for handling raw meat/poultry and cooked food or wash them thoroughly between use.
- To check whether meat, particularly poultry, is cooked, pierce the flesh with a skewer or fork; the juices should run clear. Ensure the product is piping hot throughout.
- Fish is cooked when it appears opaque and can be flaked easily

PARTS



- 1. Storage lid (see fig. 7)
- 2. Control housing
- 3. Oil tank
- 4. Outer casing
- 5. Frying basket handle
- 6. Frying basket
- 7. Heating element
- 8. Maximum & Minimum marks

- 9. Power indicator
- 10. Heating (working) indicator
- 11. Reset point
- 12. Temperature control knob
- 13. Micro switch

ASSEMBLY

1. Place the fryer on a stable, flat, heat resistant surface, away from flammable materials and surfaces that may be damaged by steam or hot oil.
2. Check that the plug will reach a socket and that it can be accessed without reaching over the fryer.
3. Fit the oil tank into the outer casing (fig. 1 & 2).
4. Fit the heating element into the oil tank (fig. 2) ensuring that the control panel is correctly engaged into the brackets at the rear of the casing so that the micro switch is activated. If the control panel is not correctly fitted, the micro switch will prevent the fryer from working.




Fig. 1




Fig. 2




Fig.3




Fig. 4




Fig. 5

ASSEMBLY (CONTINUED)

5. Unfold the handle (fig 3) until it clicks in to position with the wire handle sitting either side of the wire bracket (fig 4 & 5).
6. Fit the basket into the oil tank (fig.6).
7. For storage fit the lid, the smaller pair of grooves should be towards the front and when correctly fitted the lid will be flush with the edge of the oil tank (fig.7 & 8).




Fig. 6




Fig. 7




Fig. 8

BEFORE FIRST USE

1. Clean all detachable parts in accordance with the cleaning section of these instructions.
2. Become familiar with -
 - The parts of the fryer – See page 4
 - How to open frying basket handle – See figs. 3,4 & 5
 - The drainage position for the frying basket - See fig. 9
 - How to fit the lid – See fig. 7 & 8
 - How to fit and remove the oil tank – fig. 1.
 - How to fit the control housing to the outer casing – fig 2 & 3.


TO USE

1. Clean thoroughly before use.
2. Place the assembled fryer on a stable, flat, heat resistant surface, away from flammable materials and surfaces that may be damaged by steam or hot oil. Depending on what is being cooked, oil droplets may spit from the fryer whilst in use so choose a surface that can easily be cleaned afterwards.
3. Check that the plug will reach a socket and that it can be accessed without reaching over the fryer.
4. Fill the tank with cooking oil to the required level marked inside the oil tank. Do not fill past the maximum (3 litre) or below the minimum (2.5 litre) level.
5. Do not fit the lid. The lid is for storage purposes only and should be put to one side whilst the fryer is in use.
6. Check that the temperature control is at the 'MIN' position. Fully unwind the cable, plug in and switch on, the power indicator will illuminate. For your safety do not allow the cable to dangle over the edge of units.
7. Rotate the temperature control knob and set to the required cooking temperature and the heating indicator will now illuminate.
8. Allow the oil to preheat (8-12 minutes approx.). When the oil has reached the required cooking temperature, the heating indicator will extinguish.

TO USE (CONTINUED)

9. Place the food to be cooked into the frying basket taking care not to fill beyond $\frac{2}{3}$ full for most foods and a maximum of 600g of chips.
10. Place the basket slowly into the fryer. Do not fit the lid. Depending on what is being cooked, oil droplets may spit from the fryer so stand away from the immediate vicinity of the tank whilst cooking.
11. When frying is complete, lift the frying basket and hook onto the end of the oil tank to permit the oil to drain back into the oil tank for a short while (fig. 10).
12. If the food requires further cooking, place the basket and food back into the oil.
13. When cooking has been completed, move the temperature control knob back to the 'MIN' position, the power light will extinguish and switch the fryer off at the mains. The lid may now be fitted
14. Allow the oil to cool fully (at least 3 hours) before emptying and cleaning the fryer.

Fig. 9



TIPS FOR SUCCESSFUL FRYING

- Choose oil that can withstand high temperatures. Do not use solid fats.
- Do not mix different types of oils.
- Change the oil regularly (8-12 uses) or when it discolours. Some cooking oils (e.g. sunflower oils) need to be changed more frequently.
- Dry food thoroughly before frying and remove any ice from frozen foods to prevent oil overflowing and to extend the life of the oil.

TIPS FOR SUCCESSFUL FRYING (CONTINUED)

- Rinse raw starchy foods (e.g. potatoes) with water and pat dry to help prevent them from sticking together.
- Do not over fill the frying basket and separate food where possible. Take care not to fill the basket beyond $\frac{2}{3}$ full for most foods and a maximum of 600g of fresh chips per basket.
- After frying do not leave the food draining in the frying basket for too long as the steam will soften any coatings.
- Raw foods usually require frying at a lower temperature than cooked or partially cooked foods.
- Smaller quantities of food will cook faster than larger quantities.
- The cooking time will vary according to the shape, thickness and composition of the food.
- Smaller pieces will cook quicker than larger pieces. For best results, ensure pieces of food are similar in size.
- Arrange the food with spaces between the pieces to allow even frying.
- Cook foods with a lighter flavour before those with stronger flavours to help prevent flavour taint.

FRYING CHART

- All the times stated in the table are a guide only - always check that the centre of the food is piping hot.
- The times will vary according to personal choice, the type of oil used size or thickness of food being cooked (e.g. one large piece will take longer to cook than several smaller pieces of an equivalent weight).
- Always check food packaging for suitability for frying and use any recommended cooking times and temperatures stated on the packaging.

FRYING CHART (CONTINUED)

Food	Quantity	Frying temp. (°C)	Time (min)
Fresh foods			
French fries / Chips*	600g *	180*	7 – 11
Potato croquettes	4 – 5 pieces	170	3 – 4
Mushrooms (button)	Single layer	170	4 – 5
Aubergine slices	350g	190	3 – 4
Breaded fish fillets (e.g. plaice, sole)	3 pieces / 215g	160	5 – 7
Camembert wedges (breaded)	3 – 4 pieces	190	2 – 3
Prawns (raw)	8 – 10 pieces	180	3 – 4
Chicken goujons	8 – 10 pieces	180	3 – 4
Frozen food			
Chips	450g	175	10 – 15
Potato croquettes	6 – 8 pieces	190	6 – 8
Mushrooms (breaded whole)	10 pieces	190	4 – 5
Fried onion rings	6 – 8 pieces	190	3 – 4
Breaded scampi	16 pieces / 250g	180	4 – 5
Fish fillets (e.g. cod, haddock)	3 fillets	190	8 – 10
Fish fingers	8 pieces	190	4 – 5
Chicken nuggets	8 – 10 pieces	190	4 – 6

FRYING CHART (CONTINUED)

- If cooking thicker chips or larger quantities of fresh chips, partially cook the chips in small batches ahead of the required time. Cook chips at 150 °C until soft to the feel and light golden colour and then remove the chips from the fryer (place on a plate lined with kitchen towel) and allow to cool. When the chips are required, heat the oil to 190°C and fry until crisp and a mid golden colour. Each batch will take about a minute until crisp and allows batches of chips to be ready to eat in a short time.

SAFETY CUT / RESET POINT

The fryer is equipped with a safety cut out, which will switch off the fryer if it overheats, for example if there is insufficient oil in the tank. If this occurs it may be necessary to manually reset the fryer. In the event that the fryer cuts out -

1. Unplug the fryer and allow the oil to cool for at least 30 minutes.
2. Top up the oil level if the level is below the minimum mark on the inside of the oil tank.
3. Plug the appliance into the mains and switch on. If the power light does not illuminate it will necessary to insert a pointed object into the reset point. This will reset the cut out device.




Fig. 10

CLEANING

1. Switch off and unplug the fryer and allow it and the oil to cool completely.
2. Remove the frying basket.
3. Carefully lift out the oil tank and pour the cold cooking oil into a storage container. It is not recommended that the oil is stored in the fryer between uses.
4. Wash the outer casing, frying basket, lid and oil tank in hot water with a little washing up liquid. Rinse and dry thoroughly. Do not use detergent or abrasives as these may scratch the surface. Not suitable for the dishwasher.
5. Wipe the control housing and element with a soft damp cloth soaked in soapy water. Rinse and dry surfaces with a soft dry cloth. Do not use detergent or abrasives as these may scratch the surface. Never immerse the control housing in water.
6. After cleaning reassemble the fryer and fit the lid for storage.
7. Cooking oil and fat shouldn't be poured down sinks as it can cause blockages. Small amounts of cooking oil, fats, plate scrapings of fatty food can be added to your food waste recycling service. If you do not have access to a food waste recycling service, put it in a sealed container and place in the general waste bin.

TECHNICAL SPECIFICATION

Cookworks Semi Professional Fryer	
Model	XJ-10302(2000W)
Rated Voltage & Frequency	220 – 240V AC, 50-60Hz
Rated Power Input	2000W
Power consumption (Off mode)	0.3W
Period after which the appliances reach automatically OFF mode	N/A
Capacity	3 litre
Class rating	I (earthed)
BS 1362 fuse	10A
Product dimensions (external)	220 x 220 x 375mm
Product weight (net)	2.2 kg approx.



RECYCLING ELECTRICAL PRODUCTS



You should now recycle your waste electrical goods and in doing so help the environment.

This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal when finished with. Visit www.recycle-more.co.uk, click on “bank locator” and enter your postcode to find your nearest recycling site.

PLUG / WIRING ADVICE

The wires in this mains lead are coloured in accordance with the following UK electrical code:

BLUE = NEUTRAL

BROWN = LIVE


GREEN + YELLOW = EARTH

Non-rewireable plug

This appliance may be fitted with a “non-rewireable” plug. If you need to change the fuse in a “non-rewireable” plug, the fuse cover must be refitted. If the fuse cover is lost or damaged, the appliance must not be used.

Rewireable plug

The colours of the wires in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in a rewireable plug. **Rewireable plugs should only be replaced by a suitably competent person. If in doubt, consult a qualified electrician.**



The BLUE wire must be connected to the terminal marked with the letter N

The BROWN wire must be connected to the terminal marked with the letter L

The GREEN & YELLOW wire must be connecting to the terminal marked with the letter E or the earth symbol .

Produced in
China.

Argos Limited, London, EC1M 6HA, UK.
Argos (N.I.) Ltd. Forestside Shopping Centre,
Upper Galwally, Belfast, BT8 6FX, UK.
argos.co.uk/help/contact-us
Tel: 0345 640 3030



PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



Year

This product is guaranteed for twelve months from the date of original purchase.

Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual. A replacement copy of this manual can be obtained from www.argos-support.co.uk
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexperienced repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd.
London
EC1M 6HA
argos.co.uk/help/contact-us