


5324310




1 Fix the pillar on the basin




2 Connect the pillar and angle valve, and be careful not to mistake the cold and hot connecting.




3 Connect the inlet flexible hose and angle valve, and be careful not to mistake the cold and hot connecting.



4



5 Open the angle valve; open the faucet and keep the water flowing for 30 seconds; installation done



6

