
Romantic Large TV Unit

Assembly Instructions - Please keep for future reference | 653/9441

THE COLLECTION BY ARGOS



Dimensions

Width - 120cm
Depth - 38cm
Height - 52.6cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800

Issue 1 - Nov/20/16

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts


• Regularly check and ensure that all bolts and fittings are tightend properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400800**


Please check you have all the panels listed below




1 Top panel (120 x 38cm)




2 Left frame side (50.1 x 36.4cm)



3 Right frame side (50.1 x 36.4cm)




4 Top front rail (108 x 3.8cm)




5 Shelf panel (108 x 32.8cm)




6 Bottom front rail (108 x 7.5cm)




7 Back rail (108 x 8.8cm)




8 Center panel (35.1 x 32cm)




9 Back panel (109.2 x 34.4cm)




10 Back drawer panel x 2 (48.4 x 16.5cm)




11 Left side drawer panel x 2 (30 x 16.5cm)




12 Right side drawer panel x 2 (30 x 16.5cm)



13 Left drawer front (53.7 x 21.3cm)



14 Right drawer front (53.7 x 21.3cm)











15 Bottom drawer panel x 2 (49.6 x 28.8cm)

Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  25mm Screw x 16	**B**  30mm Bolts x 3	**C**  Allen key x 1
D  16mm Flat washer x 3	**E**  10mm Spring washer x 3	**F**  35mm Cam bolts x 17
G  15mm Cam locks x 17	**H**  25mm Bolts x 2	**I**  30mm Metal handle x 2
K  20mm Pads x 4	**L**  25mm Rectangle Pad	

Tools required



Phillips screwdriver (medium & large)





Flatblade screwdriver (medium)



Ruler/tape measure

Ruler - Use this ruler to help correctly identify the screws






The screws length is measured from the head to the point (30mm screw shown).

Assembly Instructions


Step 1


Insert Cam bolts

a: Insert Cam bolts (F) into top panel [1] as shown



b: Insert Cam bolts (F) into left frame side [2] and right frame side [3] as shown






Assembly Instructions

Insert Cam bolts

c: Insert Cam bolts (F) into shelf panel [5] as shown


.


c:



d: Insert Cam bolts (F) into back rail [7] and bottom front rail [6] as shown

d:






Assembly Instructions

Step 2

Assembly frame side


Insert Cam locks G into the shelf panel 5 back rail 7 and top front rail 4 . Press firmly together . Turn the cam lock clockwise with a philipshead screwdriver to lock.



Step 3

Assembly center panel

Insert Cam locks G into the bottom front rail 6 and center panel 8 Press firmly together. Turn the cam locks clockwise with a philipshead screwdriver to lock.



Assembly Instructions

Step 4


a: Assembly frame side

Insert Cam locks G into the shelf panel 5 back rail 7 ,bottom front rail 6 and top front rail 4 . Press firmly together . Turn the cam lock clockwise with a philipshead screwdriver to lock.


b: Attach the pad

Remove cover paper on the pad K . Attach the pad into under the legs.
Remove cover paper on the pad L . Attach the pad into under the center panel.
With help stand the assembled unit upright.

a:




b:



Step 5

Assembly back panel

Insert back panel 9 into the slot of back rail & frame side .




Assembly Instructions

Step 6

Assembly top panel

Insert Cam locks G into side panel 2 3 as shown .Press top panel 1 onto assembly.Turn cam locks to lock . Insert bolts B , Spring washer D , flat washer E , Tighten with supplied allen key C Do not over tighten.




Step 7

Assembly Drawer


a: Position Left side drawer panel 11 ,and right side drawer panel 12 into left drawer front 13
Fix through holes using screw A

a:




b: Insert bottom panel drawer 15 into the slot of side drawer panel & drawer front panel.

b:



c: Position back panel drawer 10


Fix thourgh holes using screw A



d: Position metal handle I into drawer front panel.

Fix through holes using bolt H

Repeat (step 7) for second drawer with right drawer front 14.



Step 8

Assembly Drawer

Position two drawers into the assembled unit.

