



**Ben Sherman**  
**QUARTZ WATCH**  
Guarantee and Instructions

Your **Ben Sherman** watch is a precision instrument designed to give years of pleasure under normal use. It will not withstand extreme shocks or vibration.

**BATTERIES**

The battery should be replaced about every eighteen months. Battery replacement requires the use of special tools and should only be carried out by reputable jewellers or similar outlets. **IMPORTANT:** Do not attempt to replace the battery yourself as this invalidates your guarantee.

**OPERATING INSTRUCTIONS**

To set the watch: Pull the crown (Winder) out gently and turn it clockwise. When the correct time is reached simply push the crown back.

PLEASE NOTE: Do not wind the crown when it is pushed back.

NOTE: The gold plating can be affected by detergents or by perfume. Avoid contact where possible.

**Water Resistance.**

- If your watch is not marked, usually on the back of the case, with either the words "Water Resistant" or a degree of water resistance e.g. 3 ATM, then it is NOT water resistant. Care should be taken to avoid getting the watch wet as damage to the movement may result. This usually applies to watches designed for "dress or cocktail", type wear.
- 3 ATM The watch is designed to withstand accidental splashing or rain but it is NOT suitable for swimming.
- 5 ATM The watch is designed to withstand leisure type swimming i.e. swimming baths, yachting and taking a shower. It is NOT designed to withstand sports high board diving, scuba type diving etc.
- 10 ATM The watch is designed to withstand swimming, yachting, taking a shower, shallow diving e.g. swimming baths and bathing but NOT scuba diving.

**General Notes.**

- Do not operate buttons or the crown while the watch is in contact with water.
- Remember diving into a swimming pool can very briefly and significantly increase pressure on your watch. It

**P3**

may be that the action of diving into the pool increases the pressure on your watch to beyond the limits it has been designed to withstand.

- Wide variance of temperature can affect, temporarily, the time keeping accuracy of your watch.
- Pressure in ATM's is a test pressure and should not be considered as actual diving depth as movement in the water tends to increase the pressure bearing at a given depth.
- If your watch has been used in salt water it should be rinsed off in fresh water and carefully dried.
- Leather straps are not recommended for regular use in water.

**Ben Sherman QUARTZ GUARANTEE**

The terms of this guarantee provide rights which are in addition to the consumer's statutory rights and do not limit or otherwise affect those statutory rights.

Your **Ben Sherman** watch is guaranteed for two years from the date of purchase against any defects in material or construction. **PLEASE NOTE** that this guarantee does not cover the following:

Breakages caused from maltreatment, mishandling or accident; Water penetration except in watches marked as water protected; Batteries in electronic watches. The replacement of leather watch straps or bracelets, glass, crystal or tarnishing of watch bracelets or cases.

**P4**

**Ben Sherman**  
**HORLOGES QUARTZ**  
Garantie en gebruiksaanwijzingen

Uw **Ben Sherman** horloge is een precisie-instrument waarvan u bij normaal gebruik jarenlang plezier zult hebben. Het kan echter niet tegen grote schokken of trillingen.

**BATTERIJEN**

De batterij moet ongeveer iedere anderhalf jaar worden vervangen. De batterij kan alleen met speciaal gereedschap worden vervangen. Het werk mag alleen uitgevoerd worden door goede juweliërs of soortgelijke firma's. **BELANGRIJK:** Probeer de batterij niet zelf te vervangen aangezien uw garantie hierdoor ongeldig wordt.

**GEBRUIKSAANWIJZINGEN**

Tijd instellen: Trek het opwindknopje voorzichtig naar buiten en draai het in de richting van de klok. Wanneer het horloge de juiste tijd aangeeft drukt u het knopje weer naar binnen. **N.B.:** Het knopje mag niet worden gedraaid terwijl het wordt ingedrukt. **N.B.:** Het goudpleet kan worden beschadigd door schoonmaakmiddelen of parfum. Vermijd aanraking met deze stoffen wanneer mogelijk.

**Waterbestendingheid**

- Wanneer het woord "waterbestending" of de graad van waterbestendingheid, b.v. 3 ATM, niet op uw horloge staat normaal gesproken staat dit op de achterkant - dan is het NIET waterbestendig. U moet er dan zorg voor dragen dat het horloge niet nat wordt, omdat dit schade aan de beweging tot gevolg kan hebben. Normaal gesproken is dit van toepassing op horloges die voor "cocktail-of avondkleding" ontworpen zijn.
- 3 ATM. Het horloge is ontworpen om regen of accidentele spetters te weerstaan, maar u kunt er NIET mee zwemmen.
- 5 ATM. Het horloge is ontworpen om recreatief zwemmen in b.v. een zwembad, zeilen, of douchen te weerstaan. Het is NIET ontworpen om watersport, zoals torenspringen, duiken enz. te weerstaan.
- 10 ATM. Het horloge is ontworpen om zwemmen, zeilen, douchen, duiken in ondiep water in b.v. een zwembad, en een bad te weerstaan, maar is NIET geschikt voor duiksport.

**Algemene opmerkingen.**

- Gebruik de knoppen of de kroon niet terwijl het horloge in contact met water is.

**P5**

- Denk eraan dat een duik in het zwembad de druk op uw horloge, voor een korte tijd, aanmerkelijk verhoogt. Het kan zijn dat het duiken de drukklimiet, waarvoor uw horloge ontworpen is, overschrijdt.
- Grote temperatuurveranderingen kunnen het nauwkeurig lopen van uw horloge tijdelijk beïnvloeden.
- De druk in ATM is de testdruk en moet niet als de werkelijke duikdiepte gezien worden, omdat beweging in het water op een bepaalde diepte de druk verhoogt.
- Wanneer uw horloge in zout water gebruikt is, dan moet het met vers water afgespoeld en zorgvuldig gedroogd worden.
- Leren horlogebanden zijn niet geschikt voor regelmatig gebruik in water.

**Ben Sherman KWARTSGARANTIE**

De voorwaarden van deze garantie verlenen u rechten in aanvulling op de wettelijke consumentenrechten en vormen geen beperking of aantasting van deze wettelijke rechten. Uw **Ben Sherman** horloge is 24 maanden vanaf de koopdatum gegarandeerd voor defecten in het materiaal of de constructie.

**N.B.:**  
Deze garantie geldt niet voor de volgende beschadigingen:  
Defecten naar aanleiding van misbruik, verkeerde behandeling of ongeluk; waterpenetratie behalve bij horloges die zijn vervaardigd als waterdicht; batterijen in elektronische horloges. De vervanging van leren horlogebandjes, glas, kristal of verlevring van horlogebandjes of -kast.

**P6**