Hisense

life reimagined

USER'S OPERATION MANUAL

Before operating this unit, please read this manual thoroughly, and retain for future reference.

DH3I902UWDC
DH3I902UBDC*
DH3I902UW2C
DH3I902UB2C*
DH3I902U
DH3I904UBDC
DH3I902UWDC*
DH3I902UTDC
DH3I902UW2C*
DH3I902UT2C
DH902UKDC
DH3I904UWDC
DH3I902UBDC
DH3I902UTDC*
DH3I902UB2C
DH3I902UT2C*
DH902UKDC*

EN

English

Thank you very much for choosing our company's products.

- Please correctly install and use this product, and do not use this product to dry items that are not suitable for drying in a clothes dryer.
- The images in the manual are for illustration purposes only. The appearance, printing, etc. shall be subject to the actual product.
- Our company emphasizes technology updates. In order to enhance the overall performance of this appliance, we will make technical changes to it without further notice. Your understanding is appreciated.
- This product is for household use only.

The following symbols in this manual are indicated as follows:

Information, suggestions, prompts, or advice

WARNING - GENERAL HAZARD

WARNING - ELECTRIC SHOCK HAZARD

WARNING - BURN HAZARD

WARNING - FIRE HAZARD

Please read the user manual carefully.

CONTENTS

4 SAFETY PRECAUTIONS	**INTRODUCTION**
15 PRODUCT OVERVIEW	
16 Specifications	
17 INSTALLATION AND CONNECTION	**PREPARATION BEFORE FIRST USE**
17 Unpacking/packaging	
18 Installation location	
18 Adjustable feet	
19 Installation clearance	
21 Stacking installation	
22 Changing the door opening direction	
24 Connect the drain hose	
25 Drying rack (available on select models)	
26 Fragrance tablet installation	
27 Transportation after installation	
28 BEFORE FIRST USE	**DRYING STEPS**
29 Power connection	
31 Programs and functions	
32 Program table	
34 Additional settings and functions	
38 Function selection table	
39 Smart networking	
40 Start the program	
40 End of the program	
41 MAINTENANCE AND CLEANING	
41 Cleaning the filter	
42 Cleaning the heat exchanger	
43 Emptying the condensate tank	
44 Cleaning the humidity sensor	
45 Cleaning the water tank filter	
45 Clean the door seal	
45 Clean the appliance exterior	
46 TROUBLESHOOTING	**TROUBLESHOOTING**
48 Error codes and troubleshooting	
49 Service	
49 Usage advice	
50 DISPOSAL	**MISCELLANEOUS**
51 Consumption data table	
52 Typical consumption table	

SAFETY PRECAUTIONS

Before using this appliance, please carefully read the user manual.

Do not operate the appliance unless you have fully read and understood this manual.

This manual applies to several models of this appliance. Therefore, this manual may include features not applicable to your specific model.

Failure to follow the instructions or improper operation may damage clothing or the appliance, or cause injury to you. Please keep this manual near the appliance for easy access whenever needed.

⚠ To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following.

This appliance is intended to be used in household and similar applications such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential type environments;
- bed and breakfast type environments;
- areas for communal use in blocks of flats or in launderettes.

If the appliance is used for professional, for-profit purpose or purpose exceeding normal use in a household and similar applications, or if the appliance is used by a person who is not a consumer, the warranty period shall be equal to the shortest warranty period required by relevant legislation.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

The tumble dryer is not to be used if industrial chemicals have been used for cleaning.

The lint trap has to be cleaned frequently.

The lint must not to be allowed to accumulate around the tumble dryer.

For appliances with ventilation openings in the base, a carpet must not obstruct the openings.

The maximum capacity in some cycles for dry clothes to be used is Dry (9.0 kg).

The maximum capacity recommendations for each program may vary. For the best drying results, please refer to the "Program Chart".

Do not dry unwashed items in the tumble dryer.

Items that have been soiled with substances such as cooking oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed in hot water with an extra amount of detergent before being dried in the tumble dryer.

Items such as foam rubber (latex foam), shower caps, waterproof textiles, rubber backed articles and clothes or pillows fitted with foam rubber pads should not be dried in the tumble dryer.

Fabric softeners, or similar products, should be used as specified by the fabric softener instructions.

Remove all objects from pockets such as lighters and matches.

Fill steam generators only with liquids specified by the manufacturer.

WARNING: Never stop a tumble dryer before the end of the drying cycle unless all items are quickly removed and spread out so that the heat is dissipated.

WARNING: The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.

Exhaust air must not be discharged into a flue that is used for exhausting fumes from appliances burning gas or other fuels.

The appliance must not be installed behind a lockable door, a sliding door or a door with a hinge on the opposite side to that of the tumble dryer, in such a way that a full opening of the tumble dryer door is restricted.

That adequate ventilation has to be provided to avoid the back flow of gases into the room from appliances burning other fuels, including open fires.

ELECTRICAL SAFETY

This appliance meets all relevant safety standards.

Before connecting the appliance to the power source, wait at least 2 hours to allow the appliance to reach room temperature.

The appliance must be serviced by an authorized service center and can only be repaired using parts approved by the authorized manufacturer.

Any maintenance or repairs related to safety or performance should be carried out by trained professionals.

Do not attempt to repair the appliance yourself. Repairs carried out by unqualified personnel could result in injury or more serious damage to the appliance. Please contact your local service center and always use genuine replacement parts.

Before connecting the appliance to the power supply, ensure that the electric voltage specified on the rating plate matches the Voltage of your socket.

If the appliance is damaged, malfunctioning, partially disassembled, or has missing or damaged parts (including damaged power cords or plugs), do not attempt to operate the appliance.

Avoid excessive bending of the power cord or placing heavy objects on it.

Ensure that the mains cable is not kinked or trapped, and it does not come into contact with heat sources or sharp edges.

Do not use multiple outlets, extension cords, or double adapters with this appliance. Do not use an extension cord to connect the appliance to the power supply.

Do not spray water inside or outside the appliance for cleaning.

In the event of flooding, disconnect the power plug immediately and contact customer service.

Avoid sharing the power outlet with high-wattage appliances (e.g., hairdryers or electric razors) when using this appliance.

Do not connect the appliance to outlets designated for low-load appliances.

This appliance must be earthed via the power cord. In the event of malfunction or breakdown, grounding will reduce the risk of electric shock by providing a path of least resistance for electric current.

Improper connection of the equipment-grounding conductor can result in risk of electric shock. Check with a qualified electrician or service personnel if you are in doubt as to whether the appliance is properly grounded.

This appliance is equipped with a power cord having an equipment-grounding earthing pin and a grounding power plug. The power plug must be plugged into an appropriate outlet socket that is installed and grounded in accordance with all local codes and ordinances.

INSTALLATION

Before using the appliance, remove any packaging materials (such as sponges or polystyrene foam) attached to the bottom of the appliance.

Please follow the instructions carefully for proper installation and properly connect the water and power supplies (see "INSTALLATION AND CONNECTION"). Water and power connections should only be made by trained or professional technicians.

When installing the dryer on top of the washing machine, at least two people are required.

Do not install the appliance in a location where the door cannot open fully.

Always use the provided pipes or hoses that come with the appliance.

The appliance may not be in contact with a wall or adjacent furniture.

Install the appliance in a well-ventilated room with temperatures between 5°C and 35°C. **Do not install the appliance in a location where the temperature may drop below 5°C**, as this could cause freezing and damage the parts.

Place the appliance on a stable, level surface. If the appliance is being installed on a countertop, it must be securely anchored to prevent it from tipping over.

Keep the bottom and surrounding areas of the appliance free of flammable materials such as threads, paper, rags, chemicals, etc.

This appliance should not be stored or used outdoors.

Avoid the accumulation of lint near the appliance. For appliances with ventilation openings at the bottom, ensure the openings are not blocked by carpets.

Never block the exhaust vent, and do not place the appliance on long-fiber carpets as it can obstruct airflow.

Do not install the appliance near heaters or flammable materials.

Do not install the appliance in areas where there may be gas leaks or dust particles in the air.

Ensure proper ventilation to prevent gases produced by the appliance from re-entering the room, which could potentially cause a fire hazard.

USAGE

After installation, let the appliance stand for 24 hours before use. If the appliance needs to be laid down during transportation or servicing, place it on its left side (viewed from the front).

Check for any damage that may have occurred during transportation. Never operate the appliance if it is damaged.

The dryer uses a heat pump system to heat the air.

If the condensate tube is blocked or clogged, then tumble dryer operation is stopped.

Clean the dryer filters after each drying cycle. If you have removed the filters, replace them before the next drying cycle.

When cleaning the filters, the lint should be thrown in the garbage bin and not washed through the drain in order to avoid spreading microplastics in the used water system.

Do not touch the power plug or operate the appliance with wet hands.

The system consists of a compressor and a heat exchanger. When the dryer is started, compressor operation (the sound of flowing liquid) or flow of refrigerant may be louder as long as the compressor operates. This is not a sign of malfunction and it will not affect useful life of the dryer. In time and with use of the dryer this noise will become quieter.

Do not drink or prepare food with the condensed water/ distilled water. It can cause health problems to people and pets.

Never attempt to operate the appliance if it is damaged, malfunctioning, partially disassembled, or has missing or broken parts, including a damaged cord or plug.

⚠ RISK OF BURNS

If you open the dryer door during the drying process, the clothes may be very hot and there is a risk of burning.

⚠ FIRE HAZARD

This appliance is designed only for drying clothes washed with water. Do not dry clothing that has been cleaned with industrial cleaners, chemicals, flammable cleaners, or similar substances (such as gasoline, trichloroethylene, etc.), as this could lead to an explosion.

Do not attempt to separate any panels or disassemble the appliance.

Do not press buttons with sharp objects like pins, knives, nails, or other pointed items.

After the program ends, unplug the power cord. Never pull the plug by the power cord to disconnect the appliance. Always grip the plug firmly and pull it directly from the socket.

Since the appliance is heavy, you may injure yourself while trying to lift it. Do not attempt to lift the appliance on your own, as the sharp edges of the appliance could cause cuts on your hands.

Do not grab any protruding parts to move the appliance. Protruding parts on the appliance may break if used for lifting or pushing the appliance.

Do not dry garments with large buttons or other heavy metal items. Ensure that all pockets of garments to be dried are empty. To prevent odors and mold, open the door and allow the drum to dry after the drying cycle is complete.

Do not leave metal objects inside the drum for long periods.

The door glass may shatter if struck with force, so handle the appliance with care during use.

Make sure all clothes are fully inside the drum to prevent them from being caught by the door.

When not in use, unplug the appliance from the power socket.

Do not place animals (e.g., pets) inside the appliance.

Oil-affected items can ignite spontaneously, especially when exposed to heat sources such as in a tumble dryer. The items become warm, causing an oxidation reaction in the oil. Oxidation creates heat. If the heat cannot escape, the items can become hot enough to catch fire. Piling, stacking or storing oil-affected items can prevent heat from escaping and so create a fire hazard.

If it is unavoidable that fabrics that contain vegetable or cooking oil or have been contaminated by hair care products be placed in a tumble dryer they should first be washed in hot water with extra detergent - this will reduce, but not eliminate the hazard.

Do not use any solvents or cleaning agents that could damage the appliance (see the detergent manufacturer’s recommendations and instructions).

Do not use the appliance to dry clothes that have not been washed (except for certain dry care programs).

⚠ RISK OF BURNS

During the drying process, the appliance door may become hot. Be careful to avoid burns. Do not allow children to play near the appliance door. Do not touch the door glass during operation.

The back of the appliance may become very hot during operation, do not touch the back until it has fully cooled down.

Remove all clothing immediately after the drying cycle ends, or if you power off the appliance mid-cycle. Leaving dried clothes in the appliance creates a fire risk. Spread or hang removed items to allow proper cooling.

The dryer is protected with an automatic switch-off system in case of overheating. This system will switch off the dryer if the temperature is too high.

Never reach into the appliance while it is operating. Wait until the drum has completely stopped.

Do not push down on the door, when the appliance door is open.

If the net filter is clogged, the overheating automatic switch- off system may be activated. Clean the filter, wait for the dryer to cool down, and try running it again. If the dryer still fails to start, call a service technician.

⚠ WARNING

In the appliance enclosure or in the built-in structure, keep ventilation openings clear of obstruction.

⚠ WARNING

The appliance contains refrigerant which although it is environmentally friendly, is flammable R290. Failure to dispose of it properly may result in a fire or poisoning. Dispose of the appliance properly and do not damage the pipes in the refrigerant circuit.

Before moving the appliance or storing it in an unheated room during winter, ensure that the condensate tank is emptied.

⚠ WARNING

Do not damage the refrigerant circuit.

CHILD SAFETY

Before closing the door and starting the cycle, ensure that only clothes are inside the drum. Ensure that no children climb inside the appliance or close the door from within.

Do not leave the appliance door open. Children may climb on the door or crawl into the appliance, leading to potential damage or injury.

Keep all packaging materials out of reach of children, as these could be dangerous.

Do not allow children under the age of 3 to approach the appliance unless supervised at all times.

After understanding the safe use of the appliance and the dangers associated with improper use, children 8 years and older, as well as individuals with physical, sensory, cognitive impairments or lacking experience and knowledge, can use the appliance, but supervision is required.

Children must not clean or perform any maintenance on the appliance without supervision.

SERVICING

Damage caused by incorrect installation, improper use, or unauthorized repairs will result in the user being responsible for repair costs, as this type of damage is not covered under the warranty.

The warranty does not cover consumables, minor color variations, increased noise resulting from normal aging (which does not impair the appliance's performance), or cosmetic defects on parts (which do not compromise the appliance's safety or functionality).

PRODUCT OVERVIEW

Front View

1 Condensate Tank
2 Control Knob
3 Control panel
4 Door
5 Filter
6 Air vent
7 Heat exchanger door cover



Rear View

1 Power cord
2 Condensate discharge hose
3 Adjustable feet



The images in this manual are for illustrative purposes only. Due to product improvements and model variations, the appearance, color, and functional components of the product you receive may differ from the images in this manual. Please refer to the actual product for details.

SPECIFICATIONS

(Varies by model)

Maximum Load	9.0kg
Net Weight	46kg
Rated Voltage	220-240V~
Rated Frequency	50Hz
Rated Power	650W
Refrigerant Type	R290
Refrigerant Volume	130g
Noise Level	64dB
Waterproof Rating	IPX4
Allowed ambient temperature	5-35°C

DIMENSIONS (MM)

Index	Size (mm)
A	595
B	845
C	565
D	590
E	620
F	1110
G	390



E = Depth of the appliance
F = Depth with door open





G = Diameter of drum opening

INSTALLATION AND CONNECTION

Unpacking/Packaging

Remove all packaging and foam, especially the foam base. When unpacking the appliance, do not use sharp objects that could cause damage. Keep packaging materials (plastic bags, plastic parts, etc.) out of reach of children.



The process of packing the machine is just the opposite of unpacking above.

Check for any damage to the appliance. If the appliance is damaged, do not use it. Immediately contact customer service for assistance.

The appliance comes with one or more of the following accessories, depending on the model.

Instructions



Drying rack



Drain pipe



Fragrance Holder

Configuration varies by model. The accessories are subject to the actual configuration.

For your safety and extended product life, use only authorized components. The manufacturer is not responsible for product malfunction or accidents caused by the use of unauthorized components or parts.

INSTALLATION LOCATION

Place the appliance on a solid, flat surface to keep it stable. The surface should be clean and dry, as a slippery surface may cause the appliance to move. Additionally, clean the bottom of the adjustable feet.

ADJUSTABLE FEET

Use a leveling tool and a 22 mm wrench to adjust the feet.



1 Rotate the four adjustable feet to level the appliance. The adjustable feet allow for 1 cm of leveling adjustment.

2 After leveling, tighten the locking nuts by turning them counterclockwise with a wrench (see diagram).

Incorrect levelling of the dryer with the adjustable legs may cause vibration, appliance sliding across the room, and loud operation. Incorrect levelling of the dryer shall not be subject to warranty.

Sometimes, unusual or louder noise may appear during appliance operation; these are mostly the result of improper installation.

INSTALLATION CLEARANCE



1



2

The dryer may not be in contact with a wall or adjacent furniture. For optimum dryer operation, we recommend observing the clearance from the walls as indicated in the figure. In case of failure to heed the required minimum clearance, the dryer may overheat.

Vents on the back wall and the air exhaust opening on the front side of the dryer should never be obstructed.

The room in which you will install the dryer should be sufficiently ventilated, with a temperature between 5°C and 35°C. Dryer operation at a lower environment temperature may result in condensate accumulation in the dryer interior. Do not place the dryer into a place where there is danger of freezing. Frozen water in the condensate tank and pump may damage the dryer.

The dryer emits heat. Therefore, do not place it in a very small room, as the drying process may take longer due to limited amount of available air.

Lighting in the room should be sufficient to allow reading the information on the display unit on the control panel.

Do not place the dryer behind lockable or sliding door, or door with a hinge on the opposite side of the dryer door hinge. Install the dryer in such way that the door can always be freely opened.

Do not place the dryer on a carpet with long fibres as this may impede air circulation.



After installation, wait for 24 hours without moving the appliance before using it for the first time. If the dryer has to be laid down on one of the sides during transport or servicing, place it with its left side, viewing from the appliance front, downwards.

STACKING INSTALLATION

This dryer must be stacked on top of a washing machine of the same brand using a compatible stacking kit (see Figure 1). The accessories shown in Figure A are available from your local dealer. For installation instructions, refer to the user manual.

Alternatively, the dryer can be placed next to the washing machine (figure 2).



Stacking Brackets Wall fixed support

a



1 **2**

STACKING KIT (ACCESSORIES)

Please use original accessories. You can refer to the following recommendations for purchasing stacking brackets.

Dryer series	Dryer depth(D)	Washing machine series	Washing machine depth(D)	Matching Stacking Brackets
3I	590mm	3I	510mm/550mm/590mm	WZ3I90W

⚠ At least two persons are required to install the tumble dryer on top of a washing machine.

CHANGING THE DOOR OPENING DIRECTION

For easier operation, you can change the door opening direction. The steps are as follows (taking the example of changing from opening the door from the left side to opening the door from the right side).

⚠ WARNING

Support the door with a stool or box that fits under the door, or have an assistant support the weight of the door.

Avoid dropping the door.

Unplug the appliance or turn off power at the main circuit breaker before beginning door reversal.

Always reverse the door BEFORE stacking the appliance on top of the washer.

Do not reverse the door while the appliance is stacked on a washing machine.

Before removing the hinge screws, have an assistant support the weight of the door. The door could fall on the floor due to the weight of the door.

For safety reasons, two or more people need to work together to reverse the door.

The appearance of the screws varies and the screws must be inserted differently depending on the position. Make sure that you've selected the correct screw before tightening.



1 Fully open the door.



2 Unscrew the two fastening screws of the door hinge with a phillips screwdriver (or 8 mm socket spanner) to remove the whole door body.



3 Unscrew the two screws of the door hook cover plate with a phillips screwdriver, and remove the whole door hook cover plate (including the door hook).



4 Unscrew the two screws of the hinge cover plate, pull it out horizontally with a little force, and then remove the two screws (stainless steel pan head screws) on the reinforcing iron plate. And press the door body with one hand, grasp the hinge with the other hand, lift it up little by little, and slowly remove the hinge from the positioning pin. If necessary, use a flat head screwdriver to pry it.



5 Rotate the hinge assembly 180° to the other side, install the hinge assembly on the stud and press it tightly, and then tighten the two screws in the middle.



6 Rotate the hinge cover plate and the door hook cover plate 180° respectively and install them at the corresponding positions on the other side of the inner frame, and then tighten the screws.



7 Remove the door lock screw of front assembly pull down the door lock vertically by hand, take it down and rotate it 180° to the other side. Then install it to the hole of front assembly, pull it down to clamp it, and tighten the screws. Now, the reversing of door lock is completed.



8 Finally, install the door hinge on the front assembly, tighten the two screws, and close the door. At present, the door reversing (from left opening to right opening) is completed.

CONNECT THE DRAIN HOSE

If the appliance is not connected to a drain hose, the water extracted from the clothes by the condenser will accumulate in the condensate box, which needs to be emptied after each program. If the installation location of the appliance is close to the drain outlet, or if the dryer is stacked on top of the washing machine, you can install the drain hose included in the package to drain the water directly into the drain outlet.



1 Unplug the connecting tube at the back of the appliance's condensate box and hang it on the back of the appliance.

2 Install the drain hose in the accessories to this position (as shown in the figure), please confirm that the installation connector is firmly inserted, and insert the other end of the drain hose into the drain outlet.

If you decide to place the condensate drain hose into the drain outlet, make sure the drain hose is installed correctly. After the drain hose is installed in place, the condensate water can be discharged directly, without the need to empty the condensate box after each use.

Please use the drain hose provided with this appliance.

Do not twist or compress the drain hose, otherwise it will affect normal drainage. The height of the drain hose must not exceed the height of the machine body; otherwise, the water cannot be drained. If the drain hose is too long, please cut off the excess portion.

Do not place the drain outlet in stagnant water; this may cause backflow.

DRYING RACK (AVAILABLE ON SELECT MODELS)

Before the first drying cycle, remove the drying rack and all packaging materials from the drum. When using the drying rack for special garments, install it as follows.



1 Open the door and insert the drying rack.

2 Tilt the drying rack at an angle, securing the lower end into the two holes of the filter and hooking the top end onto the slot of the front support (as shown).

3 The drying rack can be used for sports shoes, slippers, or other items unsuitable for tumbling.

4 After drying is complete, remove the drying rack and close the door.

Before drying, sports shoes or slippers should be wrung out to prevent dripping.

The drying rack remains stationary during drum rotation. Therefore, ensure items on the drying rack do not contact the drum. Otherwise, garments and the dryer may be damaged.

FRAGRANCE TABLET INSTALLATION

The machine has a fragrance holder, allowing users to place fragrance tablet according to preferences, enabling dried clothes to retain fragrance.



1 Open the door, remove the filter, and open it.

2 Place the fragrance tablet into the fragrance holder.

3 Install the assembled fragrance holder on the inner side of the filter (note the orientation of the clips between the fragrance holder and the filter).

4 Reinstall the filter into its original position.

- Store the fragrance tablets out of reach of children, pets, and individuals requiring special care, and keep them in a cool, dry place to prevent accidental ingestion.
- After multiple uses, the fragrance will gradually fade; replace it as needed.
- If the appliance will not be used for an extended period, remove the fragrance tablet and store it in a sealed container to prevent excessive evaporation.
- If necessary, purchase fragrance tablets separately. Use only tablets with a diameter of 20 mm and a thickness of 5 mm.

TRANSPORTATION AFTER INSTALLATION

If you need to transport an installed appliance, first unplug the power plug, detach the drain hose, and ensure the door is closed properly.

After each drying program, a small amount of condensation may remain in the appliance. Start the appliance, select any program, and run it for about half a minute to drain the accumulated water to prevent damage to the appliance during transportation. If it is not possible to transport the appliance upright, please tilt it to the left.

Pack all packaging materials (plastic bags, other plastic parts, etc.).

⚠ The device is heavy. Please use at least two people to move it. When transporting, do not hold protruding parts such as the door, top cover, etc., to prevent them from falling off or being damaged.

⚠ After transport, let the device sit for at least 2 hours before connecting it to the power supply. The device should be installed and connected by trained technicians.

⚠ Please read the instructions carefully before reconnecting the device. Damage caused by improper connection or use is not covered by the warranty.

If the appliance was not transported according to the instructions, it should be allowed to rest for at least 24 hours before connecting it to the power supply. Failure to do so may lead to heat pump failure, and such failures are not covered by the warranty. Be careful not to damage the cooling system; please refer to "Installation and connection".

Transport and Handling Method



BEFORE FIRST USE

FIRST USE

Before using this appliance for the first time, ensure that it is not connected to the power supply. Then, open the appliance door and clean the drum with a soft, damp cloth.

⚠ Do not use solvents or cleaning agents that may damage the appliance (follow the recommendations and warnings provided by the cleaning agent manufacturers).

GARMENT CARE LABELS

Washing	Maximum water temperature 95°C	Maximum water temperature 60°C	Maximum water temperature 40°C	Maximum water temperature 30°C	Hand wash only	Do not wash
Rinsing	Rinse in cold water			Do not rinse		
Dry clean	Suitable for dry cleaning (any detergent may be used) (A)	Dry clean with solvent R11, R113 (P)		Dry clean with kerosene, pure alcohol, or R113 (F)	Do not dry clean	
Ironing	Maximum ironing temperature 200°C	Maximum ironing temperature 150°C		Maximum ironing temperature 110°C	Do not iron	
Tumble Dry	Lay Flat to Dry (Place on a flat surface)	Drip dry Line dry		High heat Low temperature	Do not tumble dry	

LAUNDRY PREPARATION

1. Sort your laundry based on the type and thickness of the fabrics, following the care labels on each garment.
2. Empty all pockets; remove any metal items that could damage the clothes or the appliance; fasten all buttons; turn clothes with buttons or embroidery inside out; zip up all zippers; and tie drawstrings securely.
3. Place delicate, small, or lightweight items inside a mesh laundry bag before drying with other garments.
4. Turn garments prone to pilling or those with long fibers inside out before drying.
5. Do not dry delicate fabrics in the dryer, as they may be damaged during the drying process. To avoid damage, do not put the following items in the dryer:
   - Leather and other leather products.
   - Waxed or specially treated garments requiring special care.
   - Clothes with large amounts of wool, plastic, or metal decorations.
   - Items with sequins or other shiny embellishments.
   - Garments with metal parts that can easily rust.



POWER CONNECTION



After installation, let the appliance stand on a stable surface for at least 2 hours before plugging it in.

Connect the appliance to a properly grounded power outlet without any obstructions between the plug and socket. The power outlet must meet grounding safety standards. Ensure the power supply matches the voltage and frequency specified on the rating label. For basic information about the appliance, see the nameplate.

We recommend using a surge protector to safeguard the appliance from lightning strikes.

Do not use extension cords or adapters to power the appliance.

Do not connect the appliance to outlets designated for low-load appliances.

Never unplug or plug in the appliance with wet hands.

Maintenance and repairs should be performed only by trained professionals.

Only manufacturer-authorized personnel are permitted to replace damaged power cords.

LOADING LAUNDRY FOR DRYING

Open the door, check for foreign objects in the drum, and place laundry loosely inside.
Close the door firmly until you hear a "click", indicating it is securely latched.

Do not overload the drum! Refer to the "Program Chart" for maximum load capacity. Overloading may cause wrinkles and prevent proper drying.

Make sure all clothes are fully inside the drum to avoid them getting caught in the door.



During the drying cycle, you can open the door to add or remove clothes; close the door and press the Start/Pause button to resume.

Do not put clothes in the dryer if they are not properly spun or wrung out (a minimum spin speed of 800 RPM is recommended).

For large items like bedding or towels, shake them out before placing them in the drum.

PROGRAMS AND FUNCTIONS

Control panel

Please refer to the actual printing for the final printing



1 Power
Used to turn on/off the device.

2 Start/Pause
Used to start/pause a program.

3 Cycle Selector
Turn the knob to select the program.

4 Option
Press this button to select additional functions for the program.

5 Dry Level
This function selects the drying effect of the program.

6 Time Dry +/-
The function adjusts the drying time of the program.

7 Anti Crease
Short-press turns the anti-crease function of the program on/off.

*Long-press turns the mute function on/off.

8 Delay End
This function allows you to schedule drying clothes at your convenience.

9 APP
Short press to turn on/off the device's APP remote control.

***Connect**
Long press to turn on/off the Wi-Fi function of the device.

10 Drum Light
The function manually turns the Drum Light on/off.

11 Child Lock
Press and hold this button to activate/deactivate the Child Lock.

12 Display
Used to display the remaining time of the program, reservation time, fault code, and other related information.

***Extra Function: Hold 3 sec.**

For extra function:
Press and hold for 3 seconds.

PROGRAM TABLE

Turn on the device and turn the main knob to select the appropriate program (depending on the type of clothing and desired degree of drying). During operation, the main knob will not turn automatically.

Program	Program description	Maximum load	Drying type	
			Auto dry	Time dry
Cotton	This program is suitable for drying standard cotton garments.	9.0 kg	✓	
Cotton	This program is suitable for drying thicker, durable cotton garments.	9.0 kg	✓	
Synthetics	This program is suitable for drying synthetic fabrics.	4.5 kg	✓	
Wool	This program is suitable for drying wool and delicate garments (refer to garment label drying instructions).	1.0 kg		✓
Time Dry	This program is suitable for the thorough drying of durable garments.Residual moisture is not automatically detected during drying.Select an appropriate drying time to prevent under-drying or over-drying, which may cause wrinkles.	/		✓
Quick 30'	Suitable for quickly drying lightweight and small items (fewer than 3 pieces).	1.0 kg	✓	
Shirts	This program is suitable for drying shirts made of cotton, linen, synthetic fiber, or blends.	2.0 kg	✓	
Bedding	This program features anti-tangle functionality for bulky items and is suitable for large garments.	2.5 kg	✓	
Down	This program is suitable for drying down-filled garments (such as pillows, down jackets, and coats).Dry large items separately. Use the Time Dry program if necessary.	2.0 kg	✓	
Baby Care	This program is suitable for drying baby and children's clothing.	2.0 kg	✓	
Allergy Care	This program uses high-temperature drying to eliminate allergens such as dust mites.	2.0 kg		✓
Refresh	This program is a dry garment care program that refreshes your clothes. When using this program, the heating function is turned off.	/		✓
Auto	This program is suitable for drying durable soiled synthetic fabrics and cotton garments with uniform thickness.	4.5 kg	✓	
Additional Cycles				
Towels	This program is suitable for drying durable items (towels, kitchen wiping cloths, etc.).	4.5 kg	✓	
Sportwear	This program is suitable for drying outdoor wear and sportswear made of synthetic fiber.	2.0 kg	✓	
Delicates	This program is suitable for drying very delicate synthetic fiber garments. Clothes may be slightly damp at cycle end.It is recommended to dry these items in a dedicated mesh laundry bag.	1.5 kg	✓	
Power Speed 79'	This program is suitable for drying everyday clothes made of synthetic fiber or blended fabric within a short period.	4.0 kg	✓	

If your clothing has not reached the expected drying level, please use another function or select a more suitable drying program.

Note for Additional Cycles:

To use the Additional Cycles function, the user needs to turn on the APP remote control module of the device and connect the APP to the smartphone.
When the device is not connected to the network, the default program for Additional Cycles is "Sportwear". After connecting, the user can select "Sportwear, Towels, Delicates, Power Speed 79'" and other programs in Additional Cycles through the mobile APP.

ADDITIONAL SETTINGS AND FUNCTIONS

The program comes with default settings, and some functions can be changed by user. You can adjust the settings by pressing the corresponding function button (before pressing the **Start**/Pause button).

Most functions can only be set in standby mode, i.e., before a program starts. After starting the program, most functions cannot be adjusted anymore.

1 Power

Used to turn the device's power on or off.
If you need to shut down the program during operation, press and hold the "Power" button to shut down.

2 Start/Pause

Used to start/pause a program.
The device cannot be started if the door is not closed or the door lock is not locked.

4 Option

The function selects the drying mode before the program starts. The default mode is Standard Dry. Press the button to change the mode and the corresponding icon is lit.

Standard Dry

Drying can be performed at the default temperature.
All programs default to the mode.

Gentle Dry

We recommend drying at a relatively low temperature to protect your clothes.
The mode is not available for some programs.

5 Dry Level

The function selects the drying effect of the stop-on-drying programs.
It displays the current drying effect for the first time. Press this button to cycle through the set gears. The drying effect can be selected in the following gears:
/ / : The drying effect gears that can be set for each program are different.

"☼+" "Extra" means that clothes are dried to a storage-ready level.
"🧺" "Cupboard" is for drying clothes to a state that they can be worn immediately.
"👕" "Iron" means that the clothes contain a small amount of water after drying and can be ironed again.
This function is only available for Auto Dry programs and cannot be selected for Time Dry programs.

6 Time Dry +/-

The function increases or decreases the drying time of the timed drying programs.
Before starting a program, press the button to display the current drying time for the first time. Press the button again to cycle through the gears set for the preset time slots. Available gears vary depending on the programs.
The function only applies to timed drying programs and not to stop-on-drying programs.
Please select a suitable drying time. If the drying time is too short, the clothes may not be completely dried.

7 Anti Crease

The function enables the anti-crease mode. After the program ends, the inner drum rotates intermittently to prevent clothes from forming creases when the clothes are not taken out for a long time.
After selecting a program, short-press the button. The "👕" icon lights up, and the program automatically enters anti-crease mode after the program ends. The same operation can be used to turn off this function.
During the anti-crease mode, pressing any key, turning the knob or opening the door can end this function. If no operation is performed, the program will automatically end after a maximum of 12 hours by default.

*🔇

This function shields other sounds except the alarm sound and reduces noise.
When the device is in standby, pause, or running state, long-press the button, the "🔇" icon lights up and the mute function is turned on. The same operation can be used to turn off the mute function, and all sounds will be turned back on.
When the program ends or the device is turned off and restarted, the Mute function setting remains unchanged.

8 Delay End

This function allows you to schedule drying clothes at your convenience.
After selecting the program and function, make a reservation. Press this button to start the reservation, and press it again to make a selection in the cycle of the set time gears. Each press adjusts the time by 1-hour increments. The maximum selectable time is 24 hours.
The reservation time is the end time of the program, including the entire program running time, so the reservation time must be greater than the program running time.
After selecting the delay end time, press the **Start**/Pause button to start the delay end process.
When the reservation process is in progress, the icon "🕓" on the display will light up or flash. When the reservation process finishes, the icon will go off.
If the delay end function has been selected before the program starts, it can be canceled by selecting another program or function button.
After the program is started, if you need to cancel the delay end function, you need to shut down and restart.

9 APP

The function activates the APP remote control module of the device.

Short-press the button, the "" icon lights up, and the APP remote control module of the device is activated.

The same operation can be used to turn off this function. Before activating the APP function, check and make sure that the Wi-Fi function is turned on and connected normally.

When the Wi-Fi function is turned on and connected normally, and the "" icon on the screen is not lit, you can view the status or set the program parameters and function items (depending on the different permissions of the model) through your mobile phone, but you cannot start the program remotely.

When the Wi-Fi function is turned on and connected normally, and the "" icon on the screen is lit, you can set the program parameters and function items through your mobile phone, and you can start the program remotely.

Once the Remote Control is activated, if the door of the appliance is opened at any time before it starts, the remote activation function will be canceled. You need to enable Remote Control again to remotely start the program.

After enabling Remote Control mode, if there is no activity on the entire machine and the APP for a period of time, it will enter Energy Saving mode, and it will automatically shut down if there is no activity for 7 days.

After the Remote Control is started, children should be closely monitored to prevent them from crawling into the drum and causing danger.

*Connect

Wi-Fi intelligent control function is supported on this device. Press and hold this button until the "" icon flashes to activate Wi-Fi. The same operation can be used to turn off the Wi-Fi function.

Network configuration steps:

1. Press the Power button to turn on the appliance.
2. Press and hold the "*Connect" button until the "" icon flashes, and "bon" appears on the display.
3. Open the APP, and follow the instructions to connect the appliance to the network.
4. If not successful, you can start over from step one.

After the appliance is successfully connected to the network and paired, the Wi-Fi icon stays solid. The remote control module of the appliance is activated, and the appliance can be remotely controlled through the mobile APP.

10 Drum Light

The option manually turns Drum Light on/off.

it will automatically illuminate when the door is opened, when the appliance is powered on, during program pauses, when the program ends, or while the program is running by rotating the main knob or touching any button.

11 Child Lock

To prevent children from operating the device accidentally and protect their safety, this device is equipped with a child lock function.

Long-press the button, the child lock icon "" lights up and the child lock function is turned on. The same operation can be used to disable the child lock.

When the Child Lock function is enabled, only the power button and the Child Lock deactivation function are available; all other button and knob operations are locked. The Child Lock setting remains unchanged after the program ends or when the appliance is powered off and on again.

12 Display

Used to display the remaining time of the program, reservation time, fault code, and other related information.

The remaining time indicated by the program may differ from the actual running time. Due to factors such as clothing type and quantity, drying grade, and ambient temperature, the device will automatically adjust the actual drying time.

Icon description

	Water box empty icon. When this icon lights up, it means the condensate water box is full and needs to be emptied.
	Lint and debris cleaning icon. When this icon flashes, it means that Lint and debris need to be cleaned.
	Evaporator cleaning icon. When this icon is on, it means the appliance has been run 20 times and the evaporator needs to be cleaned.

FUNCTION SELECTION TABLE

	Program	Standard Dry	Gentle Dry	Dry Level	Time Dry +/-	Anti Crease		Delay End	Child Lock	Drum Light
SENSOR DRY	Cotton	•	-	-	-	•	•	•	•	•
	Cotton	•	•	•	-	•	•	•	•	•
	Synthetics	•	•	•	-	•	•	•	•	•
	Quick 30'	•	-	-	-	•	•	•	•	•
	Shirts	•	•	•	-	•	•	•	•	•
	Bedding	•	-	•	-	•	•	•	•	•
	Down	•	-	•	-	•	•	•	•	•
	Baby Care	•	-	•	-	•	•	•	•	•
	Auto	•	•	•	-	•	•	•	•	•
	Towels	•	•	•	-	•	•	•	•	•
	Sportwear	•	•	•	-	•	•	•	•	•
	Delicates	•	•	•	-	•	•	•	•	•
	Power Speed 79'	•	-	-	-	•	•	•	•	•
MANUAL DRY	Wool	•	•	-	•	•	•	•	•	•
	Time Dry	•	-	-	•	•	•	•	•	•
	Allergy Care	•	-	-	•	•	•	•	•	•
	Refresh	•	-	-	•	•	•	•	•	•

- The function is optional
- – The function is not optional

SMART NETWORKING

Enter the "Settings" interface of your smartphone or tablet PC, enable Bluetooth and wireless connections, and connect to a wireless network.

Note:

This appliance supports 2.4 GHz Wi-Fi.
When the Wi-Fi function is activated, the energy consumption of the appliance will increase. However, the Wi-Fi power is less than 2W, so it has no impact on the energy efficiency rating of the appliance.

Download

In the app store on your smartphone or tablet PC (Google Play Store or Apple App Store), you can find the ConnectLife application, download and install it.

Note:

To improve performance and experience, the application may be updated without notice.

Log in

You need to log in to ConnectLife with your account first. If you don't have a ConnectLife account, you need to create a new account. Please refer to the application usage instructions for details.

Note:

If you already have a Google account, you can use your Google account to log in directly.
Device Binding

1. Open ConnectLife on your smartphone or tablet PC.
2. Bind your appliance on ConnectLife as follows:
   A. Click "+" on the "Home" interface, and select "Add device" or "Scan".
   B. Select "TUMBLE DRYER" or click "Scan QR/BAR code" or "Manual entry" below.
   C. Scan the "QR/BAR code" on the appliance or manually enter the "AUID/SN" of the appliance. If you can't find it, click "⑦" to view instructions.
   D. Click "SET UP APPLICATION".
   E. Read the instructions and operate the appliance until it reaches "Networking" or "Binding" state, then click "NEXT".
   F. At this time, APP begins searching for devices. You can select the device you want to connect to the network from the search list; if no device is found, please check whether your Bluetooth is turned on. Please keep Bluetooth turned on at all times, and click "NEXT".
   G. Select your home Wi-Fi, enter the password, and then click "CONNECT". The device starts networking and binding.
   H. After the binding is successful, you can set the device name and room.
   I. Now you can remotely control the device through the APP.

Note:

How to reset Wi-Fi and unbind all devices?

1. Turn on the device power and make sure the "Wi-Fi" icon lights up or blinks.
2. Long-press the "Time Dry +/- + Delay End" buttons at the same time until "C-b" is displayed on the screen.
3. Power off and restart the device to perform the new binding.
4. After unbinding, you must restart the device; otherwise, the next binding will fail. Unbinding will delete the user information previously stored in the device.
5. How to exit the network pairing mode?

If you want to cancel the network connection when "bon" is displayed on the screen, no operation is required, and it will automatically exit after the timeout.

Some models do not support unbinding on the device; unbinding can be done through the APP.

START THE PROGRAM

Select the program and additional functions, and press **Start**/Pause button to start the program.



END OF THE PROGRAM

When the program finishes, the device emits an acoustic signal and "End" appears in the display.
Press the Power button to turn off the appliance.
In standby mode, at the end of the program, if no operation is performed for a period of time, the device will automatically shut down.

After the program ends, turn off the device, open the door and take the clothes out of the drum.

MAINTENANCE AND CLEANING

Regular maintenance extends the life of the appliance. Always disconnect power before maintenance.

Children should not clean or maintain the appliance without supervision.

The dryer has a multi-filter system to keep debris out of the heat exchanger.

Do not operate the appliance without the lint filter installed or if it's damaged, as excess fibers may cause malfunctions.

Never use harsh chemicals, abrasive cleaners, or solvents to clean the appliance. They will damage the finish.

CLEANING THE FILTER

Clean the lint filter after every drying cycle.



1 Remove the lint filter.

2 Open the lint filter.

3 Open the filters and gently remove lint, fibers, and threads. If needed, rinse with warm water and let them dry.

4 Reassemble the lint filter. Clean lint from the door seal if necessary.

5 Reinstall the lint filter (make sure side "a" faces you).

Do not run the dryer without the lint filter installed.

Refer to the instructions for proper lint filter cleaning; improper cleaning can lead to lint buildup and reduced drying performance. Regular, proper lint filter cleaning reduces drying time, saves energy, and helps prevent malfunctions.

CLEANING THE HEAT EXCHANGER

Water may overflow when cleaning the heat exchanger. It is recommended to place an absorbent cloth on the floor.



1 Press the latch on the lower left to open the heat exchanger door.

2 Turn the locking knob on the inner door cover to the unlock position and remove the inner door cover.

3 For models equipped with a heat pump filter: After removing the inner door cover, carefully remove the filter. Wipe off dust with a damp cloth or rinse under running water. Allow it to dry completely before reinstalling.

4 After a period of use, dust may accumulate on the surface of the heat exchanger. Use a vacuum cleaner or a soft brush to remove the dust. Models with a filter: Remove the filter to access the heat exchanger. Models without a filter: Remove the inner door cover to access the heat exchanger. When cleaning, gently brush the metal fins from top to bottom using a soft brush. Avoid excessive force to prevent deformation or damage. Do not touch them directly with your hands to avoid injury.

5 After cleaning, reinstall the heat pump filter (if equipped) and the inner door cover in the correct sequence. Tighten the locking knob and close the heat exchanger cover.

Avoid touching the internal metal parts of the heat exchanger with bare hands to prevent cuts. Wear suitable protective gloves when cleaning the heat exchanger.

Improper cleaning of the heat exchanger fins may permanently damage the appliance. Do not press the metal fins with hard objects (such as a vacuum cleaner's plastic tube).

Clean the heat exchanger at least once every 20 drying cycles.

EMPTYING THE CONDENSATE TANK

If the condensate tank is full, the dryer will pause automatically. Empty the tank as follows:



1 Pull out the condensate tank with both hands (see illustration).

2 Invert the tank over a basin, sink, or other suitable container.

3 Empty the condensate tank.

4 Reinstall the tank in its original position.

- Empty the condensate tank after every drying cycle.
- Water from the condensate tank is not drinkable. After sufficient filtration, this water may be used for ironing.
- Do not add chemicals or fragrances to the condensate tank.

CLEANING THE HUMIDITY SENSOR



The humidity sensor continuously monitors the moisture level of laundry to ensure accurate and efficient drying performance. To prevent scale buildup from affecting sensor accuracy, perform the following cleaning steps regularly:

1. Turn off the power and open the door.
2. Wait until the appliance has cooled. Use a soft sponge dampened with clean water to gently wipe the sensor surface.

- Do not use steel wool, abrasive pads, or other hard or rough tools that may damage the sensor coating.
- Do not use solvents, alcohol, or any chemical cleaners.
- Ensure the sensor is completely dry before restoring power.

CLEANING THE WATER TANK FILTER (Applicable to Certain Models)

The water tank filter may become clogged with debris over time. It is recommended to clean it once a month.

• For models with a steam function, make sure the water tank has enough water to generate steam. When using the steam function for the first time, or when the low water icon appears on the display, fill the tank with purified water.

• For models without steam function, do not add water to the tank — simply remove and clean the filter. Pull the condensation water box straight outward.



1 Pull the condensation water box straight outward.

2 Using a kettle or a bottle with a narrow spout, pour approximately 500 ml of purified water into the water tank.

3 Grip the lower water tank filter with your fingers and pull it out. Rinse the filter thoroughly under clean water, then reinstall it properly. Finally, reinstall the condensation water box into its original position.

CLEAN THE DOOR SEAL

Check the door seal regularly and clean with a damp cloth as needed.

After use, leave the door slightly open for ventilation and drying.

CLEAN THE APPLIANCE EXTERIOR

Before cleaning the exterior, disconnect the appliance from the power supply.

Wipe the appliance exterior and control panel with a soft, damp cloth. Dry with a soft, dry cloth.

Do not use solvents, abrasives, or cleaners that may damage the appliance. Always follow the cleaner manufacturer's recommendations and warnings. Wipe the drum door with a damp cloth, then dry it with a soft dry cloth.

Do not use excessive water to clean the appliance.

TROUBLESHOOTING

The appliance features multiple automatic safety functions to quickly detect faults and initiate appropriate responses. Most faults are minor and can be resolved quickly.

If the appliance does not operate normally, an error message will appear on the display. In this case, please follow the recommended actions.

If the issue persists after following the instructions, contact after-sales service.

Any damage caused by repairs made by the user or unauthorized personnel is the user's responsibility and not covered by the warranty.

Fault symptoms	Recommended handling methods
Appliance does not start	◇ Check the power connection. ◇ Make sure you have pressed the Start/Pause button. ◇ Ensure the door is properly closed. ◇ Check for blown fuses, tripped breakers, or power outages.
Appliance will not start; the display shows "End"	◇ Check if the selected program is correct. ◇ Make sure the drum contains laundry.
Drying takes too long	◇ Check if the selected program is correct. ◇ Check if clothes are tangled together. ◇ Make sure the lint filter is clean. ◇ Some programs include a cooling phase after drying.
Poor drying performance	◇ Ensure clothes have been properly spun (wrung out). ◇ Check if the selected program is correct. ◇ Make sure the load size is not too large. ◇ Sort clothes based on drying time requirements; do not mix quick-drying and hard-to-dry items. ◇ Avoid overloading with heavy garments. ◇ Ensure the lint filter is clean.
Remaining time on display stops or jumps	◇ Variations in remaining time due to fabric type, load, moisture, or environment are normal.
Clothes are wrinkled	◇ Excessive drying duration may cause wrinkles, try reducing drying time. ◇ Clothes were left in the dryer too long after the program ended.
The displayed program time does not match the actual run time	◇ For programs that stop automatically when clothes are dry, the drying duration displayed is calculated according to standard environment, initial laundry moisture, load mass and type. The drying time is automatically adjusted for any change in conditions. The difference between the actual time and the display time is normal, which ensures the best drying effect

Damage caused by external factors (lightning, grid failures, natural disasters, etc.) is not covered under warranty.

Fault symptoms	Recommended handling methods
The appliance is too loud	◇ Look for coins, loose buttons, nails, and other objects and remove them immediately. ◇ Check the lint filter. Remove any items stuck inside the lint filter. ◇ Make sure the dryer is level and standing firmly on the floor. ◇ The dryer may hum due to air moving through the drum and fan. This is normal.
Clothes are shrinking	◇ Garment care instructions are not being followed. Use a low or no heat setting.
Lint is left on clothes	◇ Lint filter has not been cleaned properly. ◇ Clothes have not been sorted properly. ◇ Some fabrics cause more lint and should be dried separately from fabrics that lint attaches easily. ◇ Tissue, paper, etc., has been left in pockets.
The appliance has an odour	◇ The smell is caused by rubber material that is attached to the appliance inside. This kind of smell is a rubber's own smell and disappears automatically after using the appliance several times. ◇ When washing the clothes, use the detergent in accordance with the manufacturers recommendations. If you use the detergent excessively not according to the recommendations, undissolved detergent may accumulate on the clothes and cause an odour. ◇ You can smell odours from the clothes if the clothes were left in the appliance after drying or in the washing machine after washing. Unload the clothes promptly at the end of the drying or washing cycle. ◇ Ensure you can smell same odour in the washing machine. If so, clean the tub of the washing machine referring to the washing machine user manual. ◇ Always take care of both lint filters clean. If any residues were left in the lint filter after drying, it may cause odours. And also dry the lint filter completely after cleaning.
The appliance is powered on and started directly after power failure, but does not work	◇ When the program is suspended, the set functions cannot be changed, If the program or function needs to be changed during operation, or the power is off during operation and the power needs to be powered on again, select the required program and function, and finally start it.

ERROR CODES AND TROUBLESHOOTING

If the appliance is not functioning properly and displays the following codes, it may not indicate a fault. Refer to the code table for recommended actions.

Some codes apply only to specific models; refer to your appliance for actual messages.

Issue / Error	Description	Solution
F50/F51	Abnormal sensor	Turn off the appliance and then turn it on again. If the problem persists, contact a service technician.
F21	Abnormal display panel and power board	Turn off the appliance and then turn it on again. If the problem persists, contact a service technician.
F22	Abnormal display, motor control board and power board	Turn off the appliance and then turn it on again. If the problem persists, contact a service technician.
Other	Electronic module fault	Turn off the appliance and then turn it on again. If the problem persists, contact a service technician.

SERVICE

Before Contacting a Technician

Provide your appliance model when contacting the service center.

Model, code/ID, type, and serial number are on the appliance nameplate.

Use only authorized spare parts for repairs.

Repairs or warranty claims due to incorrect installation or use are not covered by the warranty. In such cases, the user shall bear the repair costs.

USAGE ADVICE

The most economical way of drying is to dry the recommended amount of laundry in each batch (see PROGRAMME TABLE).

Drying laundry made of particularly delicate fabrics that may be deformed is not recommended.

Use of conditioner in the washing cycle is not necessary as the laundry is soft and smooth after drying in the dryer. Drying time will be shorter and power consumption will be lower if the garments are thoroughly wrung or spun before drying. By selecting the appropriate drying program, you will avoid over-drying your laundry and problems with ironing or shrinkage of fabric

Regular cleaning of the filters will lead to optimum drying time and minimum power consumption.

When drying smaller amounts of laundry or individual garments, the sensor may not perceive the actual level of moisture in the laundry. In such cases, it is recommended to dry smaller items or amounts with programs for dryer laundry or with the timed program.

DISPOSAL

Packaging is made of eco-friendly materials and can be recycled or disposed of safely. Packaging is marked with recycling labels.

The icon on the product or packaging indicates that it cannot be disposed of as household waste. Take this product to an electronics recycling collection point.

When disposing of the appliance, remove all power cords and disable door locks and switches to prevent any risk of entrapment.

Proper disposal helps prevent potential harm to the environment and human health. For recycling details, contact local authorities, your waste service provider, or the store where the product was purchased.

CONSUMPTION DATA TABLE

Programme Instructions

The table indicates the power consumption and time values for drying of a test batch of laundry with various loads and after washing machine spinning .
The following requirements apply to the consumption values specified below.

Inlet air temperature	room temperature
Inlet air humidity	50–60%
Drying temperature	Normal

Program	Load (kg)	Spinning (rpm)	Program consumption approximately (kWh)*	Program duration approximately (h:min)*
Cotton	9.0	1000	2.04	3:30
	4.5	1000	1.10	2:00
Cotton	9.0	1000	1.88	3:40
Synthetics	4.5	1000	0.72	1:22
Down	2.0	800	1.34	2:33
Sportswear	2.0	1000	0.78	1:33
Quick 30'	1.0	1400	0.28	0:30
Delicates	1.5	800	0.91	1:44
Shirts	2.0	1000	0.43	1:03
Bedding	2.5	1000	1.64	2:56
Baby Care	2.0	1000	0.85	1:43
Auto	4.5	1000	1.24	2:23

Due to deviations in terms of type and amount of laundry, spinning, power supply oscillation, and environment temperature and humidity, the values measured at the user may differ from the one stated in the table.

We reserve the right to any changes and errors in the instructions for use.

TYPICAL CONSUMPTION TABLE

Rated capacity (kg)	9.0
Air-vented or condenser tumble drier	condenser
Energy efficiency class	A++
Weighted Annual Energy Consumption (kWh)(1)	245
Automatic tumble drier or nonautomatic tumble drier Automatic	Automatic tumble dryer
Energy consumption of the standard cotton program at full load (kWh)	2.04
Energy consumption of the standard cotton program at partial load (kWh)	1.1
Power consumption of the off-mode (W)	0.5
Power consumption in left-on mode (W)	0.57
Duration of the left-on mode (min)(2)	2
Standard drying program(3)	⇦ Cotton
Weighted program time of the'standard cotton program at full and partial load' (min)	159
Program time of the 'standard cotton program at full load' (min)	210
Program time of the 'standard cotton program at partial load' (min)	120
Condensation efficiency class on a scale from G (least efficient) to A (most efficient)	B
Average condensation efficiency of the standard cotton program at full load as a percentage	85
Average condensation efficiency of the standard cotton program at partial load as a percentage	85
Weighted condensation efficiency for the 'standard cotton program at full and partial load as a percentage	85
Sound power level (dB)(4)	64
Built-in	NO

(1) Based on 160 drying cycles of the standard cotton program at full and partial load, and the consumption of the low-power modes. Actual energy consumption per cycle will depend on how the appliance is used.
(2) If the household tumble drier is equipped with a power management system.
(3) The 'standard cotton program' used at full and partial load is the standard drying program to which the information in the label and the fiche relates, this program is suitable for drying normal wet cotton laundry and it is the most efficient program in terms of energy consumption for cotton.
(4) For the standard cotton program at full load.
(5) In accordance with standard EN 61121 and Commission Regulation (EU) 2023/2533, when testing the ⇦ cotton program at full and partial load, the drain hose must be connected to the appliance to allow condensate water to be drained externally. If the drain hose is not yet connected, refer to the "Connect the drain hose" section for installation instructions.

Hisense

life reimagined

20290690-N6020033945A