Era 200

ENG - SLO

Overview



- Era 200 speaker
- Era 200 Wall Mount
- Era 200 Stand
- Era 200 Stand Mount
- Quick Start Guide
- Safety and Warranty Information booklet
- Power cable
- Speaker connector panel cover

Controls and lights



Name	Function
Volume control	• Turn to increase the volume. • Turn to decrease the volume. • Press to mute the microphone. The LED indicator lights red. Press again to unmute.
Bluetooth	• Press to enter the Bluetooth pairing mode. • Press to disconnect the Bluetooth device.
Input Selector	• Press to change the input source. **Note:** The input source will change automatically when you connect a device.
Microphone mute	Press to mute the microphone. The LED indicator lights red. Press again to unmute.
Microphone mute	Press to mute the microphone. The LED indicator lights red. Press again to unmute.

Connector panel



Power input	Connect the power cable.
Reset button	• Press and hold to reset the device.
Microphone input socket	Connect the microphone cable. **Note:** Use only the microphone cable that is supplied with the device. Using other microphone cables may result in poor audio quality.
USB-C port	• Connect the USB-C cable for charging your smartphone or tablet. • Connect the USB-C cable for Bluetooth pairing with your computer. **Note:** Use only the USB-C cable that is supplied with the device. Using other USB-C cables may result in poor audio quality.

Select a location

Position your speaker on a flat surface, or mount it to the wall. Do not place your speaker:

- Near heat sources, such as radiators or heaters.
- In direct sunlight or in areas with excessive dust.
- In areas with excessive moisture.
- Where it is exposed to rain or water.
- Where it is exposed to shocks or vibrations.
- Where it is exposed to strong magnetic fields.
- Where it is exposed to ambient temperatures above 35°C (95°F) or below 5°C (41°F).

Caution: Do not block the ventilation openings on the speaker. Leave a minimum distance of 10 cm (4 inches) around the speaker for ventilation.

Power supply

- Connect the power cable to the power input on the speaker.
- Connect the power cable to a power outlet.

Bluetooth pairing

- Connect your Bluetooth device to the speaker. Refer to the user manual for your Bluetooth device for more information.
- Press the Bluetooth button on the speaker to enter the Bluetooth pairing mode.
- Select the speaker from the list of available devices on your Bluetooth device.

Line-in

- Connect the 3.5 mm audio cable to the line-in socket on the speaker.
- Connect the 3.5 mm audio cable to the audio output socket on your device.
- Select the line-in input source on the speaker.

Microphone on/off

Press the mute button to mute the microphone.

- The LED indicator lights red when the microphone is muted.
- The LED indicator lights white when the microphone is unmuted.
- When the microphone is muted, the LED indicator lights red for 5 seconds, then turns off.
- When the microphone is unmuted, the LED indicator lights white for 5 seconds, then turns off.

Note: The microphone is unmuted when you disconnect the microphone from the speaker.

Voice services

Control your voice services, such as Alexa, Google Assistant, Siri, Cortana, or Bixby, with your speaker.

- Connect the microphone cable to the microphone input socket on the speaker.
- Connect the USB-C cable to the USB-C port on the speaker.
- Connect the USB-C cable to your computer.
- Select the speaker as the audio input and output device for your voice service.

Note: Refer to the user manual for your voice service for more information.

Trueplay™

Trueplay™ is a feature that optimizes the sound of your speaker for the environment it is in. Trueplay™ is available for iOS devices.

- Open the Settings app on your iOS device.
- Select Bluetooth and connect to your speaker.
- Select your speaker in the list of devices.
- Select Trueplay™ and follow the instructions on the screen.

Advanced tuning

Use the Bang & Olufsen app to tune the sound of your speaker to your preferences.

- Download the Bang & Olufsen app from the App Store or Google Play.
- Open the app and follow the instructions on the screen.

Set up stereo pair

Connect two speakers to create a stereo pair. Set one speaker as the Left speaker and the other speaker as the Right speaker.

- Connect the two speakers to the same power source.
- Connect the two speakers to the same network.
- Open the Bang & Olufsen app on your device.
- Select the speaker you want to set as the Left speaker.
- Select Settings > Stereo pair > Left.
- Select the speaker you want to set as the Right speaker.
- Select Settings > Stereo pair > Right.

Set up surrounds

Connect two speakers to create a surround pair. Set one speaker as the Left surround and the other speaker as the Right surround.

- Connect the two speakers to the same power source.
- Connect the two speakers to the same network.
- Open the Bang & Olufsen app on your device.
- Select the speaker you want to set as the Left surround.
- Select Settings > Surrounds > Left.
- Select the speaker you want to set as the Right surround.
- Select Settings > Surrounds > Right.

Product settings

- Language
- Wi-Fi network
- Automatic firmware updates

Name	Change the name of your speaker.
Input selector	Select the input source.
Microphone	Set the microphone to On (unmuted) or Off (muted).
Wi-Fi	Connect your speaker to a Wi-Fi network.
Bluetooth	Connect your speaker to a Bluetooth device.
Trueplay™	Optimize the sound of your speaker for the environment it is in. Trueplay™ is available for iOS devices.
Stereo pair	Set your speaker as the Left speaker or Right speaker in a stereo pair.
Surrounds	Set your speaker as the Left surround or Right surround in a surround pair.
Voice control	Set your voice service to Alexa, Google Assistant, Siri, Cortana, or Bixby.
Microphone input	Set the microphone input to On (unmuted) or Off (muted).
Line-in	Set the line-in input to On or Off.
Power input	Set the power input to On or Off.

Zones

Create a zone to play the same music in different rooms.

- Connect your speakers to the same network.
- Open the Bang & Olufsen app on your device.
- Select Settings > Zones > Create zone.
- Select the speakers you want to add to the zone.
- Select Create.

Add a speaker

- Select Settings > Zones > Add speaker.
- Select the speaker you want to add to the zone.

Remove a speaker

- Select Settings > Zones > Remove speaker.
- Select the speaker you want to remove from the zone.

Delete a zone

- Select Settings > Zones > Delete zone.

Accessories

Visit your local retailer or www.bang-olufsen.com to purchase accessories.

Era 300 Stand

- Era 300 Stand
- Era 300 Stand Mount
- Era 300 Wall Mount

Era 300 Wall Mount

- Era 300 Wall Mount
- Era 300 Stand Mount
- Era 300 Stand

Get it up



1. Remove the speaker from the packaging.
2. Remove the protective cover from the connector panel.
3. Connect the power cable to the power input on the speaker.
4. Connect the power cable to a power outlet.
5. Press the power button on the speaker to turn it on.
6. Connect your device to the speaker via Bluetooth or line-in.
7. Adjust the volume to your preference.

Era 300 Wall Mount

- Remove the speaker from the packaging.
- Remove the protective cover from the connector panel.
- Connect the power cable to the power input on the speaker.
- Connect the power cable to a power outlet.
- Press the power button on the speaker to turn it on.
- Connect your device to the speaker via Bluetooth or line-in.
- Adjust the volume to your preference.

Era 300 Stand

- Remove the speaker from the packaging.
- Remove the protective cover from the connector panel.
- Connect the power cable to the power input on the speaker.
- Connect the power cable to a power outlet.
- Press the power button on the speaker to turn it on.
- Connect your device to the speaker via Bluetooth or line-in.
- Adjust the volume to your preference.

Choose the orientation

Wall mounting

- Era 300 Wall Mount
- Era 300 Stand Mount

Horizontal mounting (stand)

- Era 300 Stand
- Era 300 Stand Mount

Mount upright

1. Remove the speaker from the packaging.
2. Remove the protective cover from the connector panel.
3. Connect the power cable to the power input on the speaker.
4. Connect the power cable to a power outlet.
5. Press the power button on the speaker to turn it on.
6. Connect your device to the speaker via Bluetooth or line-in.
7. Adjust the volume to your preference.

Mount inverted

1. Remove the speaker from the packaging.
2. Remove the protective cover from the connector panel.
3. Connect the power cable to the power input on the speaker.
4. Connect the power cable to a power outlet.
5. Press the power button on the speaker to turn it on.
6. Connect your device to the speaker via Bluetooth or line-in.
7. Adjust the volume to your preference.

Specifications

Name	Specification
GENERAL	
Amplifier	Class D digital amplifier Era 300: 2 x 50 W (RMS) Era 200: 2 x 25 W (RMS)
Frequency	Era 300: 45 Hz - 20 kHz (-6 dB) Era 200: 60 Hz - 20 kHz (-6 dB)
Microphone	• Era 300: 4 microphones for voice control • Era 200: 2 microphones for voice control
Bluetooth	• Bluetooth 5.0 • Supported codecs: SBC, AAC, aptX Adaptive
Wi-Fi	• Wi-Fi 6 (802.11ax) • Supported frequency bands: 2.4 GHz, 5 GHz
Ethernet	10/100 Mbps RJ-45 connector
Power supply	Era 300: 100 V - 240 V, 50 Hz - 60 Hz, 150 W Era 200: 100 V - 240 V, 50 Hz - 60 Hz, 100 W
Power consumption	Era 300: 0.5 W (standby) Era 200: 0.5 W (standby)
Ambient temperature	• Operating: 5°C - 35°C (41°F - 95°F) • Storage: -20°C - 60°C (-4°F - 140°F)
Protection rating	IP54 (Era 300: 2.5 L/min/100 cm², 3 min) IP52 (Era 200: 2.5 L/min/100 cm², 3 min)
PHYSICAL SPECIFICATIONS	
Dimensions (W x H x D)	Era 300: 170 x 300 x 180 mm Era 200: 170 x 170 x 180 mm
Weight	Era 300: 4.7 kg Era 200: 2.5 kg
Net weight (without packaging)	Era 300: 4.5 kg Era 200: 2.3 kg
Volume of packaging	Era 300: 0.12 m³ Era 200: 0.08 m³
Colour of cloth	• Grey: Grey Mist • Black: Black Anthracite
Packaging materials	• Era 300: FSC-certified cardboard and paper • Era 200: FSC-certified cardboard and paper

Note: Specifications are subject to change without notice.

Important safety information

- Read these instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- To completely disconnect this apparatus from the mains, disconnect the plug from the wall outlet.
- The mains plug of the power supply cord shall remain readily operable.
- Do not expose batteries to excessive heat such as sunshine, fire or the like.
- Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- Use only