Move 2

Overview

Sonos Move 2 is the premium portable speaker that lets you bring powerful stereo sound from room to room and outdoors.

- **Weatherproof design.** With a durable IP66 rating, you can enjoy your music, like to barbecues, pool parties, and other outdoor events.
- **Battery lasts up to 10 hours.** Keep the party going with up to 10 hours of battery life. Or, plug in for power when you're ready to settle in.
- **Stream music over WiFi and Bluetooth.** It's connect or controller device using a USB-C to C cable (not included) for Bluetooth streaming.
- **Sonos S2 compatible.** Move is packed with the Sonos app and works features like Sonos Voice Control and TruePlay™.
- **Go Sonos** when you're ready to add Move 2 to your Sonos system.

Controls and lights

Volume control

- Volume up (while light is on): ▲
- Volume down (while light is on): ▼

Note: When music is playing, press and hold ▲ or ▼ to speedily change the volume.

Play/Pause

- Press once to play or pause audio.
- Press and hold to group with the audio that's playing in another room to be grouped.

Next/Previous

- Press ▶ skip to the next song.
- Press ◀ to go to the previous song.

Note: You can't skip forward in Line-In or when listening to a radio station.

Voice service mute

Press this mute service button to turn the microphones on or off. The mute will turn on once service is the mute is on.

- When the microphones are off, the control is disabled.
- When the microphones are off, the control is disabled.

Note: Voice assistant is not available in the Sonos app.

Status light

Displays the product's connection to WiFi or Bluetooth, indicates when the volume is muted, and signals errors. **Learn more**

Battery light

Indicates the battery status

- Blinking: a major error has occurred.
- Solid orange (indicates Move 2 has started charging): The light will turn off on its own after 10 minutes. To check the battery level, press the Play/Pause button.

Note: The battery will last 5 hours in the Sonos app.

Connector panel

Handle

Allows for easy lifting and carrying so you can take Move 2 anywhere you want.

Power button

Press to power on. The status light turns on and you'll hear a chime.

Press to put to sleep. The status light turns off and you'll hear a chime.

Press and hold to factory reset. The status light will blink white and then turn off.

Note: Move 2 goes to sleep automatically after 20 minutes when off of the charging base.

Bluetooth button

Press to connect to a mobile device via Bluetooth. Move 2 will connect to your most recently used device.

Press again to disconnect the current device.

Universal microphone switch

Turn all microphones on or off. You can set up a Sonos voice service, like Alexa.

When you switch off Alexa, the microphones are disabled to protect your privacy. Alexa won't respond to wake words or process commands.

When the switch is on, the microphones related features like TruePlay and Sonos Voice Control are enabled. Microphones are also activated right up to your command.

USB-C port

- **Power:** Use a compliant USB-PD power supply or 5 W computer/device to charge Move 2's battery.
- **Stream:** Use the Sonos Cordless Adapter and a USB-C to C cable (not included) to connect to your router if you want to hardwire your Move 2 for streaming audio.
- **Line-In:** Use the Sonos Cordless Adapter and a Sonos Cordless Adapter to connect your Move 2 to a turntable or other audio source.

Charging dock

Set Move 2 on the charging base and it'll start online for at least one will be charging.

Note: Move 2 is designed for the user with the Sonos S2 2020 / S1 Compact app. Move 2 can also use USB-C compliant USB-PD power supply or 15 W.

Charging

FEATURE	DESCRIPTION
Charging base	Set Move 2 on the charging base for easy charging. Move 2 will start charging when it's powered on and connected to a Sonos S2 system (currently Sonos Voice Control is not supported). Move 2 will charge when it's powered off.
USB-C port	**Note:** Charge battery level in the Sonos app. Move 2 is designed to be used only with the Sonos S2 2020 / S1 Compact app. Move 2 can also use USB-C compliant USB-PD power supply or 15 W.

Battery Saver

Enable the **Battery Saver** in the Sonos app to hold product battery life when Move 2 is online. When enabled, you'll have 24 hours of unpowered use (currently offline) 10 minutes to keep mode.

1. Select **Settings**.
2. Select Move 2 to get started.
3. Select **Battery Saver** to turn the Sonos app with TruePlay tuning.

Note: Battery Saver is not available in the Sonos app.

Bluetooth pairing

1. Press and hold the Bluetooth button on the back of the speaker until you hear a low tone. The status light will blink blue and then turn solid blue.
2. Choose **Sonos Move 2**from the list of available devices in your Bluetooth settings. Your mobile device will automatically connect next time you pair the Bluetooth.

Select a location

Move 2 is designed for use in multiple rooms. For maximum performance, have a few guidelines:

- For best performance, leave at least 1" (2.5 cm) space around the back of Move 2 when placing it next to a wall or furniture.
- For play outside, Move 2 is designed to work in the range of temperatures from -4°F to 122°F (-20°C to 50°C) indoors. Avoid dust, dirt, soot, and moisture because prolonged exposure to these can affect Move 2's performance.

Note: Move 2 will connect to your most recently used WiFi network when it's powered on. If you want to connect to a different WiFi network, you'll need to put Move 2 in Setup Mode. Learn how.

Microphone on/off

The microphones in Move 2 are used to detect voice commands and enable the **Sonos voice** the microphones.

The universal microphone switch on the back allows you to quickly turn on or off all microphones in the product. When the microphones are turned off, you'll see a red light on the front of Move 2.

When the voice service mute is on:

- If you say a wake word, the product will not respond.
- If you say an voice control, the mute is mute.

When the voice service mute is off:

- You can say a wake word to activate the voice assistant.
- If you say an voice control, the mute is mute.
- The universal microphone switch could be on or off.

Voice services

Use your voice to control your Sonos system with any voice assistant Sonos product, play and control playback, adjust volume, and more.

Note: Voice Control is currently only available in the Sonos app for iOS and Android devices. Some voice assistant services may require a subscription. Learn more

Amazon Alexa will receive the most up-to-date voice features and services. Alexa is currently available in the English locale only. Learn more

Google Assistant is currently available in the English locale only. Learn more

Apple AirPlay 2 lets you stream music from your supported Apple devices to your Sonos system. Learn more

Note: Apple AirPlay 2 is currently not available in the Sonos app for iOS devices.

Sonos Voice Control is built into your Sonos system. Learn more

Trueplay™

Every room is different. Trueplay tuning measures how sound reflects off walls, furnishings, and other surfaces in your room and then tunes your speaker to sound its best in your space. Trueplay tuning is available for iOS devices only.

Note: Trueplay tuning is not available when using Line-In or when the Sonos Boost and Sonos Sub Mini are connected wirelessly. Audio Trueplay tuning is not available when using Bluetooth. Trueplay tuning adjustments are not applied when sound enhancement is on speaker is and whatever you're listening to is in Stereo.

Auto Trueplay

Auto Trueplay uses the Sonos Boost and Sonos Sub Mini automatically tunes. Trueplay tuning is not available when using Bluetooth. Auto Trueplay tuning adjustments are not applied when sound enhancement is on speaker is and whatever you're listening to is in Stereo.

1. Select **Settings**.
2. Select Move 2 to get started.
3. Choose the product you want to tune.
4. Select **Trueplay** to get started.
5. Choose the product you want to tune.
6. Select **Trueplay**, and then select **Auto Trueplay**.

Set up stereo pair

Use the Sonos app to combine two Sonos speakers and create a stereo pair. One speaker acts as the left channel and the other as the right channel.

Move 2 is the best speaker to combine with each of the same type.

1. Place the speakers 2 to 3 metres apart. Too close listening position should be 2.5 to 3.5 metres from the speakers. Too far apart and the stereo effect will be lost. Too close and the sound will be too centered.
2. Select **Settings**.
3. Choose the product you want to tune.
4. Select **Trueplay** to get started.
5. Choose the product you want to tune.
6. Select **Set up stereo pair** to begin.

Learn more

Product settings

You can customize Sonos products for your surroundings.

1. Go to **Settings**.
2. Select a product.

Room Name

If you move your speaker to a new room you can change its name in **Settings**.

Ethernet

You can turn off your product's WiFi and connect it to your network with an Ethernet cable. Ethernet connections can provide more stable and reliable performance.

Learn more

For products like desk and that, turning off WiFi can improve Bluetooth performance. Learn more about Bluetooth performance in **Learn more**.

Line-In

Sonos products with a 3.5 mm input can play audio from other devices. You can change the sound settings there. Turn on **Auto-Play** to automatically play audio when it's detected.

Learn more

Enable to enable the sound for one surrounding and connect. Connect the products you want to use as surrounds.

Learn more

Trueplay

Volume Limit

You can set a maximum volume for each room. **Learn more**

Status Light

Displays the speaker's connection to WiFi, indicates when the volume is muted, and signals errors. **Learn more**

Note: Fine-tune the balancing, you can turn it off in **Settings**.

Touch Controls

You can disable the touch controls on your speaker. You can still control playback, volume, and more from the Sonos app. Disable touch controls if you're concerned about accidental touches.

Audio

To tune audio files, you can set your preferred speaker to power off automatically instead of going to sleep. If you're using your speaker as a surround, you can adjust the sub level.

Battery Saver

Set when you're not in use.

Line-In

Allows you to play with line-in capability)

Specifications

FEATURE	DESCRIPTION
Audio	
Amplifiers	Three Class-D digital amplifiers
Tweeters	Two angled tweeters create a crisp and accurate high frequency response, even at high volumes
Woofers	Two extended-excursion low-frequency woofers for rich mid-range vocal frequencies and deep bass
Microphones	• Far-field microphone array • Arrive presence, including voice control, up-to-date and to-speech processing • Integrated noise cancellation • When the voice service light is off, voice processing and recording are disabled. Audio is not recorded, and no data is sent to the Internet.
Noise	The software automatically optimizes the speaker's playback for its environment and the current audio content.
Auto Trueplay	**Note:** To increase microphone switch must be turned on.
Adjustable EQ	Use this control to adjust:
	• Bass
	• Treble
	• Loudness
Power & Connectivity	
Power supply	**Charging base:** 100-240 VAC, ~50/60 Hz, 1 A (Class II, Level VI of DOE 2.0 EPS) **USB port:** USB-C PD power with 15 W, 5 V power **Note:** Move 2 will not charge using Sonos's charging base.
Battery	**Capacity:** 9.5Wh cell **Replacement:** Not user serviceable for more information. **Disposal:** Dispose of your used battery in accordance with local laws. To determine the proper disposal method in your area.
WiFi	Connects to WiFi networks with 802.11 a/b/g/n/ac 2.4 GHz and 5 GHz radios. Supports WPA and WPA2 security.
Bluetooth	Bluetooth 5.0 supports audio streaming from any Bluetooth-enabled device.
USB-C	Connects to an audio source using an analog-to-digital converter (ADC) or digital audio source. Use the Sonos Cordless Adapter. (Accessories sold separately)
Charging	The product automatically starts charging when placed on the charging base. Charging is optimized for safety, speed, and battery health.
CPU	Quad-Core 4x A53 1.4 GHz

Details & Dimensions

Dimensions (W x H x D)	9.53 x 6.85 x 4.96 in (242 x 174 x 126 mm)
Weight	6.61 lb (3 kg) (excluding packaging)
Operating temperature	32°F to 104°F (0°C to 40°C)
Storage temperature	-13°F to 140°F (-25°C to 60°C)
Humidity resistant	Move 2 meets IP66 water and dust resistance tests. **Note:** The charging base is not water and dust resistant.
Colors	Matte black Matte white White only
What's in the box?	Move 2, charging base with USB-C to USB-C 1.5 cable, 15 W USB-C PD power adapter, and Quickstart guide.

Important safety information

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Clean only with a dry cloth and/or. Household cleaners or solvents can damage the finish or your Sonos product.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
7. Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician to replace the obsolete outlet.
8. Protect the power cable from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Only use attachments/accessories specified by the manufacturer.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
12. The Sonos plug should not be installed to disconnect the equipment.

Caution: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

Caution: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.