Move 2

Overview

Sonos Move 2 is the premium portable speaker that lets you bring powerful stereo sound from room to room and outdoors.

- **Weatherproof design.** With a durable IP66 rating, you can enjoy your music, like to barbecues, pool parties, and other outdoor events.
- **Battery lasts up to 10 hours.** Keep the party going with up to 10 hours of battery life. Or, plug in for power when you're ready to settle in.
- **Stream music over WiFi and Bluetooth.** It's connect or controller device using a USB-C to C cable (not included) for Bluetooth streaming.
- **Sonos S2 compatible.** Move is packed with the Sonos app and works features like Sonos Voice Control and TruePlay™.
- **Go Sonos** when you're ready to add Move 2 to your Sonos system.

Controls and lights

Volume control

- Volume up (while light is on): ▲
- Volume down (while light is on): ▼

Note: When music is playing, press and hold ▲ or ▼ to speedily change the volume.

Play/Pause

- Press once to play or pause audio.
- Press and hold to group with the audio that's playing in another room to be grouped.

Next/Previous

- Press ▶ skip to the next song.
- Press ◀ to go to the previous song.

Note: You can't skip forward in Line-In or when listening to a radio station.

Voice service mute

Press this mute service button to turn the microphones on or off. The mute will turn on once service is the mute is on.

- When the microphones are off, the control is disabled.
- When the microphones are off, the control is disabled.

Note: Voice assistant is not available in the Sonos app.

Status light

Displays the product's connection to WiFi or Bluetooth, indicates when the volume is muted, and signals errors. **Learn more**

Battery light

Indicates the battery status

- Blinking: a major error has occurred.
- Solid orange (indicates Move 2 has started charging): The light will turn off on its own after 10 minutes. To check the battery level, press the Play/Pause button.

Note: The battery will last 5 hours in the Sonos app.

Connector panel

Handle

Allows for easy lifting and carrying so you can take Move 2 anywhere you want.

Power button

Press to power on. The status light turns on and you'll hear a chime.

Press to put to sleep. The status light turns off and you'll hear a chime.

Press and hold to factory reset. The status light will blink white and then turn off.

Note: Move 2 goes to sleep automatically after 20 minutes when off of the charging base.

Bluetooth button

Press to connect to a mobile device via Bluetooth. Move 2 will connect to your most recently used device.

Press again to disconnect the current device.

Universal microphone switch

Turn all microphones on or off. You can set up a Sonos voice service, like Alexa.

When you switch off Alexa, the microphones are disabled to protect your privacy. Alexa won't respond to wake words or process commands.

When the switch is on, the microphones related features like TruePlay and Sonos Voice Control are enabled. Microphones are also activated right up to your command.

USB-C port

- **Power:** Use a compliant USB-PD power supply or 5 W computer/device to charge Move 2's battery.
- **Stream:** Use the Sonos Cordless Adapter and a USB-C to C cable (not included) to connect to your router if you want to hardwire your Move 2 for streaming audio.
- **Line-In:** Use the Sonos Cordless Adapter and a Sonos Cordless Adapter to connect your Move 2 to a turntable or other audio source.

Charging dock

Set Move 2 on the charging base and it'll start online for at least one will be charging.

Note: Move 2 is designed for the user with the Sonos S2 2020 / S1 Compact app. Move 2 can also use USB-C compliant USB-PD power supply or 15 W.

Charging

FEATURE	DESCRIPTION
Charging base	Set Move 2 on the charging base for easy charging. Move 2 will start charging when it's powered on and connected to a Sonos S2 system (currently Sonos Voice Control is not supported). Move 2 will charge when it's powered off.
USB-C port	**Note:** Charge battery level in the Sonos app. Move 2 is designed to be used only with the Sonos S2 2020 / S1 Compact app. Move 2 can also use USB-C compliant USB-PD power supply or 15 W.

Battery Saver

Enable the **Battery Saver** in the Sonos app to hold product battery life when Move 2 is online. When enabled, you'll have 24 hours of unpowered use before Move 2 will go to sleep.

1. Select **Settings**.
2. Select Move 2 to get started.
3. Select **Battery Saver** to turn on.

Note: Battery Saver is not supported in the Sonos app.

Bluetooth pairing

1. Press and hold the Bluetooth button on the back of the speaker until you hear a low tone. The status light will blink blue and then turn solid blue.
2. Choose **Sonos Move 2** from the list of available devices in your Bluetooth settings. Your mobile device will automatically connect next time you pair the device.

Select a location

Move 2 is designed for use in multiple rooms. For maximum performance, have a few guidelines:

- For best performance, leave at least 1" (2.5 cm) space around the back of Move 2 when placing it next to a wall or furniture.
- For play-related, Wifi, and Bluetooth performance, avoid placing Move 2 in corners, behind furniture, built-in shelves, and behind tempered/laminated/coated glass (such as tinted windows).

Microphone on/off

The microphone on Move 2 lets you control your music with voice commands from the Sonos app. You can also turn the microphone on or off.

The universal microphone switch on the back allows you to quickly turn on or off all microphones in the product. Use the switch to turn off Alexa and your voice cannot be heard by the microphones.

The control service mute on the app toggles voice control on and off without affecting the microphones needed for TruePlay and Sonos Voice Control.

When the voice service light is on:

- If you set up voice control, it's ready to listen.

When the voice service light is off:

- Alexa and Sonos Voice Control are off.
- If you set up voice control, it's not available.
- The universal microphone switch could be on or off.

Voice services

Use your voice to control your Sonos system with any voice-enabled Sonos product, play and control playback, and adjust volume and more.

Sonos Voice Control is built into your Sonos system. Set up compatible Sonos speakers in the Apple Home app and use Siri on your iPhone, iPad, or Apple TV to ask for to play Sonos (currently limited to Apple Music).

Note: Sonos Voice Control is not supported in every country yet. See Alexa on the website as soon as Alexa and voice services support is up to date.

Trueplay™

Every room is different. Trueplay tuning measures how sound reflects off walls, furnishings, and other surfaces in your room and then optimizes your speaker's performance to sound its best. Trueplay is available on iOS devices.

1. Select **Settings**.
2. Choose the product you want to tune.
3. Select **Trueplay** and follow the prompts.

Auto Trueplay

Auto Trueplay tuning uses the Sonos Room and Move sensors to automatically detect environmental changes and tune your speaker's performance. Auto Trueplay will automatically tuning adjustments to your speaker's sound whenever your speaker is and whatever you're listening to it.

1. Select **Settings**.
2. Choose the product you want to tune.
3. Select **Trueplay**, and turn on **Auto Trueplay**.

Set up stereo pair

Pair two Sonos speakers to experience true stereo sound, with the left channel and the right channel.

1. Place the two speakers in a room, each one of the same type.
2. Press the speakers' (1) & 2 buttons apart. You hear the stereo pairing tone when pressing (1) for (2) button from the speaker. Alternatively, you can select the speakers in the Sonos app and choose **Create Stereo Pair**.

Separate a stereo pair

1. Select **Settings** (⚙).
2. Choose the product you want to set as the stereo pair.
3. Select **Set up Stereo pair** to begin.

Learn more

Product settings

You can customize Sonos products for your surroundings.

1. Go to **Settings** (⚙).
2. Select a product.

Room Name	If you move your speaker to a new room you can change its name in **Settings**.
Ethernet	You can turn off your speaker's WiFi and connect it to your network with an Ethernet cable. Ethernet connections can provide more reliable performance. **Learn more**
Turn off WiFi	For products like Arc and Five, turning off WiFi can improve performance. Turn off WiFi if you're connected to a wired network. **Learn more**
Fix	Select **Fix** to restart your speaker and its WiFi and Bluetooth connections. **Learn more**
Trueplay	Trueplay adjusts the sound for your surroundings and corrects. Trueplay is available on iOS devices. Automatically. **Learn more**
Volume Limit	You can set a maximum volume for each room. **Learn more**
Status Light	Disables the speaker's connection to WiFi, indicating when the volume is muted, and signals errors. **Learn more**
Touch Controls	**Note:** Fix is typically only used by support agents.
Battery Saver	To save battery life, you can set your speaker's power to power off automatically instead of going to sleep. If you're using your speaker with a battery, you can turn on Battery Saver.
Line-In	When your speaker, turntable, stereo, or other audio device is connected to a Sonos product, you can adjust these Line-In settings.
Allow access to Line-In	Allow Line-In input to play for this Sonos system.
	Source Level - Adjust the Line-In source level if you're hearing distortion or if the sound is too quiet.
	Audio Delay - If you notice a difference between the video and audio when you're watching TV, you can adjust the audio delay to synchronize the sound.
	Autoplay - Choose whether Line-In starts to play its last playing automatically when Sonos detects a signal at the Line-In port.

Specifications

FEATURE	DESCRIPTION
Audio	
Amplifiers	Three Class-D digital amplifiers
Tweeters	Two angled tweeters create a crisp and accurate high frequency response, even at high volumes.
Woofers	Two extended-excursion low-frequency drivers for rich mid-range sound fidelity and deep bass.
Microphones	• Far-field microphone array • Arrive antennas, including voice control, can be turned off with the microphone switch on the back of the speaker.
	• Integrated noise cancellation
Voice	• When the voice service light is off, voice assistant services, like Alexa, Sonos Voice Control, and Trueplay, are off and cannot hear. Audio is disabled. Audio is the Sonos app.
Auto Trueplay	Auto Trueplay automatically optimizes the speaker's sound for its environment each time it's moved. **Learn more**
Adjustable EQ	Tune the Sonos app to adjust: • Treble • Bass • Loudness
Power & Connectivity	
Power supply	**Charging base:** 100-240 VAC, 50/60Hz, 1 A, 5 V, 3 A (max) 15 V 2 A (max), 12 V 2.5 A (max) **USB port:** USB-C PD power with 15 W (5 V, 3 A) **Note:** Move 2 will not charge using Sonos's charging base.
Battery (rechargeable)	**Capacity:** 9.5Wh cell **Replacement:** Not user serviceable for more information. **Disposal:** Contact your local waste recycling authority to determine the proper disposal method in your area.
WiFi	Connects to WiFi networks with 802.11 a/n/ac (2.4GHz and 5GHz) for streaming music.
Bluetooth	Bluetooth 5.0 supports audio streaming from any Bluetooth-enabled device.
USB-C	Connects to a wired router using an Ethernet adapter and Sonos Cordless Adapter. (Accessories sold separately)
Charging	The product automatically starts charging when placed on its Wireless charging dock for safe, waterproof, and dust-resistant charging. Connect to a power source to charge.
CPU	Quad-Core 4x A53 1.4 GHz

Details & Dimensions

Dimensions (H x W x D)	9.53 x 6.29 x 4.96 in (242 x 160 x 126 mm)
Weight	6.61 lb (3 kg) (excluding packaging)
Operating temperature	41°F to 104°F (5°C to 40°C)
Storage temperature	-13°F to 140°F (-25°C to 60°C)
Humidity resistant	Move 2 meets IP66 water and dust resistance tests. **Note:** The charging base is not water and dust resistant.
Colors	Matte black Matte white White only
What's in the box?	Move 2, charging base with USB-C to USB-C 1.5 cable, 15 W USB-C PD power adapter, and Quickstart guide.

Important safety information

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by Sonos.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Clean only with a dry cloth and/or household cleaners or consumer wet sponge that fresh or your Sonos product.
6. Do not operate this unit near water, except as the device such as Move Move 2, One, and One SL, may be used in outdoor environments. Avoid using near bathtubs, swimming pools, or other sources of water.
7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
8. Do not operate the battery pack or battery-powered product in extreme conditions.
9. Protect the power cable from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the unit has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. The Warning shall not be exceeded by connection to the equipment.

Caution: To prevent the risk of electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel. The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock. Do not open the product and attempt to service it yourself.