

Clair de Lune

Rocking Stand

Assembly Instructions



Component Parts

Base Rockers x2



Upright Pillars x4



Cross Dowels x4



Flexible End Straps x2



Top Rails x2



60mm Screws x8



50mm Screws x4



40mm Screws x8



12mm Screws x8



Assembly Instructions

Stage 1.

- Locate the dowels on the 4 upright pillars into the holes on the top of the 2 base rockers ensuring the "feet" of the upright pillars are facing outwards.
- (To check correct positioning place the rockers on a flat surface with the carving facing upwards. The "feet" of the uprights should face outwards).
- Using 8 x 60 mm screws fasten the upright pillars to the rockers through the holes in the base of the rockers.



MAKE SURE THE SCREW ARE FIRMLY LOCATED TO THE BOTTOM OF THE GUIDE HOLES IN THE ROCKERS.

Stage 2.

- Locate the 4 cross dowels into the recesses on the inside of the uprights and secure with 8 x 40mm screws.



MAKE SURE THE SCREWS LINE UP ACCURATELY WITH THE END OF THE DOWELS AND ARE SCREWED FULLY HOME.

Stage 3.

- Locate the dowels in the 2 top rails into the location holes at the top of the uprights. Ensure the screw holes face inwards.
- Secure the top rails using the 4 x 50 mm screws.



IT MAY BE NECESSARY TO CAREFULLY EASE APART THE UPRIGHT PILLARS SLIGHTLY TO LOCATE THE DOWELS CORRECTLY.

Stage 4.

- Align the holes in the flexible end straps with the pre drilled fittings on the inside of the uprights and top rails and secure with the 8 x 12 mm screws.



NB. IT IS VERY IMPORTANT TO MAKE SURE THE COT OR CRIB IS HELD SECURELY BY THE END STRAPS. USE THE HOLES ON THE END STRAPS TO PROVIDE ANY ADJUSTMENT. CHECK CAREFULLY THAT THE COT OR CRIB IS SECURE IN THE ROCKING STAND BEFORE USE.