

## HOW TO APPLY SELF-ADHESIVE WALL TILES



### IMPORTANT

Do not remove the clear membrane from the back of the tile as this forms a waterproof barrier. Only the white backing paper should be removed to reveal the sticky surface.

### TOOLS FOR THE JOB:

Tape measure  
Pencil  
Cloth  
Utility knife

### Step 1



Clean the surface

### Step 2



Measure.

### Step 3



Peel away white backing paper (leaving the clear membrane in situ).

### Step 4



Apply to the wall.

### Step 5



Apply the next tile, overlapping the clear membrane to form a waterproof barrier between the tiles.

### Step 6



If you need to cut the tile, just score and snap.