

Hang it

HOW TO APPLY 3D TILE WALLPAPER



TIPS!

Test by spraying water on the surface, if it rolls off it's non-absorbent, if the surface goes dark it's absorbent.

To make your new splashback water tight use silicone sealant at the edges and joins.

Step 1



Only apply to a solid, flat, clean, dry surface (flat walls and flat tiles are ideal).

Step 2



Measure the surface.

Step 3



Cut the wallpaper to the right size.

Step 4



If the surface is absorbent (eg. plastered walls) apply normal wallpaper paste and leave to soak for 10 minutes. Skip this step & continue with step 5 if the surface is non-absorbent.

Step 5



Apply a coat of special 3D wallpaper glue (270-1098) directly to the wall if the surface is non-absorbent (eg ceramic tiles)

Step 6



Now apply the first strip to the wall horizontally. If you're applying several strips you need to make sure the strips are butt joined together. Wipe away any excess glue.

Step 7



Press the wallpaper down firmly, smoothing out to the sides in order to push out any trapped air. Ensure the edges and the corners are firmly stuck down.



That's it! Stand back and admire your new look kitchen or bathroom!