

canzano 3 drw mirrored bedside


Assembly Instructions—Please keep for future reference

496/8382

501/7081



Heart of House



Dimensions

Width - 45.4cm
Depth - 40.6cm
Height - 66.4cm

Important—Please read these instructions fully before starting assembly

If you need help or have damage or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.


- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints






- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

- Regularly check and ensure that all bolts and fittings are tightened properly.


Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  Strap x 1	B  Bracket x 2	C  Ø3.5 x40 mm Screw x 2	D  Ø3.5 x16 mm Screw x 2	E  Rubber plug x 2
--	--	---	--	--

Tools required




Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions

Step 1

Drawer handle is pre-assembled reversely. Disassemble the handle and re-attach as shown in the figure.



Step 2

Attach the bracket **B** to the back panel of chest with screw **D**.

It is recommended that another bracket **B** is fixed to a wall.

Mark fixing hole on the wall



Warning: Before drilling, check wall for hidden pipes and cables.


Attach the bracket **B** to the wall using a suitable wall screw/plug system.

With the help of another person move the unit into position.

Secure the two brackets with the strap as shown.

Assembly is complete.

Note: The correct type of wall screws must be used for your wall. Please seek professional advice if in doubt



If you need help or have damaged or missing parts, call the Customer Helpline
Argos = 0345 6400800

A Guide to - Wall Mounting & Fixings

Important note :

If plastic wall plugs are supplied with your product :



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.


Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important : When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints :

- 1: General rule :  Always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing -Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug
Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety : Always check the fitting and location to ensure your safety in and around the home.

Fitting : From time to time check the fitting to ensure the wall plugs or screws do not become loose.