


Zander

habitat



Spare Parts

 www.argos-support.co.uk

 Help@ClickSpares.co.uk

 0370 112 1928

Customer Support

 0345 640 2020



Safety and Care Advice

Product Details

Textured Sideboard
702/2483 White/Oak Effect
794/6655 Grey

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- This product has been constructed to be used in the domestic environment only and not for commercial purposes.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

- Use a dry cloth to clean the product, furniture polish is not recommended.

- From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

WARNING

In order to prevent overturning this product must be used with the wall attachment device provided.

Additional Guidance


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.

- Regularly check and ensure that all bolts and fittings are tighten properly.


- This product is compliant BS4875-7 level 3

Fittings (Shown to scale)


Bag 1




A
5 x 65mm Screw x 10
SCR05065




B
5 x 50mm Screw x 6
SCR05050



C
7 x 39mm Locking Pin x 18
SCR07039



D
8 x 40mm Dowel x 12
PGW0840




E
6 x 30mm Dowel x 3
PGW0630




F
15 x 12mm Locking Nut x 18
FIT1512000



G
Support Cover x 8
PGP0412




H
4 x 18mm Shelf Support x 8
PGM0418



I
3 x 12mm Screw x 9
SCR03012W



J
Leg Pad x 4
FOT0170151



K
1.2 x 20mm Nail x 1
ELSNAIL




L
4 x 14.5mm Screw x 2
SCR04014




M
3.5 x 15mm Screw x 24
SCR04014




N
Bracket x 6
PARBLK07




O
3 x 18mm Screw x 6
SCR03018




P
Push Open Device x 3
PAR082015175



Q
Wall Strap x 2
ELSRING10015




R
4 x 33mm Screw x 2
SCR04033



S
Wall Plug x 2
CAP070350

Hardware


T



Door Hinge x 4

HIG0900048354F


U




Door Hinge x 2

HIG0906048354F


Tools required




Phillips screwdriver
(small & medium)



Ruler/tape
measure




Phillips screwdriver
(small & medium)




Eye protection
(when using a
hammer or glue)




Small
hammer




Large hammer



Power Drill



Pencil



Mallet



Drill Heads




Set Square




Spirit Level


Panels




1 Top (1200 x 390mm)




2 Bottom (1200 x 390mm)



3 Right Side (567 x 389mm)



4 Left Side (567x 389mm)




5 Middle Panel (567x 366mm)



6 Large Shelf (762 x 348mm)



7 Small Shelf (390 x 348mm)



8 Door (560 x 385mm) (x3)




9 Right front/Left back leg (200 x 50mm) (x2)



10 Left front/Right back leg (200 x 50mm) (x2)




11 Side Support (274 x 55mm) (x2)




12 Front/Back Support (1112 x 55mm) (x2)




13 Upper Brace (1171 x 40mm)



14 Base Brace (1171 x 40mm)







15 Large Back Panel (574 x 768mm)





16 Small Back Panel (574 x 397mm)



1







2





3





4




5



6




 **Repea**
x 2




7

F 
15 x 12mm Locking Nut x 2





8


F 
15 x 12mm Locking Nut x 4




9









10






11







12








13




14



17





18



19


Hinges Adjustment



A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.



Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

- 1: General rule:**  Always use a larger screw and wall plug if you are not sure.
- 2:** Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3:** Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
- 4:** Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5:** Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 "Plasterboard" wall plug




For use when attaching light loads on to plasterboard partitions.

No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

No.4 "Cavity Fixing-Heavy Duty" wall plug




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 "Hammer Fixing" wall plug



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 "Shield Anchor" wall plug Heavy loads



For use with heavier loads such as TV & HiFi speakers and satellite dishes etc.



Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.