Thank you for buying the OLPRO Shade. We are positive you will enjoy using your OLPRO Shade. We designed it with the Great British weather in mind ensuring you get the most from your time away.

Hopefully this short guide on how to fit the Shade, how to put it away and a few tips on looking after your Shade will help. If you need further help then check out our website at www.olpro.co.uk for videos and further information or you can email us at sales@olpro.co.uk or call 01299 896959.

CONTENTS: Shade canvas, Carry bag., 1 bag of pegs and 3 x poles



Always try your Shade prior to going away. This way you can ensure you are happy with the way in which it pitches and you are sure you have everything in order to fit the Shade.

When selecting your pitching area always try to pitch on a flat area away from trees and make sure the ground is free from stones and branches.

## FITTING YOUR SHADE

When you remove your Shade from the bag, take note of how it is packed as this will help when you come to pack it away.

### STEP ONE

Making sure the Shade is the correct way around (print to top) slide the end of the Shades 6mm awning piping into your awning rail until the shade is fully inserted.

### **STEP TWO**

Using the eyelets on the Shade you can now fit the poles through and adjust the poles to the desired height. Using the guyropes provided you can peg these out to secure the Shade to the ground.

#### STEP THREE

Make sure the middle pole is higher than the two side poles as this will allow any rain to drain off the Shade.

## PUTTING THE SHADE AWAY

Remove the guyropes and poles from the Shade

Carefully slide the shade out of the awning rail.

Fold the Shade to the same width of the carry bag.
This is very important. Put the poles at the end and use them to help assist in rolling the canvas tightly.

When the canvas is completely rolled tie the canvas ties around the Shade and place it in the carry bag.

# **MAINTENANCE**

Always make sure your Shade is clean and dry before packing away for long periods of time, as this will damage the fabric and it's waterproofing.

