CD/CASSETTE ADAPTOR

PC-7200

Play CD's through your car stereo

Instructions:



1. Turn down volume of car stereo system.
2. Plug the CD adaptor into the headphone output of CD player.
3. Insert the CD adaptor into cassette slot of car stereo system making sure the cord is not trapped.
4. Make sure the cassette is in play mode, adjust volume and sound control of car stereo system until desired levels are obtained.

Attention:

To avoid any damage to cassette or connecting cable, use the EJECT button on your car stereo system to remove the adaptor. If you are using an auto-reverse cassette player and sound is low or distorted, try pressing the auto-reverse button.

PHILEX

CUSTOMER CARELINE:

08457 573 479

Local rate - UK Only

TECHNICAL SUPPORT:

http://technical.philex.com

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority for recycling advice.

ARGOS MK9 2NW

RACO LABEL
& PO LABEL
stick here

108

83

17