maldon 4ft6 bed frame

Assembly Instructions - Please keep for future reference

379/1921





Dimensions

Width - 142.6cm Depth - 216cm Height - 102cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline**: **Argos = 0345 640 0800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

- Improper use of electrical tools will crack the components.
- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the Customer Helpline: Argos = 0345 640 0800

Please check you have all the panels listed below



Components - Key Diagram





Components - Fittings

measure

Please check you have all the fittings listed below

Note: The quantities below are correct amount to complete the assembly. In some cases more fittings may be supplied than are required.





Assembly Instructions

Step 1

Attach the supports to the headboard and the footboard.

Insert the dowels **A** into the holes indicated on the headboard **1** and the footboard **2**.


Attach the supports 4 to the headboard 1 and the footboard 2 using the screws **3**.

Step 2

Attach the sides to the headboard and the footboard.

Fit the sides 3 into the holes indicated on the headboard 1 and the footboard 2.

Make sure the hooks are connected to the bracket by pressing the sides firmly.



Assembly Instructions

Step 3

Mounting the center legs onto the center rail.


Attach the center legs 6 onto the center rail 5.

Fix the center legs using screws **©** and allen key **D** through the holes indicated.

Step 4

Attach the center rail to the supports.

Attach the center rail 5 to the supports 4 using the screws **3**.




Assembly Instructions

Step 5

Inserting the slat to the sides and the center rail.

Insert the slat 7 into the holes indicated on the sides 3 and the center rail 5.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline**: **Argos = 0345 640 0800**

Dear Customer.

Please note that the product you have purchased is a natural living timber.

Just like nature itself, wood varies in shape and colour. Knots, vein patterns, resin pockets and colour differences contribute to giving the piece of furniture its beauty and form - a natural part of solid wood.

Although the tree has been cut down and dried, it is still alive and therefore will react to high and low temperatures, light, humidity, drought and time.

In cold and dry periods, the wood contracts which may lead to small cracks in the piece of furniture. The reverse happens in warm and humid periods where the wood expands and this may result in slight unevenness.

The colour of the wood also changes with time, particularly if the furniture is place in a light place. This is a natural process and part of owning a piece of furniture made of solid wood.

Any flexing that has occurred during transport will re-correct it self once this product is correctly assembled.

Tighten all joints of the furniture after six months.

Please keep these instructions in a safe place for future use.