
Ashley Dressing Table And Stool

Assembly Instructions - Please keep for future reference

719/1792 719/3161



Dimensions	Dimensions	
Width - 80cm	Width - 30cm	
Depth - 39cm	Depth - 30cm	
Height - 62.7cm	Height - 36cm	

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers *for inserting screws,*

as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Safety Warning Information

• Do not place very hot or very cold items against or in close proximity to glass surface unless an adequately thick insulating material is used to prevent such items from coming into contact with the mirror.

- Do not strike the mirror with hard or pointed items.
- Do not sit or stand upon horizontal mirror surfaces.

• When cleaning glass panels or mirrors use a damp or leather with washing up liquid or soft soap if necessary; do not use washing powders or any other substance containing abrasive since these substances scratch glass.

BS7449 : 1991

Catalogue Number: ______ • This u Manufacture date: ______ 3mm, v Retailer: Argos ______ classifie Retailer address: MK9 2NW

• This unit contains film backed mirror of nominal thickness of 3mm, which is not required to be classified to BS6206.

• If a glass is chipped or broken replace with mirror of the type described on this label. Consult the manufacturer, retailer, or agent with regard to obtaining a manufacturing specification and shape for replacement mirror quoting the model number, and batch number or date of manufacture.

Care and maintenance

 Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• Assembly to be carried out by the competent adult only.

• From time to time check that there are no loose screws on this unit.

• During assembly children should be kept away from the product due to the potential risk of injury. • This product should not be discarded with household waste. Take to your local authority waste disposal centre.

• Do not use this item if any components are missing or damaged.

• "IMPORTANT: RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE".

• This product is suitable for children in the age of 6 or above


• The maximum weight of the children user: 30kgs.

• Regularly check all fastenings to ensure that they are properly tightened.

Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the panels listed below



Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

	B	
Knob x 1	12mm Bolt x 1	32mm Screw x 2
14mm screw x 2	32mm Bolt x 16	Flat washer x 16
G		0.
Spring washer x 16	Bracket x 2	Strap x 1
Allen key x 1		

Tools required

Phillips screwdriver (medium)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1


Attaching table leg


Attach table leg 2 to the table top 1 with flat washer **(F)**, spring washer **(G)** and bolt **(E)**. Using allen key **(J)** to tight the bolts.

Step 2

Attaching stool leg

Attach the stool leg **4** to the seat **3** with flat washer **b**, spring washer **C** and bolt **b**. Using allen key **J** to tight the bolts.





Assembly Instructions

Step 3


Attaching the mirror

Attach the framed mirror **7** to the open box **5** with screw **C**.

Step 4

Fixing knob

Fix the knob A to the drawer front panel 6 with bolt B, using allen key J to tight the bolt.




Assembly Instructions

Step 5


Inserting drawer

Insert the drawer **6** into the open box **5**.



Step 6

Fixing strap Fix strap to the desk and mirror back with bracket and screw D.



If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800