
Chicago Dining Set - Bench

Assembly Instructions - Please keep for future reference

404/4952



Dimensions

Length - 95cm

Width - 30cm

Height - 45cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: Argos = 0345 640 0800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

- Unit weight: 7.8 kgs.
- Maximum safe weight of user: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- Do not stand on the bench.
- Do not use this bench as step ladder.
- This product should not be discarded with household

waste. Take to your local authority waste disposal centre.


Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.

Components - Parts

If you have damaged or missing components, call the Customer Helpline: Argos = 0345 640 0800


Please check you have all the parts listed below



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required



Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1

Attaching left legs and short stretchers

a: Insert the short stretchers 2 into holes on left legs 4 as shown.


b: Then fix through holes using screws **D**. Tighten screws using a crosshead screwdriver.



Attaching right legs

a: Insert the short stretchers 2 into holes on right legs 5 as shown.

b: Then fix through holes using screws **D**. Tighten screws using a crosshead screwdriver.



Assembly Instructions


Step 3

Attaching long stretcher

Attach the long stretcher

3 to the legs by inserting the dowels on the long stretcher into holes on the short stretcher

2.





Step 4

Attaching seat

Position the seat 1 face down on a flat protected surface.

Position the leg frame on the seat as shown then fix the legs 4 & 5 to seat using bolts A, spring washers B and flat washers C. Tighten bolts using allen key B.







Assembly Instructions

Step 5


Securing the long stretcher

Fix through holes on the long stretcher 3 and short stretchers 2 using screws **D**. Tighten screws using a crosshead screwdriver.





Carefully turn over the unit.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: Argos = 0345 640 0800**