
SAN DIEGO - Coffee Table

Assembly Instructions - Please keep for future reference

408/8365



Dimensions

Width - 100cm

Depth - 70cm

Height - 45cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.

- This product has been produced from natural timber; you may notice some variation in the grain and colour of different component parts which is normal for furniture produced using natural wood and is not the result of any manufacturing fault.
- The product has been treated with a wax and oil finish to prevent dirt ingress and preserve moisture.
- On unpacking the furniture you may notice an odour due to this treatment; this will disappear once the furniture is unpacked and assembled after a period of time.
- This process may leave some staining on the packaging material; please take care to ensure this does not transfer to clothing or carpeted surfaces during assembly.



 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

- Parts of the assembly will be easier with 2 people.
- Dispose of all packaging carefully and responsibly.


Care and maintenance

- Use an appropriate furniture polish for natural wood furniture and a dry cloth to clean the product.
- Avoid placing the furniture in direct sunlight as this will cause the timber to prematurely age.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


Please check you have all the panels listed below



1 Top panel (100 x 70cm)



2 Base panel (88 x 60cm)



3 Front panel (81.6 x 21.8cm)



4 Back panel (81.6 x 21.8cm)



Side panel x 2 (51.6 x 21.8cm)



Side drawer runner x 2 (55 x 6.9cm)



Middle drawer runner (55 x 8.1cm)



8 Rail (51 x 6.5cm)



9 Right leg x 2 (42.2 x 5.2cm)

0 0 0 0

10 Left leg x 2 (42.2 x 5.2cm)

۰

Drawer front x 2 (30.4 x 12cm)

Drawer sides x 4 (34 x 12cm)

Drawer back x 2 (28 x 12cm)

Drawer bottom x 2 (32.6 x 29cm)




Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400 800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools required



Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Step 1

Fixing rail.

Fix rail 8 in the pre drilled holes on base panel 2 using screws •.

Step 2

Fitting Metal dowels.

Screw metal dowels into right legs 9 and left legs 10.




Note: Insert metal dowels as far as shown.

Do not over tighten.

Step 3

Insert dowels **A** into the indicated parts.



Step 4

Fixing front panel.

Fit front panel 3 to right leg 9 and left leg 10 as shown, then fix using bolts **G** and allen key **1**.

Step 5

Fixing back panel.

Fit back panel 4 to right leg 9 and left leg 10 as shown, then fix using bolts **G** and allen key **1**.

Step 6


Fixing side panels.

With help, fit side panels 5 to legs 9 and 10. Make sure panel is positioned as shown.

Insert 4 locking nuts finto side panels 5 where shown.

Use a screwdriver to turn locking nuts **F** clockwise to lock.

Do not over tighten.




Step 7

Fixing top panel.

Caution:
Carefully lay the top panel on a soft and clean surface to avoid damaging the product.

With help, fit assembled frame to top panel 1 then fix it using screw **©**.




Step 8

Fixing drawer runners.

With help, fit drawer runners 6 and 7 to back panel then fix runner using screw 6.

Attention:
Make sure drawer runners are positioned correctly as shown in the diagram.



Attention!

Step 9

Fixing front frame.

Two people are required for an easier assembly.

With help, place front frame properly ensuring dowels are all fit into their holes at the same time.

Insert 4 locking nuts **f** into side panels where shown.

Use a screwdriver to turn locking nuts **F** clockwise to lock.

Do not over tighten.


Fix middle drawer runner to the front panel and front panel to the top panel using screws ①.


Step 10

Fixing base panel.

With help, fit base panel 2 to legs as shown, then fix using bolts **G** and allen key **1**.

Important:
With help, after fixing top panel, carefully stand the product upright.





Step **11**

Drawer assembly.

a: Attach drawer sides

12 to the drawer front

11 using screws **B**.

b: Slide drawer bottom 14 into slots on drawer sides and position drawer back 13 in place.

C: Holding the drawer back 13, press the drawer sides and fix them using screws **B**.


d: Using bolt **D** attach drawer handle **H** to drawer front.


Repeat step 11 for the other drawer.


Step **12**


Insert drawers into unit. With the back of the drawers past the front frames, use a hammer to tap dowels (A) in flush to drawer sides. This is a safety catch to stop drawer falling out.

Assembly is complete.










b:

12



If you need help or have damaged or missing parts, call the Customer Helpline: 03456 400 800