## **HYATT 6 FLOOR LAMP INSTRUCTIONS**

Please read these instructions carefully prior to installation and retain them for future reference. **This product is for indoor use only.** 

### **SAFETY**

This product is supplied complete with a 13-amp plug with 3-amp fuse. Our products should not be modified. If any modification is made, including tampering with the plug, it will invalidate the warranty and may render the product unsafe.

# If the flexible cable on this fitting is damaged then it cannot be replaced and the fitting must be destroyed.

☐ This fitting is double insulated and must not be earthed. If in doubt, we recommend you consult a qualified electrician.

The symbol on the product dictates that the lamp head must be at least 0.5m (50cm) from the lit surface.

Warning: This product contains glass parts, care must be taken when fitting or handling these parts to prevent personal injury, or damage to the product.


Shades can become hot in use, allow to cool prior to adjustment, cleaning or maintenance.




WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

### **ASSEMBLY**

- 1. Carefully remove all parts from their packaging.
- 2. Screw the tube A onto the base, turn the tube B counter clock wise several times, then clock wise screw the tube B onto the tube A, Finally, pull the external flexible cable to its utmost. (See fig.1). Take care that excess cable does not become trapped or twisted when fixing tubes together.





- 3. Fit the recommended bulbs. (bulb included):6x Max. 10W 12V G4 Bi Pin Halogen Bulb. See fig. 2. Warning: The correct bulb wattage for each bulb MUST be 10W MAX when replacing the failed bulb, the total load MUST be 60W MAX as its rated power.
- 4. Fit the shade to the shade retainer . See fig. 2.
- 5. Installation is now complete, plug in to test. The lamp is turned on/off and adjusted brightness using the in line foot dimmer switch .
- 6. If the product fails to light, unplug before investigating.

### **BULB REPLACEMENT**

- 1. Switch off the mains power supply.
- 2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
- 3. Never touch the bulb with your fingers directly, cover it with a cloth.
- 4. Pull the shade from the shade retainer.
- 5. Replace a new bulb with same voltage and wattage.
- 6. Replace the shade to the shade retainer.

 $\epsilon$ 

Model No.: GYT9103

Input Voltage: 230-240V~50Hz

Max. Wattage: 60W

Bulb: 6 X Max. 10W 12V G4 Bi Pin Halogen Bulb.

Argos Limited, Avebury, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes, MK9 2NW

10/4/07