

## TOUCH LAMP FIXING INSTRUCTIONS

Thank you for buying this quality light fitting. Please read these instructions carefully prior to installation and retain them for future reference. **THIS PRODUCT IS FOR INDOOR USE ONLY.**

**This product is only suitable for connection to a 220-240V~ 50Hz supply and in accordance with I.E.E. Wiring Regulations.**


If in doubt we recommend you consult a qualified electrician.

### SAFETY



This fitting is double insulated and must not be earthed. If in doubt, we recommend you consult a qualified electrician.

This product is supplied complete with a 3-amp fuse plug. Our products should not be modified. If any modification is made, including tampering with the plug, it will invalidate the warranty and may render the product unsafe.



**The symbol**  
the lit surface.

on the product indicates that the lamp head must be at least 0.3m (30cm) from

THIS PRODUCT CAN GET EXTREMELY HOT DURING USE. CAUTION MUST BE TAKEN WHEN MAINTAINING, ADJUSTING OR CLEANING THE LUMINAIRE



WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.

### TO OPERATE:

TOUCH THE FIRST TIME FOR A LOW LEVEL LIGHT

TOUCH AGAIN FOR A MEDIUM LEVEL LIGHT

TOUCH A THIRD TIME FOR A HIGH LEVEL LIGHT

TOUCH THE FOURTH TIME TO SWITCH OFF

REPEAT EACH STEP TO SELECT LIGHTING LEVEL AS REQUIRED

### ASSEMBLY INSTRUCTIONS


1. Please note: Do not plug in the lamp until after assembly.
2. Carefully unpack the lamp and put it on a soft and flat surface
3. Screw the shade on the lamp holder with ring tightly.
4. Place the bulb ( BC Max.60W, not included) into the lamp holder.
5. Plug in the lamp. Then switch on/off the lamp with on-off switch.
6. Carefully place the lamp in the desired location.

### BULB REPLACEMENT

1. Switch off the main power supply.
2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
3. Never touch the bulb with your fingers directly, cover it with a cloth.
4. Loosen the bulb and remove it from the lamp.
5. Replace a new bulb with same voltage and wattage.

### CAUTION

1. Indoor use only.
2. Connect to 220 - 240V, ~ 50Hz.
3. If in doubt about fitting this product, please consult a suitable qualified electrician.
4. The temperature of the luminaire rises very quickly.
5. Do not touch the metal parts or glass of the shade after the light is turned on.
6. The external flexible cable or cord of this luminaire cannot be replaced. If the cord is damaged, the luminaire shall be destroyed.



Model No. :DK-00234  
Input Voltage: 220-240V~50Hz  
Bulb: Max. 60W BC bulb (not included)

Argos Limited  
Avebury, 489-499 Avebury Boulevard, Saxon Gate West, Central Milton Keynes,  
MK9 2NW

