
# Hamstead Pair Of Upholstered Chairs

Assembly Instructions - Please keep for future reference

450/4818



#### **Dimensions**

Width - 41.5cm

Depth - 50.5cm

Height - 89cm

#### Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800



## Safety and Care Advice

#### Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During asembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 To reduce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

 The maximum safe weight of user: 110kg.

#### Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This produt should not be discarded with household waste. Take to your local authority waste disposal centre.

#### Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.


**Note:** if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

## Components - Panels


If you have damaged or missing components, call the Customer Helpline: 0345 640 0800

### Please check you have all the fittings listed below

NOTE: Components, listed below are required for one chair only.



1 Backrest x 1 (89 x 38cm)




2 Front Leg x 1 (43 x 39cm)



Side Stretcher x 2 (36 x 5.7cm)



4 Side Rail x 2 (38.5 x 1.9cm)




5 Seat Cushion x 1 (41 x 40cm)




## Components - Fittings

### Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly for one chair. In some cases more fittings may be supplied than are required.







# **Assembly Instructions**

### Step 1

#### Fitting the Side Stretcher

a: Insert Screw A + Spring washer + Flat washer with Allen key 3 to fix side stretcher 3 onto backrest 1.

#### Fitting the Side Rail

**b**: Insert Screw **©** to fix side rail 4 onto back rest 1 using Screwdriver.

**Note:** Do not fully tighten all the screw.

### Step 2


#### **Fitting the Front Leg**

**Note**: It would be useful to ask someone to help you at this stage.

a: Insert Screw A + Spring washer + Flat washer with Allen key B to fix front leg 2 onto side stretcher 3.

**b**: Insert Screw **c** to fix side rail 4 onto front leg 2.

**Note:** Do not fully tighten all the screw.



# **Assembly Instructions**


## Step 3

#### **Fitting the Cushion**

**Note:** It would be useful to ask someone to help you at this stage.

Use Screw **(C)** to fix cushion seat **(5)** onto the unit.

**Note:** Fully tighten all the screw now.



## **Assembly Instructions**

### Step 4

#### Finishing the unit

**Note:** Before use always make sure the unit is secure.

**Note:** The maximum safe weight of user: 110kg.



#### Warning:

- •Do not stand on this chair. Do not use this chair as a step ladder.
- •Use this product only for seating one person at a time.
- •Do not use this chair unless all bolts, screws and knobs are firmly secured.
- •At least every 4 months, check all bolts, screws and knobs, to be sure they are tight.
- If parts are missing, broken or damaged or worn, stop use of this product until repairs are made & using factory authorized parts.
- Failure to follow these warnings could result in serious injury.

Assembly is complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800