


New High Back Sofa Set - Table

Assembly Instructions - Please keep for future reference

453/5997



Dimensions

Width - 78cm

Depth - 47cm

Height - 38cm



Important: Do not fully tighten all screws until assembly is complete.

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break into a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of injury from glass breaking into large shards.
- If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.
- Check you have all the components and tools listed on page 2.

- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the parts during assembly, this could cause damage.
- Assemble on a soft level surface to avoid damaging the unit or your floor.



- We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit, only use hand screwdrivers.

- Dispose of all packing carefully and responsibly.
- Do not sit or stand on this table.
- Do not place very hot or very cold items on the glass.
- **Warning:** The unit weight approximately 9.5kgs.

Please lift with care.

Care and maintenance

- Wash glass with mild soap and water, rinse thoroughly, and dry glass completely.
- We recommend the use of furniture covers when not in use.

- Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.
- In order to prolong the life and your

table, we recommend it be stored in a dry and protected area during off season periods.

- Do not use washing powders or any abrasive substances which may scratch the surface.



Friendly Tips








- Do not fully tighten all screws until assembly is complete.
- Make sure the assemble will be easier with 2 people.

Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400800**

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


1  Table Top x 1	2  Support x 2	3  Table Leg x 2
4  Glass x 1	A  M6X25 Screw x 12	B  Washer x 12
C  Screw Cap x 12		

Tools Provided



D Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Use screws **A** and washers **B** to fix the support **2** to the table legs **3**.

Repeat above steps to assemble the other table supports.





Important:

Do not fully tighten all screws until assembly is complete.

Step 2

Use screws **A** and washers **B** to fix the table top **1** onto the table ends.

Tighten all the screws and cover all the screws **A** with the caps **C**.




Important: Do not fully tighten all screws until assembly is complete.

Assembly Instructions

Step 3


Turn the table up and carefully place the glass **1** onto the table.

Note: Be careful and do not scratch the glass top during the assembling.



Step 4

Assembly is complete



If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW