
# Arizona Dining Chair

Assembly Instructions - Please keep for future reference

461/6366





#### **Dimensions**

Width - 44.5cm

Depth - 50cm

Height - 105cm

## Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: Argos = 0345 640 0800** 



## Safety and Care Advice

### Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



 We do not recommend the use of power drill/drivers for inserting screws.

as this could damage the unit. Only use hand screwdrivers.

- Unit weight: 5.4 kgs.
- Maximum safe weight of user: 110kgs.

#### Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- Do not stand on the chair.
- Do not use this chair as step ladder.
- This product should not be discarded with household

waste. Take to your local authority waste disposal centre.


## **Handy Hints**

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
- Regularly check and ensure that all bolts and fittings are tightend properly.

## Components - Parts

If you have damaged or missing components, call the Customer Helpline: Argos = 0345 640 0800


### Please check you have all the parts listed below




## Components - Fittings

#### Please check you have all the fittings listed below

**Note:** The quantities below are the correct amount to complete the assembly of 1 chair. In some cases more fittings may be supplied than are required.



### Tools required



### Ruler - Use this ruler to help correctly identify the screws


0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 1


## **Assembly Instructions**

## Step 1

#### **Fitting dowels**

Insert wooden dowels **©** into holes on the backrests **4**, back seat rail **5** and front seat rail **6** as shown.





### Step 2


## Attaching back rest and seat rails

Position the backrests
4, back seat rail 5,
and front seat rail 6 on
the right leg 2 and insert
the wooden dowels 6
into holes as shown.



### Important:


Make sure to position the back seat rail 5 and front seat rail 6 with the smaller screw holes up as shown.



## Step 3

#### **Attaching left leg**

Carefully position the left leg 1 as shown and with a help holding the rails and back rest, attach the left leg by inserting the wooden dowels into holes as shown.



## Assembly Instructions

## Step 4

### Securing the leg frames

**a:** Secure the leg frame using bolts **A** as shown and tighten using allen key **D** but do not fully tighten at this stage.

b: Attach the stretcher 7
between the legs 1 and 2 as shown and secure using bolts 4.


Fully tighten bolts using allen key **①**.




Important:

Make sure to position the stretcher at an angle as shown in the inset diagram.

**C:** Carefully turn the chair frame on the other side to secure the leg frame 2 and the stretcher 7 using bolts **A** as shown and tighten using allen key **D**.



C:



## **Assembly Instructions**

## Step 5

### **Attaching seat**

Position the seat panel 3 face down on a flat and raised surface such as a table.


Position the chair frame on the seat as shown then fix the back seat rail 5 and front seat rail 6 to seat panel 3 using screws 6.

Tighten screws using a crosshead screwdriver.

Remove backing from foot pads **6** and carefully position on the bottom of the left leg frame **1** and right leg frame **2** as shown.

Carefully position the chair frame upright.

chair frame upright.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline**: **Argos = 0345 640 0800**