


Wooden Bar Stool

Assembly Instructions - Please keep for future reference

600/5779



Dimensions

Width - 30.5cm

Depth - 30.5cm

Height - 59.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.
- The maximum safe weight of user: 110kg.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.


Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels


If you have damaged or missing components,
call the **Customer Helpline: 08456 400800**

Please check you have all the panels listed below


Note: Components listed below are required for one chair only.




1 Right Side Frame
(30 x 58cm)




2 Left Side Frame
(30 x 58cm)



3 Stool Apron x 2
(42 x 15.5cm)



4 Short Stretcher x 2
(2 x 21cm)



5 Long Stretcher x 2
(2 x 24cm)







6 Wooden Seat
(30 x 30cm)




Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly for one chair. In some cases more fittings may be supplied than are required.

A  Tool x 1	B  40mm Screw x 8	C  Wood Dowel x 4
D  32mm Screw x 4		

Tools required



Phillips screwdriver
(medium & large)



Eye protection
(when using a
hammer or glue)



Small
hammer




Flatblade screwdriver
(medium)



Ruler/tape
measure

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1


Fitting the Legs

Note: It would be useful to ask someone to help you at this stage.


a: Insert Wood Dowel **C** into Stool Apron **3**



b: To Fix Short Stretcher **4** onto Right Side Frame **1**. Also, use Tool **A** and Screw **B** to fix Stool Apron **3** and Long Stretcher **5** onto Right Side Frame **1**.



c: Use Tool **A** and Screw **B** to fix Left Side Frame **2** onto the unit.




Assembly Instructions

Step 2

Fitting the Wooden Seat

Note: It would be useful to ask someone to help you at this stage.

a: Use Screw **D** to fix the Wooden Seat **6** onto the unit.



Step 3

Finishing the unit

Note: It would be useful to ask someone to help you at this stage.

With help, place the unit in the intended position.

Note: Before use always make sure the unit is secure.


Note: The maximum safe weight of user: 110kg.



Warning:

- Do not stand on this chair. Do not use this chair as a step ladder.
- Use this product only for seating one person at a time.
- Do not use this chair unless all bolts, screws and knobs are firmly secured.
- At least every 4 months, check all bolts, screws and knobs, to be sure they are tight.
- If parts are missing, broken or damaged or worn, stop use of this product until repairs are made & using factory authorized parts.
- Failure to follow these warnings could result in serious injury.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**