MADRID SQUARE DINING TABLE

Assembly Instructions - Please keep for future reference

6110657



Dimensions

Width - 96.5cm Depth - 96.5cm Height - 71cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 03456400800 For further assistance please visit http://www.argos-support.co.uk/

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

· This product is manufactured from toughened safety glass. In the unlikely event that the glass fails it will break in to a large number of small fragments that may be spread over a wide area. This is a feature of toughened glass, designed to remove the risk of Injure from glass breaking into large shards.

· If the glass is chipped or broken, stop using the product and consult the manufacturer or supplier.

· Check you have all the components and tools listed on page 2.

· Remove all fittings from the plastic bags and separate them into their groups.

· Keep children and animals away from the work area, small parts could choke if swallowed.

· Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the panels during assembly, this could cause damage.

· Assembly on a soft level surface to avoid damaging the unit or your floor.

· Parts of the assembly will be easier with 2 people.

· Dispose of all packaging carefully and responsibly.

- · Do not sit or stand on this table.
- · Do not place very hot or very cold items on the glass.

· Warning: The unit weighs approximately 16.3 kgs. Please lift with care.

Care and maintenance

· Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. on a regular basis to ensure the proper Do not use bleach, acid, or other solvents on the frame parts.

· Wash glass with mild soap and water, rinse thoroughly, and dry completely.

• Do not use washing powders or any abrasive substances which may scratch the surface.

• Inspect and tighten all bolts and fasteners performance and safety of your table.

· When moving the table, lift. Do not drag this table.

· We recommend the use of furniture covers when not in use.


· In order to prolong the life and beauty of your table, we recommend that it be stored in a dry and protected area when not in use.

· Do not use the glass as chopping surface. Do not strike the glass with hard or pointed items.

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly.




Components - Parts Please check you have all the parts listed below 0 1 Table Top x 1 2 Leg x 4 3 Center Connector x1 4 Center Connector With Ring x1 Tools required ()10 & 13mm Nut Wrench 4mm Hex Key Screwdriver (Not provided) Ruler - Use this ruler to help correctly identify the screws 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 55 2

Assembly Instructions


Step 1

Place the table top 1 onto a non-abrasive surface, such as a carpet, with its underside facing upwards. Insert the legs 2 into the plastic holders attached on the underside of the table top 1 rim. Fix them together by using screws A.



Step 2


Fix the center connector 3 to the middle of the legs 2 by using bolts B, washers (O and D) and plastic nuts C. Keep the bolts loose.



Assembly Instructions

Step 3

Fix the center connector with ring 4 to the middle of the legs 2 by using bolts (and plastic nuts (Make sure that all of the bolts have been tightened completely.



Step 4


Turn the table to its upright position.

Note:

To use an umbrella with this table, remove the center plug and put the umbrella pole through the table top and center connector ring.

A weighted umbrella base shouid be used when using an umbrella with this table.

Assembly is completed.



Warning: Don't detach the plastic support from the table frame! It is for glass support!

If you need help or have damaged or missing parts, call the Customer Helpline: 03456400800 For further assistance please visit http://www.argos-support.co.uk/ Retailer: Argos

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW