


AVR TV Bench

Assembly Instructions - Please keep for future reference

609/0162

609/1422

609/3712



Dimensions

Width - 60cm

Depth - 40cm

Height - 38cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2 and 3.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.

- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the panels during assembly, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the unit or your floor.

- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/driver **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- From time to time check that there are no loose screws on this unit.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

Please check you have all the panels listed below




1 Table Top (60 x 40cm)




2 Bottom (60 x 40cm)




3 Shelf (45 x 29.6cm)



4 Right side (34 x 29.8cm)



5 Left side (34 x 29.8cm)



6 Support (45 x 5cm)










Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A 	B 	C 
Locking pin x 4	Dowel x 6	44mm Screw x 12
D 	E 	F 
17mm Screw x 4	Locking nut x 4	Plastic plug x 8
G 		
Foot x 4		


Tools required



Phillips screwdriver
(medium & large)




Flatblade screwdriver
(medium)



Drill

7mm Masonry drill bit
(for use with wall plug)




Small
hammer



Ruler/tape
measure

Eye protection
(when using a
hammer or glue)

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Fitting the shelf


a: Insert dowels **B** into the shelf **3**.

a:




b: Use screws **C** to fix the right side panel **4** and left side panel **5** onto the support **6** and shelf **3**.

b:



c: Insert dowels **B** into the unit.

c:




Assembly Instructions

Step 2

Fitting the bottom panel


a: Use screws **C** to fix the bottom panel **2** onto the unit.

a:



b: Use screws **D** to fix the feet **G** onto the unit.

b:





Step 3

Fitting the table top

a: Screw locking pins **A** into table top **1**. Insert locking pins as far as shown.


a:






Assembly Instructions

Step 3 - continued

b: Attach table top **1** onto the unit.




c: Insert locking nuts **E** into left side panel **5** and right side panel **4**, then use a screwdriver to turn locking nuts **E** clockwise to lock.



Step 4

Finishing the unit

a: Use plastic plugs **F** to cover the screw heads.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**