


Black Large TV Unit

Assembly Instructions - Please keep for future reference

609/6276



Dimensions

Width - 90.1cm

Depth - 40cm

Height - 38cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**




Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2 and 3.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers **for inserting screws**,

as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components,
call the **Customer Helpline: 08456 400800**


Please check you have all the panels listed below




1 Top panel (90 x 40cm)




2 Bottom panel (90 x 40cm)




3 Right side panel
(32 x 33.4cm)



4 Left side panel
(32 x 33.4cm)



5 Shelf (72 x 30cm)



6 Right back panel
(15 x 33.4cm)








7 Left back panel
(15 x 33.4cm)




Components - Fittings

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.

A  50mm Screw x 16	B  Screw cover x 8	C  Wooden dowel x 2
D  Locking pin x 4	E  Locking nut x 4	F  Foot x 5
G  14mm Screw x 5		

Tools required



Phillips screwdriver
(medium & large)



Flatblade screwdriver
(medium)



Bradawl
(or sharp point)



Small
hammer




Ruler/tape
measure



Eye protection
(when using a
hammer or glue)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1

Attaching side panels

Note: It would be useful to ask someone to help you at this stage.

Use Screws **A** to fix the Right side panel **3** and Left side panel **4** onto the Shelf **5**.

Use Screw covers **B** to cover the screw heads.




Step 2

Attaching back panels

a: Insert Wooden dowels **C** into the Right back panel **6** and Left back panel **7**.

a:



Continued on next page.

Assembly Instructions


Step 2 - continued

b: Use Screws **A** to fix Right back panel **6** onto the Right side panel **3**.

Use Screws **A** to fix Left back panel **7** onto the Left side panel **4**.


Use Screw cover **B** to cover the screw heads.

b:



c: Use Screws **A** to fix Right back panel **6** and Left back panel **7** onto the unit.

c:



Assembly Instructions

Step 3


Attaching top panel

a: Screw Locking pins **D** into the Top panel **1**.

Note: Insert Locking pins as far as shown.

Do not over tighten.


a:



Note: It would be useful to ask someone to help you at this stage.

b: Position unit onto the Top panel **1**.

b:



Continued on next page.



Assembly Instructions

Step 3 - continued

C: Insert Locking nuts **E** into the Right side panel **3** and Left side panel **4**.

Use a screwdriver to turn Locking nuts **E** clockwise to lock.


C:



Step 4

Attaching feet

Use Screws **G** to fix Feet **F** onto the Bottom panel **2**.




Assembly Instructions

Step 5

Attaching bottom panel

Use Screws **A** to fix Bottom panel **2** onto the unit.




Step 6

Finishing the unit

Note: It would be useful to ask someone to help you at this stage.

Carefully stand the TV unit upright.

Place the TV unit in the intended position.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**