


Components



© 1 x Back Panel





Fittings

A 2 x Cap Screw	B 2 x Locking Pin	2 x Locking Nuts	6 x Screw
		AT A)
	1 x Tool		3-06

Verona Corner TV Entertainment Unit

Simple Assembly Instructions - Please keep for future reference



- 1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- 2. Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
- 3. Take all the fittings out of the plastic bag and separate them into their groups.
- 4. Ensure you have enough space to lay out all the parts before assembly.
- 5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

Assembly Instructions

Assembly Instructions


Stage 1 - Fitting the Back Panel

Stage 2 – Fitting the Shelves



 Unscrew Cap Screws A from the Feet E.
 See fig. 1.


2. Use Screws **()** to fix the Back Panel **(C**) onto the Shelf **(B)**. See fig. 2.



) onto the Shelf (B). . **2.**


D

Insert Legs D into the first Shelf
 B, then screw Feet E into the Legs.
 See fig. 3.




- NOTE: It would be useful to ask someone to help you at this stage.
- Carefully locate the second Shelf

 B onto the unit.
 See fig. 4.



- 2. Use Screws **D** to fix the second Shelf **B** onto the Back Panel **C**. **See fig. 5.**
- Screw in Legs D to fix the second Shelf B onto the unit.
 See fig. 5.




Assembly Instructions

Assembly Instructions

Stage 2 – Fitting the Shelves

Stage 3 – Fitting the Table Top




Assembly Instructions

Assembly Instructions

Stage 3 – Fitting the Table Top

Stage 4 - Finishing the Unit



NOTE: It would be useful to ask someone to help you at this stage.

Carefully place the unit in the desired location.
 See fig. 12.



Care and Maintenance

Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting

From time to time please ensure there are no loose screws on the product.