# Components

# (A) 3 x Shelf (B) 4 x Foot (C) (C) (C) (D) (D)






# Fittings





# Verona HiFi Unit

Simple Assembly Instructions - Please keep for future reference



- 1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
- 3. Take all the fittings out of the plastic bag and separate them into their groups.
- 4. Ensure you have enough space to lay out all the parts before assembly.
- 5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

# **Assembly Instructions**

# **Assembly Instructions**

# Stage 1 — Fitting the Legs

# Stage 2 - Finishing the Unit

1. Unscrew Cap Screws A from the Feet B.


See fig. 1.

2. Screw in Legs © to fix the Feet B onto the Shelf A.

See fig. 2.


3. Screw in Short Legs ① to fix the Shelf ② onto the unit.

See fig. 3.



Screw in Cap Screws to fix the other Shelf onto the unit.
 See fig. 4.

Carefully place the unit in the desired location.See fig. 5.



# Care and Maintenance

### Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

### Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

### **Fitting**

From time to time please ensure there are no loose screws on the product.