Ultimate All Surface Swingball® Assembly instructions Adult Assembly Required

⚠ WARNING:







CHOKING HAZARD-Small parts. Not for children under 3 years. Item No: 7224

Add first pole and fill base with sand or water







Fill base with sand or water. For more robust play, please add extra ballast such as sand, bricks or stones for extra stability. Please ensure that the bottom pole is inserted before sand if used.

PLEASE NOTE: Bottom pole has a stopper in the

Insert E clip through hole in the pole before fitting lid.















