

The Original  
**smarTrike®**



[www.smarTrike.com](http://www.smarTrike.com)

[www.youtube.com/user/SmartTrikeOfficial](http://www.youtube.com/user/SmartTrikeOfficial)

607/609/615/617/319/645/665

Thank you for buying smarTrike,  
If you have any assembly issues or are missing  
a part, please call us for assistance. Our  
smarTrike® assembly experts will assist you.

**DO NOT RETURN TO THE STORE**

If you are experiencing problems with this  
product, please call our HELP LINE.

**UK: +44-2035148561**

**9:30am – 5:00pm Monday to Friday**

**Not Bank Holidays or weekends.**

**You can also email us: [help@mookie.co.uk](mailto:help@mookie.co.uk)  
for assistance and advice.**

**USA: 1-855-SMTRIKE**

**(1-855-768-7453)**


607/609




615




645




617



319 A




319 B















665 A



665 B








607/609/615/617/319/645/665

|   |   |  |   |  |                        |
|---|---|--|---|--|------------------------|
| <b>1</b>  |   | 607100   | 607130 x2   | 607120   | 607210                 |
|     |   |     |    |    |                        |
|   |   | <b>A</b>   | <b>B</b>  | <b>C</b>   | <b>D</b>               |
| 607150  | 607220  | 607110   | 607200  | 607141   |                        |
|     |  |     |    |   |                        |
| <b>E</b>  | <b>F</b>  | <b>G</b>   | <b>H</b>  | <b>I</b>   |                        |
| <b>2</b>  |   |  |   |  |                        |
| 607190  |   |  |   |  |                        |
|    |  |     |  |  |                        |
| x4  | x2  |  |   |  |                        |
| <b>J</b>  | <b>K</b>  | <b>L</b>   | <b>M</b>  |  |                        |
| <b>3</b>  |   | 607140   | 665140  | 617140   |                        |
|    | 607/609<br>615/645/319  |    | 665   |   | 617                    |
| <b>N1</b>   |   | <b>N2</b>  | <b>N3</b>   |  |                        |
| 607160  |   |  | 665160  |  |                        |
|  | 607/609<br>615/617/645  |   | 319/665   |  |                        |
| <b>O1</b>   |   | <b>O2</b>  |   |  |                        |
| 615170  |   |  | 665170  |  |                        |
|  | 615/645   |  | 319/665   |  |                        |
| <b>P1</b>   |   | <b>P2</b>  |   |  |                        |
| 665410  |   | 615360   |   | 615310   |                        |
|  | 319B  |   | 319<br>645/665B   |  | 607/609<br>615/645/617 |
| <b>Q</b>  |   | <b>R</b>   | <b>S</b>  |  |                        |





# Step 1

## Parts needed to complete this section





Step 2

Parts needed to complete this section




2a





Insert part D into part C all the way through the hole.


2b



Insert part E into the body of the trike all the way through the hole.



**3a**




**CLICK!**

For 10M+ pull the clutch away from the wheel.


Insert the wheel all the way through the body of the trike until the bolt meets the retaining head.

**3b**







**CLICK!**


Push the apple firmly down to insert, slightly turn until you hear a "click". Make sure white connector is not visible.



Step 4

Parts needed to complete this section





**5a**

319/665

By using the "Allen" key (L), remove screw by turning counter clockwise.

**5b**

319/665

Take the seat (G), push the screw through the seat hole. Screw into the most rear facing hole and firmly tighten with Allen key (L).

**5c**


1


CLICK!

2


CLICK!

With little force, push part H into the apple's holes until you hear a "click". Place back holes into protrusions on the back of the seat.





**WARNING:** This product should be used on safe ground, it should not be used near steps, slopes, roadways, public highways or wet areas.



**6a**

Remove the securing pin with securing lock.

**6b**

**WARNING:** Ensure safety pin is inserted correctly and secured.


Insert the parent handle (1) into the retaining hole on rear of trike. Insert the pin with safety lock. Turn the pin until you hear a click.

**7a**


For the 10+ month stage, open the footrests by pulling it down.

**7b**


Pull down both sides of the footrest.




# 607/609



N1





O1



L


8a

**WARNING:** Nut must be inserted correctly and secured.




Keep the nut in place, remove the screw from part I by turning counter clockwise.

8b




Insert part N1 into part I. Align the hole of part I with the correct hole in part N1.

8c




Use Phillips screwdriver (L) to attach the screw to the nut.

8d




Insert part O1 into the safetybar, until you hear a "click".

607/609







N1



P1




O1



L



8a



Insert part N1 into part P1 by pressing the two buttons. Slide until it "clicks" into position.


8b

**WARNING:** Nut must be inserted correctly and secured.




Remove the screw from part L by turning counter clockwise.

8c



Use Phillips screwdriver (L) to attach the screw to the nut.


8d



Insert part O1 into the the safetybar, until you hear a "click".

615





**8a**

Remove the screw from part N3 by turning counter clockwise.

**8b**

2

1

Insert the bar into part N3. Align the hole of the bar with a hole in part N3. Use Phillips screwdriver (L) to attach the screw to the nut.

**8c**




Wrap hook and loop straps around the parent handle.

**8d**

CLICK!

Insert part O1 into the safetybar, until you hear a "click".

617





319 B




8a

**WARNING:** Nut must be inserted correctly and secured.




Keep the nut in place, remove the screw from part I by turning counter clockwise.

8b




Insert part N1 into part I. Align the hole of part I with the correct hole in part N1. Use Phillips screwdriver (L) to attach the screw to the nut.

8c




Insert part O2 into the the safetybar, until you hear a "click".

8d




Insert part P2 into the the safetybar, until you hear a "click".


319 B



Align part (Q) into the designated holes in the center of the handlebar and push down firmly until it "clicks".

319 B





**8a**

**WARNING:** Nut must be inserted correctly and secured.

Keep the nut in place, remove the screw from part I by turning counter clockwise.

**8b**

Insert part N2 into part I. Align the hole of part I with the correct hole in part N2. Use Phillips screwdriver (L) to attach the screw to the nut.

**8c**

Insert part O2 into the safetybar, until you hear a "click".


**8d**




Insert part P2 into the headrest, until you hear a "click".

665 A

Bag Step


Parts needed to complete this section

| 645  | 319 A   | 319 B   | 665 B   |  |
|--|---|---|---|--|
|  |  |  |  |  <b>(R)</b> |






# Parent Control


10M+




# Child Control




3




4a



4b




5



When the clutch is pushed closed and aligned with the front wheel, child has pedal control.


6a



607/609  
615/617/645

**WARNING:** It may be dangerous to leave your child unattended. Use a safety belt as soon as your child can sit unaided. This seat is not suitable for children under 10 months. Any load attached to the handle affects the stability of the product. This product is not suitable for running or skating.

6b



66528056603