

Single Metal Futon

Assembly Instructions - Please keep for future reference

7585418

7585401



Dimensions

Width - 82cm

Depth - 80-170cm

Height - 30-69.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Because of the size of this unit, it is recommended to assemble it in the room intended for use.

- Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.

- Assemble this product on a flat surface.

- Assemble all parts loosely before tightening any bolts.

- Discard all extra fittings and keep fittings out of reach of children.

- Unit weight: 45kgs.

- At least 2 people are required to assemble this product.

- Retain Assembly Instructions for future reference.



- We do not recommend the use of power drill/drivers **for inserting screws**,

as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

Warnings

- This product should only be used on firm, level ground.

- Make sure the legs remain in contact with the ground.

- Do not stand on the product.

- Keep hands away from folding mechanisms to prevent possible entrapment or injury.

- Do not allow children to jump on the unit as this could cause damage to the frame.

- Folding and unfolding this product should only be carried out under adult supervision.

Care and maintenance


- Please clean the unit surface using either damp (not wet) cloth and a mild domestic soap solution or by using an appropriate polish.

- Do not use any abrasive materials when cleaning.


- From time to time check that there are no loose bolts on this unit.

Components - Parts


Please check you have all the parts listed below




1 Futon side frame x 2
(70 x 30 x 3.2cm)




2 Front / back rail x 2
(76 x 8.5 x 2.5cm)




3 Back frame
(70 x 55 x 2cm)




4 Seat frame
(110 x 70 x 2cm)




5 Front leg
(63 x 26 x 2.4cm)



6 Flap stay
(23.5 x 1.5 x 1cm)




7 Centre leg
(23 x 7.5 x 2.2cm)



Sticker "8"

8 Left futon mechanism
(42.5 x 18 x 5.5cm)



Sticker "9"

















9 Right futon mechanism
(42.5 x 18 x 5.5cm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A  M8 x 40mm Bolt x 8	B  M8 x 30mm Bolt x 12	C  M6 x 60mm Bolt x 1
D  M6 x 50mm Bolt x 1	E  M6 x 30 mm Bolt x 2	F  M6 x 15 mm Bolt x 2
G  M8 Lock nut x 20	H  M6 Lock nut x 4	I  Curved metal washer x 8
J  Spacer x 2	K  Flat metal washer x 3	L  Plastic washer x 1
M  Adhesive pad x 8	N  Allen key x 1	O  Small spanner x 1
P  Big spanner x 1		

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Attaching side frames

Position the side frames **1** as shown and attach the front/back rails **2** using bolts **A**, washers **I** and nuts **G**. Tighten bolts and nuts using allen key **N** and big spanner **P**.




Step 2

Attaching futon mechanisms

Correctly position the left **8** and right **9** futon mechanisms and attach it to side frames **1** using bolts **B** and nuts **G**. Tighten bolts and nuts using allen key **N** and big spanner **P**.




Note: Identify and correctly position the futon mechanisms **8** and **9** by looking for the sticker labels pasted on the rails.



Step 3

Attaching back frame

Position the back frame **3** as shown and attach it to futon mechanisms **8** and **9** using bolts **B** and nuts **G**. Tighten bolts and nuts using allen key **N** and big spanner **P**.





Assembly Instructions

Step 4

Attaching centre leg




Carefully lay the seat frame **4** face down on a flat protected surface. Position the centre leg **7** as shown and attach it to seat frame using bolts **F**. Tighten bolts using allen key **N**.



Step 5

Attaching front leg



Position the front leg **5** and attach it to seat frame **4** using bolt **C**, spacers **J** and nut **H** on one side then using bolt **D**, washers **K** & **L** and nut **H** on the other side as shown. Tighten bolts and nuts using allen key **N** and small spanner **O**.



Step 6

Attaching flap stay

Position the flap stay **6** as shown and attach it to front leg **5** and seat frame **4** using bolts **E**, washers **K** and nuts **H**. Tighten bolts and nuts using allen key **N** and small spanner **O**.





Assembly Instructions

Step 7

Attaching seat frame



Position the seat frame **4** as shown and attach it to futon mechanisms **8** and **9** using bolts **B** and nuts **G**. Tighten bolts and nuts using allen key **N** and big spanner **P**.



Step 8

Attaching adhesive pads

Remove backing from adhesive pads **M** then carefully position it on the top surface of front & back rails **2** and under the four middle rails of seat frames **4** and back frame **3** as shown.



Assembly is complete.

Operation Instructions

Step 1


Folding the futon

a: Carefully pull up the front leg and fold down the front seat frame.


b: Fold down the front leg.

c: Then carefully push in the seat frame and pull up the back rest.


a:



b:



c:



Step 2


Opening the futon

a: Carefully pull out the front seat frame and fold down the back frame.


b: Pull up the front leg.

c: Then carefully open the seat frame as shown.


a:



b:



c:




Warning:

Keep hands away from hinges and folding mechanisms to prevent possible entrapment or injury.




Warning:

This futon can be used only as bed and seat. The reclining position as shown on the right is prohibited for this unit.



Bed position



Seat position



Reclining position

If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**