



How to Enroll your Bianca machine with the Simply-Fi app

Start by opening your Candy Smart-Fi app.

Follow the **onscreen instructions**

You are now required to insert your appliances serial number. With Bianca you can use a quick **QR code** option or **enter manually**.

Once filled, press the arrow button in the top right to proceed. The app will inform you of the products details to confirm everything as it should be.

Press the arrows once more and the app will tell you that the appliance has been recognised.

Now it is time to connect to **Bluetooth**.

If your **Bluetooth** is off it will alert you to this and inform you to turn it on for this stage. **Follow the step by step** process moving forward by swiping the image or selecting the onscreen arrow.

Start by turning on your machine and turn the dial to select the **Wi-Fi option**.

Press and hold the SET button for 3 seconds.

The machine will lock itself and will display '**Wi-Fi Settings**' on the display. **Press and hold the SET button** once again until you see '**Easy Enrollment**'. Press and release SET on the machine, and the display will show '**Connecting**'.

Enter your home **Wi-Fi password**.

Connection process will begin and the app will allow up to **6 minutes to complete**.



The appliance set up should now be complete.

Click START to finish the enrollment.

The product is now **connected** and **ready to use with the app**.

For further information on **How-To Connect**, please click [here](#)