


Components

(A) 3 x Shelf Ring



(B) 3 x Base Shelf



(C) 4 x Plastic Plug



(D) 4 x Bottom Tube



(E) 2 x Top Tube




Fittings

(A) 12 x Nut



(B) 1 x Tool



3 Tier Chrome Organiser

Simple Assembly Instructions - Please keep for future reference



IMPORTANT


1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
2. Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
3. Take all the fittings out of the plastic bag and separate them into their groups.
4. Ensure you have enough space to lay out all the parts before assembly.
5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

Assembly Instructions

Stage 1 – Fitting the Base

1. Place the Bottom Tubes (D) into the ends of the Top Tube (E). Ensure all the holes on the Tubes are facing the same way. And press the Plastic Plugs (C) firmly into the ends of the unit. See fig. 1.

fig. 1



2. Locate the Shelf Ring (A) and the Base Shelf (B) onto the unit. See fig. 2.

NOTE: Make sure all the Shelves and Rings are firmly located in place.




fig. 2

3. Use the Nuts (A) and Tool (B) to fix all the Located Shelves. See fig. 3.




fig. 3

Assembly Instructions

Stage 2 – Finishing the Unit

1. Follow the same method to fix the other Shelves. See fig. 4.




fig. 4

2. Carefully stand the unit up. And place the unit in the desired location. See fig. 5.



fig. 5

Care and Maintenance

Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting

From time to time please ensure there are no loose screws on the product.