
Assembly Instructions

Step 2


Set the lid 1 in place as shown.



If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720

Bathroom Tidy

Assembly Instructions- please keep for future reference



Dimensions

Width - 31cm

Depth - 17cm

Height - 33cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0121 753 7720

LP 260.96.052



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed below and opposite.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly may be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.


(29(w)cm x 15(d)cm)

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels

Please check you have all the panels listed below





4 Front/back x 2 (31(h)cm x 31(w)cm)



3 Side x 2 (31(h)cm x 16(d)cm)

Assembly Instructions


Step 1

Connect the side panels

3 to one of the front/
back panels
4 using 4
x 30mm screw
A.

Slot the bottom 2 into place.

Screw the remaining front/back panel 4 into place using 4 x 30mm screw A.




Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

Components - Fittings If you have damaged or missing components, call the Customer Helpline: 0121 753 7720



Tools required



Ruler – Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170