
Components


(A) 2 x Top Side Panel



(B) 2 x Bottom Side Panel



© 3 x Wire Shelf



Fittings



B 4 x Nut



D 4 x Castor

Chrome 3 Tier Storage Cart

Simple Assembly Instructions - Please keep for future reference



- 1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
- 3. Take all the fittings out of the plastic bag and separate them into their groups.
- 4. Ensure you have enough space to lay out all the parts before assembly.
- 5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

Assembly Instructions

Assembly Instructions

Stage 1 — Fitting the Side Panels

Stage 2 — Fitting the Top Panel


 Insert Top Side Panel (A) onto the top of the Bottom Side Panel (B).
 See fig. 1.

NOTE: Ensure the side rails on Top Side Panel (A) and Bottom Side Panel (B) are aligned on the same side.

2. Use Screws (A) and Nuts (B) to fix the unit.
See fig. 2.

NOTE: Ensure you fit the Screws to the opposite side of the side rails.

3. Use the same method as in fig. 1-2 to fix the other Side Panel.





Stand the Side Panel up and assemble the Wire Shelf
 onto the side with the rails.
 See fig. 3.

NOTE: Make sure that the side rails are facing inwards.



NOTE: Make sure that both the side rails are facing inwards.





Assembly Instructions

Assembly Instructions

Stage 3 — Fitting the Shelves

Stage 4 — Finishing the Unit


1. Place the second Wire Shelf © in through the Side. A small amount of force may be required to secure the shelf.

See fig. 5.



Place the 3rd Wire Shelf © in position the same way as the second shelf.
 See fig. 6.





HH WILLWY

fig. 7

fig. 8

Carefully place the unit in the desired location.See fig. 8.

Care and Maintenance

Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting

From time to time please ensure there are no loose screws on the product.