


Electronic kitchen scale

Insert the enclosed lithium battery in the battery compartment at the back of the scale



Make sure that the positive + side is placed upwards

2

Place the scale on a hard, even surface.



3

To start, touch the **ON/TARE** button.



HELO

4

HELO will show in the display and then **0g**. The scale is now ready to use.



5

Choose the unit of measurement - Kg or Lb. Press the **UNIT** button.



Kg/g



Lb/oz



6

Place the item to be weighed on the platform.





7

Using the TARE button

Start the scale and when **0g** shows in the display place the first item on the platform.







8

Touch the **ON/TARE** button and the display returns to **Og** shows **Tare**.



9

Add the new item and the weight shows in the display.







10

You can continue to use the **ON/TARE** button to get the individual weight of further items.





11

Press **ON/TARE** after the last item, remove all from the scale and the total weight will show in the display.





12

You can turn off the scale by pressing and holding the **ON/TARE** button or the scale will turn off automatically after 60 seconds.



The battery is low. Change to a new battery.



The scale is overloaded. Remove the weight and start again.



HANDLING & CARE

- The scale is a precision instrument. Avoid knocking or dropping it.
- Do not try to dissemble the scale.
- Clean the surface with a glass cleaner. Never immerse it in water or any liquid.
- Keep the scale away from excessive heat or cold.
- The scale is for domestic use only and is not suitable for professional use.
- The total maximum capacity is 5Kg /11lb.

