
Components

A 5 x Support Tube

B 2 x Lower Side Frame



① 4 x Top Plastic Plug



€ 4 x Bottom Plastic Plug





F 4 x Castor

Fittings








Chrome Tidy Rail

Simple Assembly Instructions - Please keep for future reference



- **IMPORTANT**
- 1. Read these instructions carefully and familiarise yourself with the procedure before assembling the unit.
- Check that you have all the component parts following the list on the back cover and familiarise yourself with each part before proceeding.
- 3. Take all the fittings out of the plastic bag and separate them into their groups.
- 4. Ensure you have enough space to lay out all the parts before assembly.
- 5. To avoid scratching it is recommended that you assemble the unit on a soft level surface.

Assembly Instructions

Stage 1 — Fitting the Side Frame

NOTE: It would be useful to ask someone to help you at this stage.

- Insert Lower Side Frame

 into
 Upper Side Frame


 See fig. 1.
 into
 into
- 2. Use Screw (B) to fix the Frames.
 Then press the Top Plastic Plugs
 (D) and Bottom Plastic Plugs (E)
 firmly into the ends of the Side
 Frames.

See fig. 2.

3. Insert the Castors 🕞 firmly into the unit and ensure they are well fitted.

See fig. 3.

- 4. Use the same method as in fig. 1-3 to fix the other Side Frame.
- 5. Use Screws (A) to fix Support Tubes (A) onto the Side Frame. See fig. 4.



Assembly Instructions

Stage 2 — Finishing the Unit

- Use Screws to fix the other Side Frame onto the unit.
 See fig. 5.
- Carefully place the unit in the desired location.
 See fig. 6.




fig. 5

fig. 6

Care and Maintenance

Safety

To avoid any risk of suffocation to animals or children dispose of the plastic bags immediately.

Cleaning

As with all surfaces clean with a damp cloth and mild detergent, do not use bleach or abrasive products.

Fitting

From time to time please ensure there are no loose screws on the product.