Assembly Instructions

Step 3

Note : Stand the chair on a level floor.

a: Tighten all bolts.

Note : Step 3 is essential to prevent the chair from wobbling caused by uneven legs.

b: Sit on the chair to level the legs.

C: After sitting test, re - tighten bolts ,if adjustment is needed.

d: It is highly recommend to re - tighten all the bolts after using the chair for 7 days.

Note : Please keep allen key to re - tighten all bolts when required.

Assembly is complete.



If you need help or have damaged or missing parts, call the Customer Helpline: 0845 6400800

Winslow Bar stool

Assembly Instructions - Please keep for future reference



Dimensions

Width - 40cm Depth - 53cm

Height - 100cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 08456 400800

600/5580 600/5597 600/6280 600/6400



Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on page 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product during assembly, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

 Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

· Dispose of all packaging carefully and responsibly.

· Maximum safe weight of user: 110 Kgs.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

· This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Assembly Instructions

c:Fit the front stretcher rail 7 to the right leg 3 and left leg 4.

C:



d: Turn over the chair. Screw the screw 🕒 into the pre - drilled holes on the front stretcher rail 7 and the right side stretcher rail 5 and the left side stretcher rail 7 using screwdriver.

d:



Assembly Instructions



If you have damaged or missing components, call the **Customer Helpline: 08456 400800**

Components - Parts







4 Left leg x 1





Components - Fittings

Please check you have all the fittings listed below

Note : The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

	B	G ()
Bolt x 8	Spring washer x 8	Washer x 8
Wooden dowel x 2	Screw x 6	Allen key x 1

Tools required



(medium & large)

Ruler - Use this ruler to help correctly identify the screws

0 5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170

Assembly Instructions

Step 1 a: a: Insert wooden dowels D into each centre hole in the back of the seat 2. 0 2 **b:** Insert bolts b: with spring washers B and washers C through the holes at the back of the seat 2 into the chair back 1. Tighten bolts with allen key F. Do not fully tighten. 2 Screw the screw () into the pre - drilled holes on 1 the right side stretcher rail 5 and the left side stretcher rail 6 using screwdriver. 1



