

Constant LCD Display Digital Alarm Clock

CAT NO.: 1182886

Care & Instruction Manual


PLEASE READ THESE INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE REFERENCE

Warnings

- Keep out of reach of children.
- Batteries should only be installed by an adult.

Installation

1. Place your clock face down on a flat surface.
2. Remove the battery cover at the back of the clock.
3. Insert 1 x AAA batteries into the battery compartment by observing the correct "+" and "-" polarity.
4. Replace the battery cover.



Clock Setting

- Hold "SET" button for 2 seconds until the Hour flashes.
- Press "ADJUST" button to adjust the objects and after setting, press "MODE" to exit.
- The setting sequence is shown as follow: 12/24, Hour, Minute.

Calendar Setting

- Short press "MODE" button 2 times then hold "SET" button for 2 seconds.
- Press "ADJUST" button to adjust the data and after setting, press "MODE" to exit.
- The setting sequence is shown as follow: Year, Month, Date.

Alarm

- Short press "MODE" button, then press "ADJUST" to turn on/off alarm  and hourly chime .
- Hold "SET" button for 2 seconds then press "ADJUST" button to adjust the objects and after setting, press "MODE" to exit.
- The setting sequence is shown as follow: Hour, Minute.

- Alarm duration: 60s.
- When the alarm rings, press “SNOOZE” button to activate snooze function, the alarm will repeat every 5 minutes, 4 times in total, with **Z** icon flashing indicating. Or press any other button to stop ringing.

Other Information

- Press “SET” to select Degrees or Fahrenheit temperature display format.
- Press “ADJUST” to toggle the displaying between MAX (recorded), MIN (recorded) or REAL TIME temperature & humidity. And hold “ADJUST” button for 2s to reset.

Specifications

- The accuracy of clock is +/- 2 secs per day.
- The accuracy of thermometer is +/- 1 °C.
- The accuracy of hygrometer is +/- 5%.
- Indoor temperature detecting range: -9.9°C-59.9°C (14.18°F-121.82°F) , resolution: 0.1°C (0.2°F), detecting period: 16s. While figure is out of detecting range, showing LLL°C(°F).
- Indoor humidity detecting range: 20-95%, resolution:1%, detecting period: 16s. While figure is out of detecting range, showing LL%.

Care instructions

- Wipe the clock with a soft dry cloth only.
- Replace the battery every 12 months or when the clock stops.

Battery safety & disposal

- Dispose of any used batteries responsibly by taking it to your local authority household waste recycling facility.
- Don't dispose of batteries in a fire as they may explode.
- This clock will only take 'AAA' 1.5V batteries in this clock.
- Make sure you've inserted the batteries correctly, so you have the correct polarity (+ and -). You should only use batteries that are the equivalent of those recommended above. Don't use rechargeable batteries with this item. And never mix old and new batteries, change them at the same time.



Recycling



We expect this clock to give you many years of use, but when you've finished with it, please don't just throw it in the bin. Do your bit for the environment by recycling electrical items.

Visit www.recycle-more.co.uk click “bank locator” and type in to find your nearest recycling site.

Made in China for Habitat, Argos Limited. Sainsbury's Supermarkets Ltd, London, EC1M 6HA, UK. [Argos \(N.I.\) Ltd](#) and Sainsbury's (NI) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.
habitat.co.uk/help/contact-us