


# MUSHROOM TABLE LAMP

## 1233670

Assembly and User Instructions – Please keep for future reference




**Important** –Please read these instructions fully before using  
If you need help please call our **Customer Services** on **0345 6400800**

## Contents

Section	Page
Parts and Component list	2
Safety Information	3
Maintenance	3
Installation	4

Produced for Argos, UK - 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW / Ireland - Unit 7,  
Ashbourne Retail Park, Ballybin Road, Ashbourne , County Meath

# Parts and Components Listing



- A. Pre-wired base x 1
- B. Metal shade x 1
- C. Shade support frame x 1
- D. Shade ring x 1
- E. Decorative nut x 1

# Safety Information

**IMPORTANT** – Please read these instructions fully before installation and keep for future reference

For your safety, this product must be installed in accordance with local building regulations. If in any doubt, or where required by law, consult a competent person who is registered with an electrical self-certification scheme. Further information is available online or from your local authority.

**IMPORTANT** -This product has been designed for non-professional, domestic use only.

**IMPORTANT** - Carefully unpack and examine the product for any damage. If you think there is a defect, **do not** use the product and contact our customer services on **0345 6400800**.

**IMPORTANT** - Dispose of all packaging correctly and responsibly and in accordance with all local laws and regulations. Never leave packaging components within reach of children as they can be a source of danger.

**IMPORTANT** - Before inserting or replacing bulb(s) ensure the power is switched off and the bulb(s) have cooled down.

**WARNING** - Do not modify or alter any product before or after installation. This may render the product un-safe.

**WARNING** - This is a Class 2 product and does not require an earth connection.

**WARNING** - Accessible parts become hot during use, young children **must** be kept away.

**WARNING** - If replacing the fuse in the plug do not exceed the maximum rated amps as specified on the plug.



**WARNING** - This product is not intended for use by persons (including children) with reduced physical, sensory and mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by persons responsible for their safety.

**WARNING** - Children should be supervised to ensure that they do not play with the product.

**WARNING** - **Do not** place this fitting in a damp atmosphere.

**WARNING** – The luminaire should be positioned so that prolonged staring into the luminaire at distance closer than 0.2m is not expected.

**CAUTION** - Ensure the power is switched off before cleaning or carrying out any maintenance.



# Maintenance

## Maintenance

**CAUTION!** Always disconnect power supply when servicing or cleaning.

### Cleaning

- Use a clean dry soft or slightly damp cloth.
- Do not use abrasive cloths or polishes as this may cause damage to the product.

### Changing the bulbs

**IMPORTANT!** Ensure that the bulb has cooled down before replacing.

- Ensure that the power supply has been disconnected.

### IMPORTANT!

If the external flexible cable or cord of this luminaire is damaged this product must be destroyed.

# Installation

## Installation

**IMPORTANT !** - Electrical connections must be carried out by a suitably qualified person and in accordance with all relevant local building and installation regulations. If in doubt consult a qualified electrician.

### Installation

1. Place the support shade frame onto the lamp holder section.
2. Screw the shade ring onto the lamp holder to secure support frame in place.
3. Screw the bulb (not supplied) into the lamp holder, ensuring you do not exceed maximum bulb size  
Heigh:78mm , Diameter:45mm suitable for this product and the maximum wattage stated on the product.
4. Place the metal shade over the top section of the support frame.
5. Screw the decorative nut into the support frame to secure shade in placed
6. Remove the pin plug cover and plug into a normal household socket.
7. Using the in-line switch, turn on and test.

### Replacement Lamp

Maximum wattage

- See lamp holder

Light bulb shape

- See lamp holder

