


Rattan 4 Seater Set - Bench

Assembly Instructions - Please keep for future reference

146/6904



Dimensions

Width - 113cm

Depth - 71cm

Height - 76cm



Important: Do not fully tighten all screws until assembly is complete.

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW



Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2.

- Remove all fittings from the plastic bags and separate them into their groups.

- Keep children and animals away from the work area, small parts could choke if swallowed.


- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product during assembly, this could cause damage.

- Assemble the item as close to its final position (in the same room) as possible.

- Assemble on a soft level surface to avoid damaging the bench or your floor.

- Parts of the assembly will be easier with 2 people.



- We do not recommend the use of power drill/drivers for inserting screws, as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.

- Maximum safe seated weight: 220kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

- Make sure each screw matches the corresponding figure to ensure correct assembly.

- From time to time check that there are no loose screws on this chair.

- Do not fully tighten all screws until assembly is complete.

- This product should not be discarded with household waste. Take to your local authority waste disposal centre.



Friendly Tips











- Do not fully tighten all screws until assembly is complete.
- Make sure the assembly will be easier with 2 people.

Components - Parts & Fittings

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400800**

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


1  Armrest x 1	2  Armrest x 1	3  Backrest x 1
4  Seat x 1	5  Cushion x 1	A  M6X60mm Screw x 2
B  M6X35mm Screw x 6	C  M6X25mm Screw x 4	D  Washer x 12
E  Screw caps x 12		

Tools provided



F Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws




Assembly Instructions

Step 1

Use long screws **A** and **B** and washers **D** to fix the armrest **1** and **2** to the backrest **3**.




Important:
Do not fully tighten all screws until assembly is complete.



Step 2

Use screws **B** and **C** and washers **D** to fix the armrest **1** and **2** to the seat **4**.

Tighten all the screws and cover all the screws **A** and **B** and **C** with cap **E**.




Important: Do not fully tighten all screws until assembly is complete.

Assembly Instructions


Step 3

Put the seat cushion **5** onto the chair.



Step 4

Assembly is complete



If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit <http://www.argos-support.co.uk>

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW