
Rattan 4 Seater set - Chair

Assembly Instructions - Please keep for future reference

146/6904



mensions

Width - 61cm

Depth - 71cm

Height - 76cm



Important: Do not fully tighten all screws until assembly is complete.

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit http://www.argos-support.co.uk

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW



Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on pages 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product during assembly, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the chair or your floor.
- Parts of the assembly will be easier with 2 people.



• We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

- Dispose of all packaging carefully and responsibly.
- Maximum safe seated weight: 110kgs.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- Make sure each screw matches the corresponding figure to ensure correct assembly.
- From time to time check that there are no loose screws on this chair.
- Do not fully tighten all screws until assembly is complete.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.




Friendly Tips

- Do not fully tighten all screws until assembly is complete.
- Make sure the assemble will be easier with 2 people.

Components - Parts & Fittings If you have damaged or missing components, call the Customer Helpline: Argos = 0345 6400800

Please check you have all the parts & fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Tools provided



Hexkey x 1

Ruler - Use this ruler to help correctly identify the screws

5 10 15 20 25 30 35 40 45 50 55 60 65 70 75 80 85 90 95 100 105 110 115 120 125 130 135 140 145 150 155 160 165 170 laataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataalaataal



Assembly Instructions

Step 1

Use long screws **A**and **B** and washers **D**to fix the armrest **1** and **2** to the backrest **3**.




Important:

Do not fully tighten all screws until assembly is complete.

Step 2

Use screws **3** and **4** washers **1** and **2** to the seat **4**

Tighten all the screws and cover all the screws **A** and **B** and **O** with cap **B**.






Important: Do not fully tighten all screws until assembly is complete.

Assembly Instructions


Step 3

Put the seat cushion 5 onto the chair.



Step 4

Assembly is complete



If you need help or have damaged or missing parts, call the

Customer Helpline: Argos = 0345 6400800

For further assistance please visit http://www.argos-support.co.uk

Address: 489-499 Avebury Boulevard Saxon Gate West, Central Milton Keynes Bucks, MK9, 2NW