Banbury Dining Table

Assembly Instructions - Please keep for future reference


603/3514

603/3521

632/3839

244/4248

571148



Dimensions

Width - 106/135cm

Depth - 80cm

Height - 74.2cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800



✓ Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Assemble this item in the room intended for use.
- At least 2 people are required to assemble this product.
- Do not discard any of the packaging until you have checked that you have all the parts and the pack of fittings.
- Assemble this product on a flat protected surface.
- Assemble all parts loosely

before tightening any bolts.

- Discard all extra fittings and keep fittings out of reach of children.
- · Please note wood is a natural material, some slightly colour and grain variation and natural marks will be present.
- Unit weight: 21.3kgs.
- · Dispose of all packaging carefully and responsibly.

 We do not recommend the use of power drill/drivers for inserting screws,

as this could damage the unit. Only use hand screwdrivers.

· Retain assembly instruction for future reference.

Warnings

- This product should only be used on firm, level ground.
- Make sure the legs remain in contact with the ground.
- Do not stand on the product.

Care and maintenance


- · Wood, a natural product, needs attention, general care.
- Do not lift the table when in its extended state as this may damage the table.
- · Always lift the furniture when moving it around. Never drag.
- · Metal parts should be cleaned with wet cloth only. Do not use abrasive cleaner.
- · From time to time check that there are no loose bolts or screws on this unit.

Components - Parts If you have damaged or missing components, call the Customer Helpline: 0345 640 0800

C

Flat washer x 8


Please check you have all the parts listed below



Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.



Assembly Instructions

Step 1

Attaching legs


Place the table top 1 on a flat protected surface.

Position the legs 2 on the table top 1 and insert the bolts on the legs into holes on the table top as shown.



Important:

Remove plastic tip cover on bolts before assembling.



Step 2

Fixing the legs

Fix the legs 2 using nuts A, spring washers B & washers C.


Tigten the nuts using spanner D.

Carefully turn over the table by holding the legs and place on a firm surface.



Important:

This is a solid wood table. At least 2 people are required to lift this table.



Assembly is complete.

Operation Instructions

Step 1

Extending the table

a: Release the 2 locks under the table top.

With two persons on each end of the table, carefully pull out the table top as shown.

b: Pull out the middle extension top as shown.

C: Open up the middle extension top.

d: Push the table top back in.

Firmly close the gaps by aligning and inserting the metal dowels with the holes on the edge of the table tops.

Fasten the 4 locks under the table top.



Warning:


Keep hands away from gaps when adjusting table tops.




Important:

Do not lift the table when in its extended state as this may damage the table.


a:




b:



C:



d:



Operation Instructions

Step 2

Retracting the table

a: Release the 4 locks under the table top.

With two persons on each end of the table, carefully pull out the table top as shown.

b: Pull up the middle extension top as shown.

C: Fold down the middle extension top.

d: Push the table top back in.


Firmly close the gaps by aligning and inserting the metal dowels with the holes on the edge of the table tops.

Fasten the 2 locks under the table top.




Warning:


Keep hands away from gaps when adjusting table tops. a:




b:



C:



d:



If you need help or have damaged or missing parts, call the Customer Helpline: 0345 640 0800